



**PW50W**

**SERVICE MANUAL**



---

EAS00000

**PW50W  
SERVICE MANUAL  
©2006 by Yamaha Motor Corporation,  
U.S.A.  
First edition, May 2006  
All rights reserved.  
Any reproduction or unauthorized use  
without the written permission of  
Yamaha Motor Corporation, U.S.A.  
is expressly prohibited.  
Printed in U.S.A.  
P/N LIT-11616-20-15**

---

## NOTICE

This manual was produced by the Yamaha Motor Company, Ltd. primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual. Therefore, anyone who uses this book to perform maintenance and repairs on Yamaha vehicles should have a basic understanding of mechanics and the techniques to repair these types of vehicles. Repair and maintenance work attempted by anyone without this knowledge is likely to render the vehicle unsafe and unfit for use.

This model has been designed and manufactured to perform within certain specifications in regard to performance and emissions. Proper service with the correct tools is necessary to ensure that the vehicle will operate as designed. If there is any question about a service procedure, it is imperative that you contact a Yamaha dealer for any service information changes that apply to this model. This policy is intended to provide the customer with the most satisfaction from his vehicle and to conform to federal environmental quality objectives.

Yamaha Motor Company, Ltd. is continually striving to improve all of its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

### NOTE:

- This Service Manual contains information regarding periodic maintenance to the emission control system. Please read this material carefully.
  - Designs and specifications are subject to change without notice.
- 

## IMPORTANT MANUAL INFORMATION

Particularly important information is distinguished in this manual by the following.



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

### **WARNING**

Failure to follow WARNING instructions could result in severe injury or death to the vehicle operator, a bystander or a person checking or repairing the vehicle.

### **CAUTION:**

A CAUTION indicates special precautions that must be taken to avoid damage to the vehicle.

### NOTE:



A NOTE provides key information to make procedures easier or clearer.


























## HOW TO USE THIS MANUAL

This manual is intended as a handy, easy-to-read reference book for the mechanic. Comprehensive explanations of all installation, removal, disassembly, assembly, repair and check procedures are laid out with the individual steps in sequential order.

- ① The manual is divided into chapters. An abbreviation and symbol in the upper right corner of each page indicate the current chapter.  
Refer to "SYMBOLS".
- ② Each chapter is divided into sections. The current section title is shown at the top of each page, except in Chapter 3 ("PERIODIC CHECKS AND ADJUSTMENTS"), where the sub-section title(s) appears.
- ③ Sub-section titles appear in smaller print than the section title.
- ④ To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section.
- ⑤ Numbers are given in the order of the jobs in the exploded diagram. A circled number indicates a disassembly step.
- ⑥ Symbols indicate parts to be lubricated or replaced.  
Refer to "SYMBOLS".
- ⑦ A job instruction chart accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.
- ⑧ Jobs requiring more information (such as special tools and technical data) are described sequentially.



① GEN INFO 	② SPEC 	
③ CHK ADJ 	④ CHAS 	
⑤ ENG 	⑥ CARB 	
⑦ ELEC 	⑧ TRBL SHTG 	
⑨ 	⑩ 	
⑪ 	⑫ 	
⑬ 	⑭ 	
⑮ 	⑯ 	
⑰ 	⑱ 	⑲ 
⑳ 	㉑ 	㉒ 
㉓ 	㉔ New	

## SYMBOLS

The following symbols are not relevant to every vehicle.

Symbols ① to ⑧ indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic checks and adjustments
- ④ Chassis
- ⑤ Engine
- ⑥ Carburetor
- ⑦ Electrical system
- ⑧ Troubleshooting

Symbols ⑨ to ⑯ indicate the following.

- ⑨ Serviceable with engine mounted
- ⑩ Filling fluid
- ⑪ Lubricant
- ⑫ Special tool
- ⑬ Tightening torque
- ⑭ Wear limit, clearance
- ⑮ Engine speed
- ⑯ Electrical data








Symbols ⑰ to ㉔ in the exploded diagrams indicate the types of lubricants and lubrication points.

- ⑰ Engine oil
- ⑱ Gear oil
- ⑲ Molybdenum-disulfide oil
- ㉑ Wheel-bearing grease
- ㉒ Lithium-soap-based grease
- ㉓ Molybdenum-disulfide grease

Symbols ㉔ to ㉔ in the exploded diagrams indicate the following.

- ㉔ Apply locking agent (LOCTITE®)
- ㉔ Replace the part

# TABLE OF CONTENTS

GENERAL INFORMATION	
	GEN INFO <b>1</b>
SPECIFICATIONS	
	SPEC <b>2</b>
PERIODIC CHECKS AND ADJUSTMENTS	
	CHK ADJ <b>3</b>
CHASSIS	
	CHAS <b>4</b>
ENGINE	
	ENG <b>5</b>
CARBURETOR	
	CARB <b>6</b>
ELECTRICAL SYSTEM	
	ELEC <b>7</b>
TROUBLESHOOTING	<b>?</b>
	TRBL SHTG <b>8</b>


---

---

## CHAPTER 1

### GENERAL INFORMATION


<b>VEHICLE IDENTIFICATION .....</b>	<b>1-1</b>
VEHICLE IDENTIFICATION NUMBER .....	1-1
ENGINE SERIAL NUMBER .....	1-1
 <b>IMPORTANT INFORMATION.....</b>	<b>1-2</b>
PREPARATION FOR REMOVAL AND DISASSEMBLY .....	1-2
REPLACEMENT PARTS .....	1-2
GASKETS, OIL SEALS AND O-RINGS .....	1-2
LOCK WASHERS/PLATES AND COTTER PINS .....	1-3
BEARINGS AND OIL SEALS .....	1-3
CIRCLIPS .....	1-3
 <b>CHECKING THE CONNECTIONS .....</b>	<b>1-4</b>
 <b>SPECIAL TOOLS .....</b>	<b>1-5</b>



## GENERAL INFORMATION VEHICLE IDENTIFICATION

### VEHICLE IDENTIFICATION NUMBER

The number ① is stamped into the frame head pipe.






### ENGINE SERIAL NUMBER

The engine serial number ① is stamped into the crankcase.

**NOTE:** \_\_\_\_\_

Designs and specifications are subject to change without notice.

\_\_\_\_\_



## IMPORTANT INFORMATION PREPARATION FOR REMOVAL AND DIS- ASSEMBLY

1. Before removal and disassembly, remove all dirt, mud, dust and foreign material.
2. Use only the proper tools and cleaning equipment.  
Refer to the "SPECIAL TOOLS".
3. When disassembling, always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.
4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
5. Keep all parts away from any source of fire.

EAS00021


## REPLACEMENT PARTS

Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.

EAS00022


## GASKETS, OIL SEALS AND O-RINGS

1. When overhauling the engine, replace all gaskets, seals and O-rings. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. During reassembly, properly oil all mating parts and bearings and lubricate the oil seal lips with grease.



## LOCK WASHERS/PLATES AND COTTER PINS

After removal, replace all lock washers/plates ① and cotter pins. After the bolt or nut has been tightened to specification, bend the lock tabs along a flat of the bolt or nut.




## BEARINGS AND OIL SEALS

Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals, lubricate the oil seal lips with a light coat of lithium-soap-based grease. Oil bearings liberally when installing, if appropriate.


① Oil seal

### CAUTION:

**Do not spin the bearing with compressed air because this will damage the bearing surfaces.**



① Bearing



## CIRCLIPS

Before reassembly, check all circlips carefully and replace damaged or distorted circlips. Always replace piston pin clips after one use. When installing a circlip ①, make sure the sharp-edged corner ② is positioned opposite the thrust ③ that the circlip receives.

④ Shaft





## CHECKING THE CONNECTIONS

Check the leads, couplers, and connectors for stains, rust, moisture, etc.

### 1. Disconnect:

- lead
- coupler
- connector

### 2. Check:

- lead
- coupler
- connector

Moisture → Dry with compressed air.

Rust/stains → Connect and disconnect several times.

### 3. Check:

- all connections

Loose connection → Connect properly.

### NOTE:

If the pin ① on the terminal is flattened, bend it up.

### 4. Connect:

- lead
- coupler
- connector

### NOTE:

Make sure all connections are tight.

### 5. Check:





- continuity  
(with the pocket tester)



**Pocket tester**  
90890-03112, YM-03112

### NOTE:

- If there is no continuity, clean the terminals.
- When checking the wire harness, perform steps (1) to (3).
- As a quick remedy, use a contact revitalizer available at most part stores.












## SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools as this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools, part numbers or both may differ depending on the country.

When placing an order, refer to the list provided below to avoid any mistakes.

Tool No.	Tool name/Usage	Illustration
90890-01189 YM-01189	Flywheel puller  This tool is used for removing the rotor.	
90890-01235 YU-01235	Rotor holding tool  This tool is necessary for removing and installing the rotor.	
90890-01252	Dial gauge and stand set  These tools are for measuring the crankshaft runout.	
90890-01274 YU-90058	Crankshaft instoller pot  This tool is necessary for installing the crankshaft.	
90890-01275 YU-90060	Crankshaft installer bolt  This tool is necessary for installing the crankshaft.	
90890-01278 YU-90063	Adapter (M12)  This tool is necessary for installing the crankshaft.	
90890-01306 YM-01306	Hex. wrench (25 mm)  This tool is needed for removing the middle gear screw.	



Tool No.	Tool name/Usage	Illustration
90890-01307 YM-01307	Hex. wrench (22 mm)  This tool is needed for removing the shaft drive screw.	
90890-01362 YU-33270	Flywheel puller  This tool is used for separating the crankcase.	
90890-03112 YU-03112-U	Pocket tester  This instrument is necessary for checking the electrical system.	
90890-06760 YU-06760	Digital tachometer  This tool is needed for observing engine r/min.	
90890-06754 YM-34487	Ignition checker  This instrument is necessary for checking the ignition system components.	
90890-85505	Yamaha bond No.1215 (Three bond No.1215®)  This bond is used on crankcase mating surfaces,etc.	



---

## CHAPTER 2 SPECIFICATIONS

<b>GENERAL SPECIFICATIONS .....</b>	<b>2-1</b>
<b>MAINTENANCE SPECIFICATIONS .....</b>	<b>2-2</b>
ENGINE .....	2-2
CHASSIS .....	2-6
ELECTRICAL .....	2-10
<b>GENERAL TIGHTENING TORQUE SPECIFICATIONS .....</b>	<b>2-11</b>
<b>DEFINITION OF UNITS .....</b>	<b>2-11</b>
<b>LUBRICATION POINTS AND LUBRICANT TYPES .....</b>	<b>2-12</b>
ENGINE .....	2-12
CHASSIS .....	2-12
<b>CABLE ROUTING .....</b>	<b>2-13</b>

**SPECIFICATIONS****GENERAL SPECIFICATIONS**

Model name:	PW50W (Except for EUROPE) PW50 (For EUROPE)
Model code number:	5PGD (Except for EUROPE) 5PGE (For EUROPE)
Dimensions:	
Overall length	1245 mm (49.0 in)
Overall width	575 mm (22.6 in)
Overall height	715 mm (28.1 in)
Seat height	485 mm (19.1 in)
Wheelbase	855 mm (33.7 in)
Ground clearance	105 mm (4.13 in)
Minimum turning radius	1300 mm (51.2 in)
Weight:	
With oil and fuel	39.0 kg (86 lb)








## MAINTENANCE SPECIFICATIONS



### ENGINE

Item	PW50
Engine type: Induction system Displacement Cylinder arrangement Bore x stroke Compression ratio Starting system	Air cooled 2-stroke Reed valve 49.0 cm <sup>3</sup> (2.99 cu.in) Forward-inclined single cylinder 40.0 x 39.2 mm (1.57 x 1.54 in) 6.00 :1 Kickstarter
Fuel: Recommended fuel  Fuel tank capacity	Regular unleaded gasoline only (For CANADA, EUROPE) Unleaded gasoline only (Except for CANADA,EUROPE) 2.0 L (0.53 US gal) (0.44 Imp.gal)
Engine oil: Lubrication system Type Engine oil quantity Quantity	Separate lubrication (Yamaha autolube) YAMALUBE 2 or 2-stroke engine oil  0.30 L (0.32 US qt) (0.26 Imp.qt)
Transmission oil: Type   Total amount Oil change quantity	YAMALUBE 4 (10W30) or SAE 10W30 (Except for EUROPE) SAE 10W30 (For EUROPE) API service SG type or higher JASO standard MA 0.35 L (0.37 US qt) (0.31 Imp.qt) 0.30 L (0.32 US qt) (0.26 Imp.qt)
Autolube pump: Plunger diameter Color code Minimum stroke Maximum stroke Minimum output/200 strokes Pulley adjusting mark	3.50 mm (0.14 in) YELLOW 0.25-0.30 mm (0.010-0.012 in) 1.00-1.15 mm (0.04-0.05 in) 0.48-0.57 cm <sup>3</sup> (0.03-0.04 cu.in) At idle
Spark plug (s): Manufacturer/model  Spark plug gap	NGK/BP4HS (Except for CANADA,EUROPE) NGK/BPR4HS (For CANADA, EUROPE) DENSO/W14FPL (Except for CANADA,EUROPE) 0.6-0.7 mm (0.024-0.028 in)



Item		PW50
Cylinder head: Volume Warpage limit		6.80 cm <sup>3</sup> (0.41 cu.in) 0.03 mm (0.0012 in)
Cylinder: Bore Wear limit Taper limit Out of round limit		39.993-40.012 mm (1.5745-1.5753 in) 40.100 mm (1.5787 in) 0.050 mm (0.0020 in) 0.010 mm (0.0004 in)
Piston: Piston-to-cylinder clearance Limit Diameter D Height H Offset Offset direction Piston pin bore inside diameter Limit Piston pin outside diameter Limit		0.034-0.047 mm (0.0013-0.0019 in) 0.10 mm (0.0039 in) 39.952-39.972 mm (1.5729-1.5737 in) 5.0 mm (0.20 in) 0.20 mm (0.0079 in) Exhaust side 10.004-10.015 mm (0.3939-0.3943 in) 10.035 mm (0.3951 in) 9.994-10.000 mm (0.3935-0.3937 in) 9.974 mm (0.3927 in)
Piston ring: Top ring Ring type Dimensions (B x T) End gap (installed) Limit Ring side clearance Limit 2nd ring Ring type Dimensions (B x T) End gap (installed) Limit Ring side clearance Limit	 	Keystone 1.50 x 1.80 mm (0.06 x 0.07 in) 0.15-0.35 mm (0.0059-0.0138 in) 0.50 mm (0.0197 in) 0.020-0.060 mm (0.0008-0.0024 in) 0.080 mm (0.0032 in) Keystone 1.50 x 1.80 mm (0.06 x 0.07 in) 0.15-0.35 mm (0.0059-0.0138 in) 0.50 mm (0.0197 in) 0.020-0.060 mm (0.0008-0.0024 in) 0.080 mm (0.0032 in)
Crankshaft: Width A Runout limit C Big end side clearance D Big end radial clearance Small end free play F		37.90-37.95 mm (1.492-1.494 in) 0.050 mm (0.0020 in) 0.350-0.550 mm (0.0138-0.0217 in) 0.350-0.550 mm (0.0138-0.0217 in) 0.40-0.80 mm (0.02-0.03 in)



Item	PW50
Automatic centrifugal clutch: Clutch type Clutch housing inside diameter Wear limit Clutch shoe thickness Wear limit Clutch shoe spring free length Llimit Clutch-in revolution Clutch-stall revolution	Wet, centrifugal automatic 105 mm (4.13 in) 106 mm (4.17 in) 1.0 mm (0.04 in) 0.7 mm (0.03 in) 34.5 mm (1.36 in) 35.5 mm (1.40 in) 2700 r/min 3500 r/min
Transmission: Primary reduction system Primary reduction ratio Secondary reduction system Secondary reduction ratio	Spur gear 63/33 (1.909) Shaft drive 19/15 x 54/11 (6.218)
Kickstarter: Kickstarter type Kick clip friction force P	 Ratchet 1-5 N (0.34-1.33 lbf) (0.15-0.60 kgf)
Air filter: Air filter oil grade	Foam air-filter oil or SAE10W30SE
Carburetor: Type x quantity Manufacturer ID mark Main jet Air jet Jet needle Needle jet Pilot outlet Pilot jet Valve seat size Starter jet 1 Float height Fuel level (using fuel level gauge)	VM12SC x 1 MIKUNI 5PG1 10 #70 2.5 3X24-1 E-2 0.9 #40 1.2 #30 15.5-17.5 mm (0.61-0.69 in) 2.0-4.0 mm (0.08-0.16 in)
Idling condition: Engine idling speed	1650-1750 r/min
Throttle cable free play:	1.5-3.5 mm (0.06-0.14 in)
Reed valve: Thickness T Valve stopper height Llimit Valve bending limit	 0.200 mm (0.0079 in) 4.6-5.0 mm (0.18-0.20 in) 7.4-7.8 mm (0.291-0.307 in) 0.2 mm (0.01 in)





Part to be tightened	Thread size	Q'ty	Tightening torque			Remarks
			Nm	m·kg	ft·lb	
Spark plug	M14 x 1.25	1	20	2.0	14	
Cylinder head	M6 x 1.0	4	10	1.0	7.2	
Autolube pump	M5 x 0.8	2	4	0.4	2.9	
Autolube pump cover	ø5 Tapping	1	4	0.4	2.9	
Primary drive gear	M10 x 1.25	1	30	3.0	22	
Kick crank	M6 x 1.0	1	10	1.0	7.2	
Reed valve-Manifold	M6 x 1.0	4	8	0.8	5.8	
Air filter case	M6 x 1.0	1	4	0.4	2.9	
Ignition coil	M6 x 1.0	2	9	0.9	6.5	
Rotor	M12 x 1.25	1	43	4.3	31	
Stator	M6 x 1.0	2	9	0.9	6.5	
Exhaust manifold	M6 x 1.0	2	9	0.9	6.5	
Exhaust chamber assembly	M8 x 1.25	1	18	1.8	13	
Muffler	M8 x 1.25	1	18	1.8	13	
Exhaust chamber protector	M6 x 1.0	4	9	0.9	6.5	
Bearing retainer (Main axle)	M6 x 1.0	2	12	1.2	8.7	
Middle driven pinion (Screw)	M45 x 1.5	1	60	6.0	43	Left hand thread
Plate bearing cover (Ring gear)	M6 x 1.0	2	12	1.2	8.7	
Crankcase	M6 x 1.0	8	8	0.8	5.8	Yamaha bond No.1215
Crankcase cover (Right)	M6 x 1.0	5	8	0.8	5.8	
Transmission oil drain bolt	M8 x 1.25	1	14	1.4	10	
Oil plug	M14 x 1.5	1	2	0.2	1.4	
Protector (Crankcase cover Right)	M6 x 1.0	1	9	0.9	6.5	
Magneto cover (Left)	M5 x 0.8	3	4	0.4	2.9	
Plate cover (Crankcase Right)	M6 x 1.0	1	9	0.9	6.5	



## CHASSIS

Item	PW50
Chassis: Frame type Caster angle Trail	Steel tube backbone 25.50 degree 50.0 mm (1.97 in)
Front wheel: Wheel type Rim size Rim material Wheel travel Radial wheel runout limit Lateral wheel runout limit	Panel wheel 10x1.50 Steel 60.0 mm (2.36 in) 2.0 mm (0.08 in) 2.0 mm (0.08 in)
Rear wheel: Wheel type Rim size Rim material Wheel travel Radial wheel runout limit Lateral wheel runout limit	Panel wheel 10x1.50 Steel 50.0 mm (1.97 in) 2.0 mm (0.08 in) 2.0 mm (0.08 in)
Front tire: Type Size Manufacturer/model Manufacturer/model Wear limit (front)	With tube 2.50-10 4PR BRIDGESTONE/KNOBBY IRC/KNOBBY 0.8 mm (0.03 in)
Rear tire: Type Size Manufacturer/model Manufacturer/model Wear limit (rear) Tire air pressure (measured on cold tires) Front Rear	With tube 2.50-10 4PR BRIDGESTONE/KNOBBY IRC/KNOBBY 0.8 mm (0.03 in) 100 kPa (15 psi) (1.00 kgf/cm <sup>2</sup> ) (1.00 bar) 100 kPa (15 psi) (1.00 kgf/cm <sup>2</sup> ) (1.00 bar)



Item	PW50
<b>Front brake:</b> Type Operation Front brake lever free play Front drum brake Drum brake type Brake drum inside diameter Limit Lining thickness Limit Shoe spring free length	Drum brake Right hand operation 10.0-20.0 mm (0.39-0.79 in)  Leading, trailing 80.0 mm (3.15 in) 80.5 mm (3.17 in) 3.5 mm (0.14 in) 1.5 mm (0.06 in) 44.5 mm (1.75 in)
<b>Rear brake:</b> Type Operation Rear brake lever free play Rear drum brake Drum brake type Brake drum inside diameter Limit Lining thickness Limit Shoe spring free length	Drum brake Left hand operation 10.0-20.0 mm (0.39-0.79 in)  Leading, trailing 80.0 mm (3.15 in) 80.5 mm (3.17 in) 3.5 mm (0.14 in) 1.5 mm (0.06 in) 44.5 mm (1.75 in)
<b>Steering:</b> Steering bearing type Lock to lock angle (left) Lock to lock angle (right) No./size of steel balls (Upper) (Lower)	Ball and race bearing 48.0 degree 48.0 degree  26 pcs 0.156 in 26 pcs 0.156 in
<b>Front suspension:</b> Type Spring/shock absorber type Front fork travel Fork spring free length Limit Spring rate K1 Spring stroke K1 Inner tube outer diameter Optional spring available Quantity	Telescopic fork Coil spring/oil damper 60.0 mm (2.36 in) 115.0 mm (4.53 in) 112.7 mm (4.44 in) 3.92 N/mm (22.38 lb/in) (0.40 kgf/mm) -5.0-60.0 mm (-0.20-2.36 in) 22.2 mm (0.87 in) No 35.0 cm <sup>3</sup> (1.18 US oz) (1.23 Imp.oz)



Item	PW50
Rear suspension:	
Type	Unit swing
Spring/shock absorber type	Coil spring/oil damper
Rear shock absorber assembly travel	30.0 mm (1.18 in)
Spring free length	153 mm (6.02 in)
Installed length	146 mm (5.75 in)
Spring rate K1	11.89 N/mm (67.94 lb/in) (1.22 kgf/mm)
Spring rate K2	33.4 N/mm (190.71 lb/in) (3.40 kgf/mm)
Spring stroke K1	0.0-27.0 mm (0.00-1.06 in)
Spring stroke K2	27.0-37.0 mm (1.06-1.46 in)
Optional spring available	No



Part to be tightened	Thread size	Q'ty	Tightening torque			Remarks
			Nm	m·kg	ft·lb	
Front wheel axle	M10 x 1.25	1	40	4.0	29	Yamaha bond No.1215 Yamaha bond No.1215
Handlebar	M8 x 1.25	2	19	1.9	13	
Upper bracket — Steering stem	M10 x 1.25	1	32	3.2	23	
Upper bracket — Inner tube	M10 x 1.25	2	32	3.2	23	
Lower bracket — Inner tube	M8 x 1.25	2	23	2.3	17	
Steering nut	BC1	Refer to NOTE				
Engine mount	M10 x 1.25	1	48	4.8	35	
Rear wheel axle nut	M12 x 1.25	1	60	6.0	43	
Rear shock — upper	M6 x 1.0	2	11	1.1	8.0	
— lower	M8 x 1.25	2	23	2.3	17	
Swing arm (L) — Engine (Front)	M8 x 1.25	3	26	2.6	19	
— Gear housing (Rear)	M8 x 1.25	3	26	2.6	19	
Swing arm (R) — Engine (Front)	M8 x 1.25	2	29	2.9	21	
— Bearing housing (Rear)	M8 x 1.25	2	33	3.3	24	
Front brake — Cam shaft lever	M5 x 0.8	1	4	0.4	2.9	
Side cover — Frame	M6 x 1.0	2	7	0.7	5.1	
Rear brake — Cam shaft lever	M5 x 0.8	1	6	0.6	4.3	
Housing cover	M6 x 1.0	3	9	0.9	6.5	
Drive pinion (Screw)	M35 x 1.5	1	50	5.0	36	
Starter lever	M11 x 1.25	1	1	0.1	0.7	
Main stand bracket	M6 x 1.0	2	15	1.5	11	

## NOTE:

1. First tighten the ring nut to 10 Nm (1.0 m · kg, 7.2 ft · lb). Then, after moving the steering a few times right and left, loosen the ring nut.
2. Retighten the ring nut to 0.7 Nm (0.07 m · kg, 0.5 ft · lb) by using the torque wrench.



## ELECTRICAL


Item	PW50
Ignition system: Ignition system Advancer type Ignition timing (B.T.D.C.)	CDI Fixed 16.0 degree/5000 r/min
CDI: Magneto model/manufacturer Pickup coil resistance Source coil resistance CDI unit model/manufacturer	F3L6/YAMAHA 18.0-22.0 $\Omega$ W/R-B 297-363 $\Omega$ B/R-B 3PT-00/YAMAHA
Ignition coil: Model/manufacturer Primary coil resistance Secondary coil resistance Minimum ignition spark gap	2JN/YAMAHA 0.32-0.48 $\Omega$ 5.68-8.52 k $\Omega$ 6.0 mm (0.24 in)
Spark plug cap: Material Resistance	Resin 5.0 k $\Omega$
Flywheel magneto: Lighting coil resistance	0.57-0.69 $\Omega$ W-B



EAS20330

## GENERAL TIGHTENING TORQUE SPECIFICATIONS

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided for each chapter of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross pattern and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.



A: Distance between flats  
B: Outside thread diameter

A (nut)	B (bolt)	General tightening torques	
		Nm	m·kg
10 mm	6 mm	6	0.6
12 mm	8 mm	15	1.5
14 mm	10 mm	30	3.0
17 mm	12 mm	55	5.5
19 mm	14 mm	85	8.5
22 mm	16 mm	130	13.0

## DEFINITION OF UNITS

Unit	Read	Definition	Measure
mm	Millimeter	$10^{-3}$ m	Length
cm	Centimeter	$10^{-2}$ m	Length
kg	Kilogram	$10^3$ gram	Weight
N	Newton	$1 \text{ kg} \times \text{m/sec}^2$	Force
N·m	Newton meter	$\text{N} \times \text{m}$	Torque
m·kg	Meter-kilogram	$\text{m} \times \text{kg}$	Torque
Pa	Pascal	$\text{N/m}^2$	Pressure
N/mm	Newton per millimeter	N/mm	Spring rate
L	Litter	—	Volume or Capacity
cm <sup>3</sup>	Cubic centimeter	—	Volume or Capacity
tr/mn	Rotation per minute	—	Engine speed



## LUBRICATION POINTS AND LUBRICANT TYPES

### ENGINE

Lubrication point	Lubricant
Oil seal lips	
Bearings	
O-rings	
Piston pin	
Piston outside and ring groove	
Piston ring	
Cylinder inner surface	
Connecting rod big end	
Connecting rod small end	
Main axle	
Drive and driven pinion teeth	
Drive axle	
Shaft drive spline	
Kickstarter gear inner surface	
Kickstarter shaft	
Crankcase mating surface	Yamaha bond No.1215

### CHASSIS

Lubrication point	Lubricant
Front wheel oil seal lips	
Front brake camshaft	
Rear wheel oil seal lips	
Rear brake camshaft	
Front wheel axle	
Rear wheel axle	
Throttle grip tube guide inner surface	
Brake lever pivot bolt	
Steering head bearing inner race	
Steering head bearing outer race	
Steering head upper bearing	
Steering head lower bearing	
Pivot shaft (Engine mount)	
Mainstand pivot shaft	
Throttle reel	
Wire end	
Front fork inner tube	
Front fork bushing	





## CABLE ROUTING

① Spark plug lead

② Ignition coil

③ Ground

④ Wire cylinder

⑤ Throttle cable 1

⑥ Throttle cable 2

⑦ Starter cable

⑧ Oil pump cable

⑨ Oil pipe

⑩ Rear brake cable

⑪ Carburetor overflow pipe

⑫ Oil delivery pipe

⑬ C.D.I. magneto lead wire

⑭ C.D.I. unit coupler

⑮ Fuel pipe

⑯ Control unit coupler

⑰ C.D.I unit lead

⑱ Switch cord band

⑲ Fuel pipe

⑳ Control unit lead

A Route it under the down tube.

B Pass the ignition coil lead under the ignition coil.


C Clamp the lead wire to the frame.

D Clamp the coupler lead under the throttle cable 2 and starter cable.

E Route it inside the rear brake cable.

F Route it under the rear brake cable.

G Route it outside the air filter stay.






- ① Throttle cable 1
- ② Throttle cable 2
- ③ Oil pump cable
- ④ Oil pipe
- ⑤ Starter cable
- ⑥ Spark plug lead
- ⑦ Wire harness guide
- ⑧ Wire harness
- ⑨ Rear brake cable
- ⑩ Front brake cable
- ⑪ Band
- ⑫ Starter cable
- ⑬ Fuel tank breather hose

- [A] Clamp the oil pump cable on top of all of the wire harness, starter cable, throttle cable 2 and oil pipe.
- [B] Clamp with the switch cord band the wire harness, throttle cable 2, oil pump cable and starter cable behind the ignition coil lead.
- [C] Pass through the wire harness, stator cable, rear brake cable, oil pipe, and the wire cylinder.


- [D] Fuel tank cap→ between the handlebar protector and front brake cable→ Left side of the front fender installed position→ in front of the oil tank.
- [E] Align the tape on the wire harness with the guide 1.
- [F] Don't twist the front brake cable.
- [G] Clamp the front brake cable.





- ① Throttle cable 1
- ② Front brake cable
- ③ Fuel tank breather hose
- ④ Rear brake cable
- ⑤ Starter cable
- ⑥ Clamp
- ⑦ Guide 2 (front brake cable)
- ⑧ Guide 1 (Wire harness, oil pipe, starter cable)
- ⑨ Oil pipe
- ⑩ Oil tank
- ⑪ Wire harness
- ⑫ Switch cord band

- [A] Clamp the wire harness and starter cable.
- [B] Pass the front brake cable.
- [C] Clamp the wire harness to the handlebar.
- [D] Pass the wire harness, oil pipe and starter cable.



## CHAPTER 3

### PERIODIC CHECKS AND ADJUSTMENTS

<b>INTRODUCTION .....</b>	<b>3-1</b>
<b>PERIODIC MAINTENANCE CHART FOR THE EMISSION CONTROL</b>	
<b>SYSTEM .....</b>	<b>3-1</b>
<b>GENERAL MAINTENANCE AND LUBRICATION CHART .....</b>	<b>3-2</b>
<b>SIDE COVERS, SEAT AND FUEL TANK .....</b>	<b>3-3</b>
<b>ENGINE .....</b>	<b>3-4</b>
CHANGING THE TRANSMISSION OIL .....	3-4
CHECKING THE ENGINE IDLING SPEED .....	3-5
ADJUSTING THE THROTTLE CABLE FREE PLAY .....	3-6
ADJUSTING THE AUTOLUBE PUMP CABLE .....	3-7
ADJUSTING THE AUTOLUBE PUMP MINIMUM STROKE .....	3-7
AIR BLEEDING THE AUTOLUBE PUMP .....	3-9
CHECKING THE EXHAUST SYSTEM .....	3-10
CLEANING THE SPARK ARRESTER AND EXHAUST CHAMBER .....	3-11
CLEANING THE AIR FILTER ELEMENT .....	3-11
CHECKING THE FUEL HOSE .....	3-13
<b>CHASSIS .....</b>	<b>3-13</b>
ADJUSTING THE FRONT AND REAR BRAKE .....	3-13
CHECKING THE FRONT AND REAR BRAKE SHOES .....	3-13
CHECKING AND ADJUSTING THE STEERING HEAD .....	3-14
CHECKING THE FRONT FORK .....	3-15
CHECKING THE TIRES .....	3-16
CHECKING THE WHEELS .....	3-18
CHECKING AND LUBRICATING THE CABLES .....	3-18
LUBRICATING THE LEVER .....	3-19
LUBRICATING THE MAINSTAND .....	3-19
<b>ELECTRICAL .....</b>	<b>3-19</b>
CHECKING THE SPARK PLUG .....	3-19



EAS00036

## PERIODIC CHECKS AND ADJUSTMENTS

### INTRODUCTION

This chapter includes all information necessary to perform recommended checks and adjustments. If followed, these preventive maintenance procedures will ensure more reliable vehicle operation, a longer service life and reduce the need for costly overhaul work. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

EAS00037

### PERIODIC MAINTENANCE CHART FOR THE EMISSION CONTROL SYSTEM

#### NOTE:

- From 18 months, repeat the maintenance intervals starting from 6 months.
- Items marked with an asterisk should be performed by a Yamaha dealer as they require special tools, data and technical skills.

NO.	ITEM	CHECK OR MAINTENANCE JOB	INITIAL			THEREAFTER EVERY	
			1 month	3 months	6 months	6 months	12 months
1	* Fuel line	<ul style="list-style-type: none"> <li>• Check fuel hoses for cracks or damage.</li> <li>• Replace if necessary.</li> </ul>	√	√	√	√	
2	Spark plug	<ul style="list-style-type: none"> <li>• Check condition.</li> <li>• Adjust gap and clean.</li> <li>• Replace if necessary.</li> </ul>	√	√	√	√	
3	Air filter element	<ul style="list-style-type: none"> <li>• Clean with solvent.</li> <li>• Replace if necessary.</li> </ul>		√	√	√	
4	* Carburetor	<ul style="list-style-type: none"> <li>• Check engine idling speed and starter operation.</li> <li>• Adjust if necessary.</li> <li>• Clean.</li> </ul>		√	√	√	
5	* Cylinder head and exhaust system	<ul style="list-style-type: none"> <li>• Check for leakage.</li> <li>• Tighten if necessary.</li> <li>• Decarbonize if necessary.</li> </ul>		√	√	√	
6	* Spark arrester	<ul style="list-style-type: none"> <li>• Clean.</li> </ul>			√	√	

# GENERAL MAINTENANCE AND LUBRICATION CHART




## GENERAL MAINTENANCE AND LUBRICATION CHART

NO.	ITEM	CHECK OR MAINTENANCE JOB	INITIAL			THEREAFTER EVERY	
			1 month	3 months	6 months	6 months	12 months
1	* Front brake	<ul style="list-style-type: none"> <li>Check operation.</li> <li>Adjust brake lever free play.</li> </ul>	√	√	√	√	
		<ul style="list-style-type: none"> <li>Replace brake shoes.</li> </ul>	Whenever worn to the limit				
2	* Rear brake	<ul style="list-style-type: none"> <li>Check operation.</li> <li>Adjust brake lever free play.</li> </ul>	√	√	√	√	
		<ul style="list-style-type: none"> <li>Replace brake shoes.</li> </ul>	Whenever worn to the limit				
3	* Wheels	<ul style="list-style-type: none"> <li>Check runout and for damage.</li> <li>Replace if necessary.</li> </ul>	√	√	√	√	
4	* Tires	<ul style="list-style-type: none"> <li>Check tread depth and for damage.</li> <li>Replace if necessary.</li> <li>Check air pressure.</li> <li>Correct if necessary.</li> </ul>	√	√	√	√	
5	* Wheel bearings	<ul style="list-style-type: none"> <li>Check bearings for smooth operation.</li> <li>Replace if necessary.</li> </ul>					√
6	* Steering bearings	<ul style="list-style-type: none"> <li>Check bearing assemblies for looseness.</li> <li>Moderately repack with lithium-soap-based grease every 2 years.</li> </ul>			√		√
7	* Middle and final gear cases	<ul style="list-style-type: none"> <li>Check for grease leakage.</li> <li>Check gears for damage and wear.</li> <li>Lubricate gears with lithium-soap-based grease.</li> </ul>	√	√	√	√	√
			Every 2 years				
8	* Chassis fasteners	<ul style="list-style-type: none"> <li>Check all chassis fitting and fasteners.</li> <li>Correct if necessary.</li> </ul>	√	√	√	√	
9	* Autolube pump	<ul style="list-style-type: none"> <li>Check operation.</li> <li>Correct if necessary.</li> <li>Bleed.</li> </ul>	√	√	√	√	
10	* Transmission oil	<ul style="list-style-type: none"> <li>Check for oil leakage.</li> <li>Correct if necessary.</li> </ul>	√	√	√	√	
		<ul style="list-style-type: none"> <li>Change.</li> </ul>	√		√		√
11	* Front and rear brake lever pivot	<ul style="list-style-type: none"> <li>Apply lithium-soap-based grease (all-purpose grease) lightly.</li> </ul>		√	√	√	
12	* Centerstand pivot	<ul style="list-style-type: none"> <li>Check operation.</li> <li>Apply lithium-soap-based grease (all-purpose grease) lightly.</li> </ul>		√	√	√	
13	* Shock absorber assemblies	<ul style="list-style-type: none"> <li>Check operation and for oil leakage.</li> <li>Replace if necessary.</li> </ul>	√	√	√	√	
14	* Control cable	<ul style="list-style-type: none"> <li>Apply Yamaha chain and cable lube or engine oil 10W-30 lightly.</li> </ul>		√	√		√
15	* Throttle grip housing and cable	<ul style="list-style-type: none"> <li>Check operation and free play.</li> <li>Apply Yamaha chain and cable lube or engine oil 10W-30 lightly.</li> </ul>	√	√	√	√	

**NOTE:** \_\_\_\_\_  
 The air filter needs more frequent service if you are riding in unusually wet or dusty areas.



## SIDE COVERS, SEAT AND FUEL TANK



Order	Job/Part	Q'ty	Remarks
	<b>Removing the side covers, seat and fuel tank</b>		Remove the parts in the order listed.
1	Flap	1	
2	Side cover	1	
3	Seat	1	
4	Fuel cock	1	Set the fuel cock to "S".
5	Fuel tank	1	
6	Front fender	1	For installation, reverse the removal procedure.





## ENGINE CHANGING THE TRANSMISSION OIL

1. Stand the vehicle on a level surface.

### NOTE:

- Place the vehicle on the mainstand.
- Make sure the vehicle is upright.



2. Start the engine, warm it up for several minutes, and then turn it off.
3. Place a container under the transmission.
4. Remove.
  - Oil filler cap ①
  - Transmission oil drain bolt ②Completely drain the transmission oil.

5. Install:

- Transmission oil drain bolt

14 Nm (1.4 m•kg, 10 ft•lb)

6. Fill:

- Transmission oil  
(with the specified amount of the recommended transmission oil)



### Type:

**YAMALUBE 4 (10W30) or  
SAE 10W30**

**(Except for EUROPE)**

**SAE 10W30 (For EUROPE)**

### Recommended engine oil grade:

**API service SG type or higher  
JASO standard MA**

### Quantity:

**Periodic oil change**

**0.3 L (0.32 US qt) (0.26 Imp.qt)**

**Over haul**

**0.35 L (0.37 US qt) (0.31 Imp.qt)**

7. Install.

- Oil filler cap






## CHECKING THE ENGINE IDLING SPEED

### NOTE:

Prior to checking the engine idling speed, the air filter element should be clean, and the engine should have adequate compression.

1. Start the engine and let it warm up for several minutes.



2. Install:
  - Digital tachometer (onto the spark plug lead ① of cylinder)




**Digital tachometer**  
**90890-06760, YU-06760**

3. Check:
  - Engine idling speed  
Out of specification → Adjust the throttle stop screw.



**Engine idling speed**  
**1650-1750 r/min**



4. Adjust:
  - Engine idling speed


- a. Install the digital tachometer onto the spark plug lead.
- b. Turn the throttle stop screw ② in direction ① or ② until the specified engine idling speed is obtained.



## ADJUSTING THE THROTTLE CABLE FREE PLAY

**NOTE:** \_\_\_\_\_

Prior to adjusting the throttle cable free play, the engine idling speed should be adjusted properly.



1. Check:


- Throttle cable free play (a)  
Out of specification → Adjust.




**Throttle cable free play**  
**1.5-3.5 mm (0.06-0.14 in)**

2. Adjust:

- Throttle cable free play



- Loosen the locknut ① and adjusting nut ②(oil pump cable).
- Loosen the locknut ③(carburetor side), and then turn the adjusting nut ④ in direction (a) or (b) until the specified throttle cable free play is obtained.
- Tighten the locknut.
- Adjust the autolube pump cable. Refer to “ADJUSTING THE AUTOLUBE PUMP CABLE”.
- Loosen the locknut ①(handle grip side), and then turn the adjusting nut ② in direction (a) or (b) until the specified throttle cable free play is obtained.



Direction (a)	Throttle cable free play is increased.
Direction (b)	Throttle cable free play is decreased.

- Tighten the locknut.


### ⚠WARNING

After adjusting the throttle cable free play, start the engine and turn the handlebars to the right and to the left to ensure that this does not cause the engine idling speed to change.





# ADJUSTING THE AUTOLUBE PUMP CABLE/ ADJUSTING THE AUTOLUBE PUMP MINIMUM STROKE

**CHK**  
**ADJ**



## ADJUSTING THE AUTOLUBE PUMP CABLE

1. Remove:
  - Muffler
  - Exhaust chamber assembly
2. Start the engine and turn the throttle grip slowly until slack off the pump cable.
3. Remove:
  - Autolube pump cover (outer) ①
4. Check
  - Pin ①  
Align with the mark (a) on the autolube pump.  
Not aligned → Adjust.



5. Adjust:
  - Autolube pump → alignment mark




- a. Loosen the locknut ①.
- b. Turn the adjust nut ② until align the pin with the mark (a) on the autolube pump.
- c. Tighten the locknut ①.

### NOTE:

After adjusting, be sure to tighten the locknut completely.



6. Install:
  - Autolube pump cover




## ADJUSTING THE AUTOLUBE PUMP MINIMUM STROKE


1. Remove:
  - Seat assembly
  - Muffler
  - Exhaust chamber assembly
  - Air filter case assembly ①

# ADJUSTING THE AUTOLUBE PUMP MINIMUM STROKE

**CHK**  
**ADJ**




2. Remove:
  - Autolube pump cover (outer) ①



3. Install:
  - Dial gauge ①
 Install the dial gauge to the autolube pump plunger, so that the top end is attached.



**Dial gauge and stand set  
90890-01252**



4. Check:
  - Autolube pump minimum stroke



- a. Measure the autolube pump stroke while turning the kick crank slowly.
- b. Loosen the locknut ① and turn the adjusting bolt ② direction ① or ② for proper adjustment.

Direction ①	Autolube pump stroke is increased.
Direction ②	Autolube pump stroke is decreased.



**Minimum stroke:**  
0.25-0.30 mm (0.010-0.012 in)  
**Maximum stroke:**  
1.00-1.15 mm (0.04-0.05 in)

- c. Tighten the locknut ①.



**CAUTION:**

- 

- 

- 

- 


- 3-9**



## CHECKING THE EXHAUST SYSTEM

### **⚠ WARNING**

- Always let the exhaust system cool prior to touching exhaust components.
- Do not start the engine when cleaning the exhaust system.




1. Check
  - Exhaust chamber assembly
  - Muffler
  - Cracks/damage → Replace.
  - Exhaust gas leaks → Replace the gasket.

2. Check:
  - Tightening torque



**Exhaust manifold bolt ①**  
9 Nm (0.9 m•kg, 6.5 ft•lb)  
**Exhaust chamber bolt ②**  
18 Nm (1.8 m•kg, 13 ft•lb)  
**Muffler bolt ③**  
18 Nm (1.8 m•kg, 13 ft•lb)



## CLEANING THE SPARK ARRESTER AND EXHAUST CHAMBER

1. Remove:
  - Tail pipe ①
  - Muffler
  - Exhaust chamber assembly
  - Gasket

2. Check:
  - Tail pipe

### NOTE:

- Use a wire brush to remove any carbon deposits from the spark arrester portion of the tail pipe.
- Tap the tail pipe lightly and remove the carbon deposits from the outside portion of the tail pipe.

- Exhaust chamber  
If the carbon deposit use the round scraper to remove the carbon deposit.

3. Install:
  - Gasket **New**
  - Exhaust manifold bolt

**9Nm (0.9m•kg, 6.5 ft•lb)**



- Exhaust chamber assembly

**18Nm (1.8 m•kg, 13 ft•lb)**

- Muffler

**18Nm (1.8 m•kg, 13 ft•lb)**


- Spark arrester



## CLEANING THE AIR FILTER ELEMENT

1. Remove:
  - Seat assembly
  - Air filter case cover ①

2. Remove:
  - Air filter element ①



## 3. Clean:

- Air filter element
- Clean them with solvent.

## NOTE:

After cleaning, remove the remaining solvent by squeezing the element.

## 4. Check:

- Air filter element

## 5. Apply:

- Foam-air-filter oil or equivalent oil
- To the element.

## NOTE:

Squeeze out the excess oil. Element should be wet but not dripping.

## 6. Install:

- Air filter element
- Air filter case cover


## CAUTION:

Never operate the engine without the air filter element installed. Unfiltered air will cause rapid wear of engine parts and may damage the engine. Operating the engine without the air filter element will also affect carburetor tuning, leading to poor engine performance and possible overheating.

## NOTE:


When installing the air filter element into the air filter case cover, make sure that the sealing surfaces are aligned to prevent any air leaks.





### CHECKING THE FUEL HOSE

1. Check:
  - Fuel hose ①
  - Clack/Damage → Replace




### CHASSIS ADJUSTING THE FRONT AND REAR BRAKE

1. Check:
  - Brake lever free play ①
  - Out of specification → Adjust.



**Brake lever free play (at the end  
of the brake lever)**  
10.0-20.0 mm (0.39-0.79 in)



2. Adjust:
  - Brake lever free play




- a. Turn the adjuster ① in direction ① or ② until the specified brake lever free play is obtained.

Direction ①	Brake lever free play is increased.
Direction ②	Brake lever free play is decreased.

### CAUTION:


After adjusting the brake lever free play, make sure there is no brake drag.



### CHECKING THE FRONT AND REAR BRAKE SHOES


NOTE: \_\_\_\_\_

To remove the front wheel:  
Refer to "FRONT WHEEL" in chapter 4.  
To remove the rear wheel: See  
Refer to "REAR WHEEL" in chapter 4.



# CHECKING THE FRONT AND REAR BRAKE SHOES/ CHECKING AND ADJUSTING THE STEERING HEAD

**CHK**  
**ADJ**



## 2. Check:

- Wear indicator

If the lining thickness of a brake shoe is less than 1.5 mm (0.06 in) → Replace the front or rear brake shoes as a set.

Refer to "FRONT WHEEL, REAR WHEEL AND BRAKE" in chapter 4.

## NOTE:

Be sure to measure the brake lining at the thinnest portion.

## CHECKING AND ADJUSTING THE STEERING HEAD


1. Stand the vehicle on a level surface.

## ⚠ WARNING

Securely support the vehicle so that there is no danger of it falling over.

## NOTE:

Place the vehicle on a suitable stand so that the front wheel is elevated.



## 2. Check:

- Steering head


Grasp the bottom of the front fork legs and gently rock the front fork.

Blinding/looseness → Adjust the steering head.

## 3. Remove:

- Handle protector
- Handle

Refer to "STEERING" in chapter 4.



## 4. Adjust:


- Steering head



- a. Remove the steering stem bolt ①, washer ② and cap bolt ③ washer ④.

# CHECKING AND ADJUSTING THE STEERING HEAD/ CHECKING THE FRONT FORK

**CHK**  
**ADJ**



- b. Tighten the steering nut ⑤ with a wrench.



**Steering nut (1st)**  
**10 Nm (1.0 m•kg, 7.2 ft•lb)**

- c. Lock to lock the steering head a few times.  
d. Fully loosen the steering nut and then tighten the steering nut to specified torque.

## **⚠ WARNING**

**Do not over tighten the steering nut.**



**Steering nut (2nd)**  
**0.7 Nm (0.07 m•kg, 0.5 ft•lb)**

- e. Check the steering head for looseness or binding by turning the front fork all the way in both directions. If any binding is felt, remove the lower bracket and check the upper and lower bearings. Refer to “STEERING” in chapter 4.  
f. Install the oil tank bracket, washer and steering stem bolt, and then tighten the steering stem bolt to specified torque.



**Steering stem bolt**  
**32 Nm (3.2 m•kg, 23 ft•lb)**



5. Install:
- Washer
  - Cap bolt
  - Handle
  - Handle protector



**32Nm (3.2 m•kg, 23 ft•lb)**

Refer to “STEERING” in chapter 4.

## CHECKING THE FRONT FORK

1. Stand the vehicle on a level surface.

## **⚠ WARNING**

**Securely support the vehicle so that there is no danger of it falling over.**

## **NOTE:**

Place the vehicle on a suitable stand so that the front wheel is elevated.




2. Check:

- Inner tube

Damage/scratches → Replace.

Refer to “FRONT FORK” in chapter 4.



3. Hold the vehicle upright and apply the front brake.


4. Check:

- Front fork operation

Push down hard on the handlebar several times and check if the front fork rebounds smoothly.

Rough movement → Repair.

Refer to “FRONT FORK” in chapter 4.



## CHECKING THE TIRES

The following procedure applies to both of the tires.

1. Tire pressure

Out of specification → Regulate.

### **⚠ WARNING**

- The tire pressure should only be checked and regulated when the tire temperature equals the ambient air temperature.
- The tire pressure and the suspension must be adjusted according to the total weight (including cargo, rider, passenger and accessories) and the anticipated riding speed.
- Operation of an overloaded vehicle could cause tire damage, an accident or an injury.

**NEVER OVERLOAD THE VEHICLE.**

### **⚠ WARNING**

It is dangerous to ride with a worn-out tire. When the tire tread reaches the wear limit, replace the tire immediately.



## 2. Check:

- Tire surfaces

Damage/wear → Replace the tire.

**⚠ WARNING**

- Do not use a tubeless tire on a wheel designed only for tube tires to avoid tire failure and personal injury from sudden deflation.
- When using a tube tire, be sure to install the correct tube.
- Always replace a new tube tire and a new tube as a set.
- To avoid pinching the tube, make sure the wheel rim band and tube are centered in the wheel groove.
- Patching a punctured tube is not recommended. If it is absolutely necessary to do so, use great care and replace the tube as soon as possible with a good quality replacement.


Tube wheel	Tube tire only
Tubeless wheel	Tube or tubeless tire

**⚠ WARNING**

After extensive tests, the tires listed below have been approved by Yamaha Motor Co., Ltd. for this model. The front and rear tires should always be by the same manufacturer and of the same design. No guarantee concerning handling characteristics can be given if a tire combination other than one approved by Yamaha is used on this vehicle.



**⚠ WARNING**

After a tire has been repaired or replaced, be sure to tighten the tire air valve stem nut ① to specification.



## CHECKING THE WHEELS/ CHECKING AND LUBRICATING THE CABLES

**CHK**  
**ADJ**



### CHECKING THE WHEELS

The following procedure applies to both of the wheels.

1. Check:
  - Wheel  
Damage/out-of-round → Replace.

#### **⚠ WARNING**

**Never attempt to make any repairs to the wheel.**

#### **NOTE:**

After a tire or wheel has been changed or replaced, always balance the wheel.

### CHECKING AND LUBRICATING THE CABLES

The following procedure applies to all of the inner and outer cables.

#### **⚠ WARNING**

**Damaged outer cable may cause the cable to corrode and interfere with its movement. Replace damaged outer cable and inner cables as soon as possible.**


1. Check:
  - Outer cable  
Damage → Replace.
2. Check:
  - Cable operation  
Rough movement → Lubricate.



**Recommended lubricant**  
**Engine oil or a suitable cable**  
**lubricant**

#### **NOTE:**

Hold the cable end upright and pour a few drops of lubricant into the cable sheath or use a suitable lubricating device.




#### LUBRICATING THE LEVER

Lubricate the pivoting point and metal-to-metal moving parts of the lever.



**Recommended lubricant**  
**Lithium-soap-based grease**




#### LUBRICATING THE MAINSTAND

Lubricate the pivoting point and metal-to-metal moving parts of the mainstand.



**Recommended lubricant**  
**Lithium-soap-based grease**



#### ELECTRICAL CHECKING THE SPARK PLUG

1. Disconnect:
  - Spark plug cap ①
2. Remove:
  - Spark plug


#### CAUTION:

Before removing the spark plug, blow away any dirt accumulated in the spark plug well with compressed air to prevent it from falling into the cylinder.

3. Check:
  - Spark plug typeIncorrect → Change.



**Manufacturer/model**  
**NGK/BP4HS or**  
**DENSO/W14FP-L**  
**(Except for CANADA, EUROPE)**  
**NGK/BPR4HS**  
**(For CANADA, EUROPE)**



## 4. Check:

- Electrode ①

Damage/wear → Replace the spark plug.

- Insulator ②

Abnormal color → Replace the spark plug.

Normal color is medium-to-light tan.

## 5. Clean:

- Spark plug

(with a spark plug cleaner or wire brush)

## 6. Measure:

- Spark plug gap ①

(with a wire thickness gauge)

Out of specification → Regap.



### Spark plug gap

0.6-0.7 mm (0.024-0.028 in)

## 7. Install:

- Spark plug



20 Nm (2.0 m•kg, 14 ft•lb)

### NOTE:

Before installing the spark plug, clean the spark plug and gasket surface.

## 8. Connect:

- Spark plug cap





## CHAPTER 4

### CHASSIS


<b>FRONT WHEEL, REAR WHEEL AND BRAKE</b>	4-1
FRONT WHEEL	4-1
REMOVING THE FRONT WHEEL	4-3
CHECKING THE FRONT WHEEL	4-3
DISASSEMBLING THE FRONT WHEEL	4-4
ASSEMBLING THE FRONT WHEEL	4-5
INSTALLING THE FRONT WHEEL	4-5
FRONT BRAKE	4-7
REMOVING THE FRONT BRAKE	4-8
DISASSEMBLING THE FRONT BRAKE SHOE PLATE	4-8
CHECKING THE FRONT BRAKE	4-9
ASSEMBLING THE FRONT BRAKE SHOE PLATE	4-10
REAR WHEEL AND BRAKE	4-11
REMOVING THE REAR WHEEL	4-13
CHECKING THE REAR WHEEL	4-13
DISASSEMBLING THE REAR BRAKE	4-14
CHECKING THE REAR BRAKE	4-14
ASSEMBLING THE REAR BRAKE	4-14
INSTALLING THE REAR WHEEL	4-15
<b>HANDLEBAR</b>	4-16
REMOVING THE HANDLEBAR	4-17
CHECKING THE HANDLEBAR	4-17
INSTALLING THE HANDLEBAR	4-18
<b>FRONT FORK</b>	4-20
REMOVING THE FRONT FORK LEGS	4-22
DISASSEMBLING THE FRONT FORK LEG	4-23
CHECKING THE FRONT FORK LEG	4-24
ASSEMBLING THE FRONT FORK LEG	4-25
INSTALLING THE FRONT FORK LEGS	4-26
<b>STEERING HEAD</b>	4-27
REMOVING THE LOWER BRACKET	4-28
CHECKING THE STEERING HEAD	4-28
INSTALLING THE STEERING HEAD	4-29
<b>REAR SHOCK ABSORBER ASSEMBLY AND SWINGARM</b>	4-31
REMOVING THE REAR SHOCK ABSORBER ASSEMBLIES	4-32
CHECKING THE REAR SHOCK ABSORBER ASSEMBLY	4-32
INSTALLING THE REAR SHOCK ABSORBER ASSEMBLIES	4-32
REMOVING THE SWINGARM	4-33
CHECKING THE SWINGARM	4-33
INSTALLING THE SWINGARM	4-34
<b>SHAFT DRIVE</b>	4-35
DISASSEMBLING THE SHAFT DRIVE ASSEMBLY	4-37
CHECKING THE SHAFT DRIVE	4-37
ASSEMBLING THE SHAFT DRIVE ASSEMBLY	4-38
INSTALLING THE REAR ARM	4-38




## CHASSIS

### FRONT WHEEL, REAR WHEEL AND BRAKE

#### FRONT WHEEL



Order	Job/Part	Q'ty	Remarks
	<b>Removing the front wheel</b>		
1	Brake cable adjusting nut	1	Remove the parts in the order listed.
2	Front brake cable	1	
3	Pin	1	
4	Spring	1	
5	Axle nut/washer	1/1	
6	Wheel axle	1	
7	Front wheel	1	
8	Brake shoe plate	1	For installation, reverse the removal procedure.
9	Spacer/color	1/1	



Order	Job/Part	Q'ty	Remarks
	<b>Disassembling the front wheel</b>		Disassemble the parts in the order listed.
①	Oil seal	1	
②	Bearing	2	
③	Spacer/coller	1/1	
④	Ring 1	1	
			For assembly, reverse the disassembly procedure.



## REMOVING THE FRONT WHEEL

1. Stand the vehicle on a level surface.

### **⚠ WARNING**


**Securely support the vehicle so that there is no danger of it falling over.**

### **NOTE:**

Place the vehicle on the mainstand so that the front wheel is elevated.

2. Remove:
  - Brake cable adjusting nut
3. Disconnect:
  - Front brake cable at the brake camshaft lever.

4. Remove:
  - Axle nut
  - Washer
  - Wheel axle
  - Front wheel
  - Brake shoe plate
  - Spacer
  - Coller




## CHECKING THE FRONT WHEEL

1. Check:
  - Wheel axleRoll the wheel axle on a flat surface.  
Bends → Replace.

### **⚠ WARNING**

**Do not attempt to straighten a bent wheel axle.**

2. Check:
  - Tire
  - Front wheelDamage/wear → Replace.  
Refer to “CHECKING THE TIRES” and “CHECKING THE WHEELS” in chapter 3.




### 3. Measure:

- Radial wheel runout (a)
- Lateral wheel runout (b)

Over the specified limits → Replace the wheel.




**Radial wheel runout limit**  
**2.0 mm (0.08 in)**  
**Lateral wheel runout limit**  
**2.0 mm (0.08 in)**



### 4. Check:

- Wheel bearings

Front wheel turns roughly (1) or is loose → Replace the wheel bearings.



## DISASSEMBLING THE FRONT WHEEL

### 1. Remove:

- Oil seals
- Wheel bearings




- Clean the outside of the front wheel hub.
- Remove the oil seal (1) with a flat-head screwdriver.

### NOTE:

To prevent damaging the wheel, place a rag between the screwdriver and the wheel surface.

- Remove the wheel bearings (2) with a general bearing puller (3).





### ASSEMBLING THE FRONT WHEEL

1. Install:
  - Wheel bearings
  - Oil seal **New**



- a. Install the new wheel bearings and oil seal in the reverse order of disassembly.

### CAUTION:

**Do not contact the wheel bearing inner race ④ or balls ⑤. Contact should be made only with the outer race ⑥.**

### NOTE:

Use a socket ⑦ that matches the diameter of the wheel bearing outer race and oil seal.




### INSTALLING THE FRONT WHEEL

1. Lubricate:
  - Front wheel axle
  - Wheel bearing
  - Oil seal lip



**Recommended lubricant**  
**Lithium-soap-based grease**



2. Install:
  - Spacer
  - Front wheel
  - Brake shoe plate


### NOTE:

Make sure the slot ① in the brake shoe plate fits over the stopper ② on the outer tube.



3. Tighten:

- Front wheel axle nut

 40 Nm (4.0 m·kg, 29 ft·lb)

**⚠ WARNING**

**Make sure the brake cable is routed properly.**

**CAUTION:**

**Before tightening the wheel axle nut, push down hard on the handlebar(s) several times and check if the front fork rebounds smoothly.**

4. Connect:

- Front brake cable  
at the brake camshaft lever.

5. Install:


- Brake cable adjusting nut

6. Adjust:

- Brake lever free play  
Refer to “CHECKING THE BRAKE  
LEVER FREE PLAY” in chapter 3.



### FRONT BRAKE



Order	Job/Part	Q'ty	Remarks
	<b>Disassembling the front wheel</b>		
①	Brake shoe/brake shoe spring	2/1	Disassemble the parts in the order listed.
②	Nut	1	
③	Bolt	1	
④	Brake camshaft lever	1	
⑤	Brake camshaft	1	
			For assembly, reverse the disassembly procedure.





### REMOVING THE FRONT BRAKE


1. Stand the vehicle on a level surface.

#### **⚠WARNING**

**Securely support the vehicle so that there is no danger of it falling over.**

#### **NOTE:**


Place the vehicle on the mainstand so that the front wheel is elevated.





2. Remove the front wheel.  
Refer to “REMOVING THE FRONT WHEEL”
3. Remove:
  - Brake shoe plate from the front wheel.

### DISASSEMBLING THE FRONT BRAKE SHOE PLATE

1. Remove:
  - Brake shoe spring ①
  - Brake shoe ②
  - Brake camshaft lever ③
  - Brake camshaft ④





### CHECKING THE FRONT BRAKE

#### 1. Check:

- Brake shoe lining  
Glazed areas → Repair.  
Sand the glazed areas with course sand-paper.

#### NOTE:

After sanding the glazed areas, clean the brake shoe with a cloth.

#### 2. Measure:

- Brake shoe lining thickness (a)  
Out of specification → Replace the brake shoe and brake shoe spring as a set.




**Limit**  
**1.5 mm (0.06 in)**

### ⚠ WARNING

**Do not allow oil or grease to contact the brake shoes.**

#### NOTE:

Replace the brake shoes as a set, if either is worn to the wear limit.



#### 3. Measure:


- Brake drum inside diameter (a)  
Out of specification → Replace the wheel.



**Brake drum inside diameter limit**  
**80.5 mm (3.17 in)**

#### 4. Check:


- Brake drum inner surface  
Oil deposits → Clean.  
Remove the oil with a rag soaked in lacquer thinner or solvent.  
Scratches → Repair.  
Lightly and evenly polish the scratches with an emery cloth.



5. Check:

- Brake camshaft

Damage/wear → Replace the brake camshaft




### ASSEMBLING THE FRONT BRAKE SHOE PLATE


1. Install:

- Brake camshaft ①
- Brake camshaft lever ②

4 Nm (0.4 m·kg, 2.9 ft·lb)



- Install the brake camshaft so its punch mark ① is positioned as shown.
- Align the projection on the brake shoe wear indicator with the notch in the brake camshaft.
- Align the punch mark in the brake camshaft with the mark on the brake camshaft lever.
- Check that the brake shoes are properly positioned.




2. Install:

- Brake shoe ③
- Brake shoe spring ④


**NOTE:** \_\_\_\_\_  
Install the shoe spring as shown.



### REAR WHEEL AND BRAKE



Order	Job/Part	Q'ty	Remarks
	<b>Removing the rear wheel and brake</b>		Remove the parts in the order listed.
	Side cover		Refer to "SIDE COVERS, SEAT AND FUEL TANK" in chapter 3.
	Muffler		Refer to "ENGINE REMOVAL" in chapter 5.
	Rear shock absorber lower bolt (right)		Refer to "REAR SHOCK ABSORBER ASSEMBLY AND SWINGARM".
	Swingarm		
1	Brake cable adjusting nut	1	
2	Rear brake cable	1	
3	Pin	1	
4	Spring	1	
5	Rear wheel	1	
6	Ring 1	1	
7	Brake shoe	2	
8	Brake shoe spring	1	
9	Brake camshaft bolt/lockwasher	1/1	



Order	Job/Part	Q'ty	Remarks
10	Brake camshaft lever	1	For installation, reverse the removal procedure.
11	Brake camshaft	1	



### REMOVING THE REAR WHEEL

1. Stand the vehicle on a level surface.

#### **⚠ WARNING**

**Securely support the vehicle so that there is no danger of it falling over.**

#### **NOTE:**


Place the vehicle on the mainstand so that the rear wheel is elevated.

2. Remove
  - Exhaust chamber assembly
  - Muffler.

Refer to “ENGINE REMOVAL” in chapter 5.
3. Remove
  - Swingarm

Refer to “REAR SHOCK ABSORBER ASSEMBLY AND SWINGARM”.
4. Remove:
  - Brake cable adjusting bolt ①
  - Rear brake cable ②
  - Pin ③
  - Spring ④

at the brake camshaft lever.




### CHECKING THE REAR WHEEL

1. Check:
  - Rear wheel

Refer to “CHECKING THE FRONT WHEEL”.
2. Check:
  - Tire
  - Rear wheel

Damage/wear → Replace the rear wheel.  
Refer to “CHECKING THE TIRES” and “CHECKING THE WHEELS” in chapter 3.
3. Measure:
  - Radial wheel runout
  - Lateral wheel runout

Refer to “CHECKING THE FRONT WHEEL”.




### DISASSEMBLING THE REAR BRAKE

1. Remove:
  - Brake shoe ①
  - Brake shoe spring ②
  - Brake camshaft lever ③
  - Lockwasher ④
  - Brake camshaft ⑤

### CHECKING THE REAR BRAKE

1. Check:
  - Brake shoe lining  
Refer to "CHECKING THE FRONT BRAKE".
2. Measure:
  - Brake shoe lining thickness  
Refer to "CHECKING THE FRONT BRAKE".
3. Measure:
  - Brake drum inside diameter  
Refer to "CHECKING THE FRONT BRAKE".
4. Check:
  - Brake drum inner surface  
Refer to "CHECKING THE FRONT BRAKE".
5. Check:
  - Brake camshaft  
Refer to "CHECKING THE FRONT BRAKE".




### ASSEMBLING THE REAR BRAKE

1. Install:
  - Brake camshaft ①
  - Brake camshaft lever ②
  - Lock washer **New** ③  
Bend the tab of the lockwasher.
  - Brake shoe
  - Brake shoe spring



- a. Install the brake camshaft so its punch mark (a) is positioned as shown.

**NOTE:** Hock the return spring onto the stopper.



- b. Check that the brake shoes are properly positioned.



### INSTALLING THE REAR WHEEL

1. Stand the vehicle on a level surface.

#### **WARNING**

**Securely support the vehicle so that there is no danger of it falling over.**

#### **NOTE:**

Place the vehicle on the mainstand so that the rear wheel is elevated.

2. Install:

- Rear wheel
- Swingarm

Refer to “REAR SHOCK ABSORBER ASSEMBLY AND SWINGARM”.

- Rear axle nut

3. Tighten

- Rear axle nut



**60 Nm (6.0 m·kg, 43 ft·lb)**

#### **NOTE:**


While apply the rear brake to Tighten the rear axle nut.

4. Install the exhaust chamber assembly and muffler. Refer to “CLEANING THE SPARK ARRESTER AND MUFFLER” in chapter 3.





## HANDLEBAR



Order	Job/Part	Q'ty	Remarks
	<b>Removing the handlebar</b>		
	Front fender		Remove the parts in the order listed. Refer to "SIDE COVERS, SEAT AND FUEL TANK" in chapter 3. Refer to "STEERING".
	Oil tank		
1	Handle protector	1	
2	Rear brake cable	1	
3	Rear brake lever	1	
4	Front brake cable	1	
5	Front brake lever	1	
6	Ignition control switch	1	
7	Throttle cable	1	
8	Throttle grip assembly	1	
9	Grip	1	
10	Handlebar	1	
			For installation, reverse the removal procedure.




## REMOVING THE HANDLEBAR

1. Stand the vehicle on a level surface.

### **⚠WARNING**

**Securely support the vehicle so that there is no danger of it falling over.**




2. Remove:

- Handle protector
- Ignition control switch ①
- Throttle cable
- Throttle grip ②

### **NOTE:**

While removing the ignition control switch, pull back the rubber cover ③.



3. Disconnect:


- Rear brake lever

4. Remove:

- Grip ①

### **NOTE:**

Blow compressed air between the left handlebar and the handlebar grip, and gradually push the grip off the handlebar.



## CHECKING THE HANDLEBAR

1. Check:

- Handlebar  
Bends/cracks/damage → Replace.

### **⚠WARNING**

**Do not attempt to straighten a bent handlebar as this may dangerously weaken it.**



## INSTALLING THE HANDLEBAR

1. Stand the vehicle on a level surface.

**⚠ WARNING**

**Securely support the vehicle so that there is no danger of it falling over.**

- 2. Install:
  - Handlebar

- ### 3. Tighten:
- Handlebar



**19 Nm (1.9 m·kg, 13 ft·lb)**


- 4. Install:
  - Grip



- Apply a thin coat of rubber adhesive onto the left end of the handlebar.
- Slide the handlebar grip over the left end of the handlebar.
- Wipe off any excess rubber adhesive with a clean rag.

**⚠ WARNING**

**Do not touch the handlebar grip until the rubber adhesive has fully dried.**



5. Install:
- Throttle cable
  - Throttle grip ①

**NOTE:**

Lubricate the inside of the throttle grip with a thin coat of lithium-soap-based grease and install it onto the handlebar.



- 
6. Install:
- Ignition control switch

**⚠ WARNING**

**Make sure the throttle grip operates smoothly.**

---

**NOTE:**


Align the same angle of the ignition control switch with left lever holder, and then install the ignition control switch.

---


7. Connect:
- Front brake cable
  - Rear brake cable
8. Install:
- Handle protector
9. Adjust:
- Throttle cable free play
- Refer to “ADJUSTING THE THROTTLE CABLE FREE PLAY” in chapter 3.



## FRONT FORK



Order	Job/Part	Q'ty	Remarks
	<b>Removing the front fork</b>		
	Handlebar		Remove the parts in the order listed.
	Oil tank		Refer to "HANDLEBAR".
1	Band	1	Refer to "STEERING"
2	Front brake cable	1	
3	Cap bolt/washer	2/2	
4	Lower bracket pinch bolt	2	Loosen.
5	Front fork	2	Do not disassemble the front fork (right) For installation, reverse the removal procedure.
	<b>Disassembling the front fork (left side only)</b>		Disassemble the parts in the order listed.
①	Dust seal	1	
②	Circlip	1	
③	Inner tube	1/1	
④	Bushing	1	
⑤	Collar	1	



Order	Job/Part	Q'ty	Remarks
⑥	Spring	1	For assembly, reverse the disassembly procedure.
⑦	Fork spring	1	
⑧	Damper rubber	1	
⑨	Outer tube	1	

**REMOVING THE FRONT FORK LEGS**

The following procedure applies to both of the front fork legs.

1. Stand the vehicle on a level surface.

**⚠ WARNING**

- Securely support the vehicle so that there is no danger of it falling over.
- Place the vehicle on a suitable stand so that the front wheel is elevated.

2. Remove:


- Handlebar

Refer to “REMOVING THE HANDLEBAR”.

3. Remove:

- Front wheel

Refer to “REMOVING THE FRONT WHEEL”.



4. Remove:

- Front fork cap bolt ①
- Washer

5. Loosen:





- Lower bracket pinch bolt ②

**⚠ WARNING**

**Before loosening the lower bracket pinch bolts, support the front fork leg.**

6. Remove:

- Front fork ③



## DISASSEMBLING THE FRONT FORK LEG

The following procedure applies to the front fork leg.

### CAUTION:

**Do not disassembly the right front fork leg.**

#### 1. Remove:

- Dust seal ①
- Circlip ②

a. Hold the inner tube vertically.

b. Securely clamp the inner tube in a vise with soft jaws.

### CAUTION:

**Do not scratch the inner tube.**

c. Remove the dust seal from outer tube.

d. While pressing down on the front fork, remove the circlip.

#### 2. Remove:

- Inner tube ①
- Outer tube ②

a. Hold the front fork leg horizontally.

b. Securely clamp the outer tube in a vise with soft jaws.

c. Separate the inner tube from the outer tube by pulling the inner tube forcefully but carefully.

#### 3. Remove:

- Spring seat ①
- Fork spring ②
- Damper rubber ③



**CHECKING THE FRONT FORK LEG**

The following procedure applies to the front fork leg.

**1. Check:**

- Inner tube assembly  
Bends/damage/scratches → Replace.

**⚠ WARNING**



**Do not attempt to straighten a bent inner tube as this may dangerously weaken it.**

**2. Measure:**

- Spring free length (a)  
Out of specification → Replace.



**Spring free length**  
**115.0 mm (4.53 in)**

**3. Check:**

- Outer tube assembly ①  
Damage/wear → Replace.

**CAUTION:**

**When disassembling and assembling the front fork leg, do not allow any foreign material to enter the front fork.**

**4. Check:**

- Damper rubber ②  
Damage/wear → Replace.




## ASSEMBLING THE FRONT FORK LEG

The following procedure applies to the front fork leg.


### NOTE:

- When assembling the front fork leg, be sure to replace the following parts:
- Before assembling the front fork leg, make sure all of the components are clean.




### 1. Lubricate:

- Inner tube's outer surface
- Fork spring
- Damper rubber






### 2. Install:

- Damper rubber ①
- Fork spring ②
- Spring seat ③



### 3. Install:

- Inner tube assembly ①
- Spring ②
- Collar ③
- Bushing ④ **New**  
(strike with the flat head driver)



4. Install:
  - Circlip **New** ①

## **⚠WARNING**

**Always use a new circlip.**

## **NOTE:**

- Fully compress the front fork leg, and then install the circlip.
- When installing the circlip ①, make sure the sharp-edged corner ② is positioned opposite the thrust that the circlip receives.

③ Outer tube

## **INSTALLING THE FRONT FORK LEGS**

The following procedure applies to both of the front fork legs.

1. Install:
  - Front fork ①
 Temporarily tighten the lower bracket pinch bolt.
2. Tighten:
  - Lower bracket pinch bolt ②

**23 Nm (2.3 m·kg, 17 ft·lb)**

3. Install:
  - Washer
  - Cap bolt

4. Tighten:
  - Cap bolt ③

**32 Nm (3.2 m·kg, 23 ft·lb)**


## **⚠WARNING**

**Make sure the brake cables are routed properly.**

5. Install:
  - Front wheel
 Refer to “REMOVING THE FRONT WHEEL”.
  - Handlebar
 Refer to “REMOVING THE HANDLEBAR”.



## STEERING HEAD



Order	Job/Part	Q'ty	Remarks
	<b>Removing the steering head</b>		
	Handlebar		Remove the parts in the order listed. Refer to "HANDLEBAR".
1	Steering stem bolt/cap bolt	1/2	
2	Oil tank cap	1	
3	Oil tank	1	Drain the engine oil.
4	Oil tank bracket/starter cable	1/1	
5	Upper bracket	1	
6	Inner fender	1	
7	Ring nut	1	
8	Upper bearing	1	
9	Bearing inner race	1	
10	Lower bracket	1	
11	Bearing inner race	1	
12	Lower bearing	1	
13	Bearing outer race	1	
			For installation, reverse the removal procedure.




## REMOVING THE LOWER BRACKET

1. Stand the vehicle on a level surface.

**⚠ WARNING**

**Securely support the vehicle so that there is no danger of it falling over.**


2. Remove:
- Handlebar
- Refer to “REMOVING THE HANDLEBAR”.




3. Remove:
- Steering stem bolt
  - Washer
  - Upper bracket
  - Oil tank bracket
  - Ring nut ①
  - Upper ball bearing
  - Lower bracket
  - Lower ball bearing

## CHECKING THE STEERING HEAD

1. Wash:
  - Ball bearing
2. Check:
  - Ball bearing
  - Bearing raceDamage/pitting → Replace.
3. Replace:
  - Ball bearing
  - Bearing race



- a. Remove the bearing races from the steering head pipe with a long rod ① and hammer.




- b. Remove the bearing race from the lower bracket with a floor chisel ② and hammer.
- c. Install a new bearing races.

**CAUTION:**

If the bearing race is not installed properly, the steering head pipe could be damaged.

**NOTE:**

- Always replace the bearings and bearing races as a set.
- Whenever the steering head is disassembled, replace the rubber seal.

**INSTALLING THE STEERING HEAD**

## 1. Lubricate:

- Upper ball bearing ①
- Lower ball bearing ②
- Bearing race




**Recommended lubricant**  
**Lithium-soap-based grease**

## 2. Install:

- Lower bracket
- Ring nut

Refer to "CHECKING AND ADJUSTING THE STEERING HEAD" in chapter 3.



## 3. Install:

- Oil tank
- Upper bracket
- Washer ①
- Steering stem bolt ②

**32 Nm (3.2 m·kg, 23 ft·lb)**


## 4. Bleed:

- Autolube pump

Refer to “AIR BLEEDING THE AUTOLUBE PUMP” in chapter 3.



## REAR SHOCK ABSORBER ASSEMBLY AND SWINGARM



Order	Job/Part	Q'ty	Remarks
	<b>Removing the rear shock absorber and swingarm</b>		
	Side cover		Remove the parts in the order listed.
	Muffler		Refer to "SIDE COVERS, SEAT AND FUEL TANK" in chapter 3.
1	Rear shock absorber assembly (Left/right)	1/1	Refer to "ENGINE REMOVAL" in chapter 5.
2	End cap	1	
3	Oil seal	2	
4	Bearing	1	
5	Swingarm	1	
			For installation, reverse the removal procedure.





### REMOVING THE REAR SHOCK ABSORBER ASSEMBLIES


1. Stand the vehicle on a level surface.

#### **⚠ WARNING**

Securely support the vehicle so that there is no danger of it falling over.

#### **NOTE:**

Place the vehicle on a suitable stand so that the rear wheel is elevated.



2. Remove:

- Rear shock absorber assembly bolt (lower) ①
- Rear shock absorber assembly bolt (upper) ②
- Rear shock absorber assembly

### CHECKING THE REAR SHOCK ABSORBER ASSEMBLY

1. Check:

- Rear shock absorber rod (rear shock absorber assembly)  
Damage/wear → Replace.
- Rear shock absorber  
Oil leaks → Replace the rear shock absorber assembly
- Rear shock absorber spring  
Damage/wear → Replace.
- Bushing  
Damage/wear → Replace.
- Bolt  
Bend/damage/wear → Replace.

### INSTALLING THE REAR SHOCK ABSORBER ASSEMBLIES

1. Install:

- Rear shock absorber assembly
- Rear shock absorber bolt (upper) ①
- Rear shock absorber bolt (lower) ②


2. Tighten:




- Rear shock absorber bolt (upper)

11 Nm (1.1 m·kg, 8.0 ft·lb)

- Rear shock absorber bolt (lower)

23 Nm (2.3 m·kg, 17 ft·lb)





## REMOVING THE SWINGARM

1. Remove:
  - Rear shock absorber bolt (lower/right) ①
2. Loosen:
  - Swingarm bolt (rear) ②
  - Swingarm bolt (front) ③
3. Loosen:
  - Rear axle nut ④

## NOTE:

While applying the rear brake, loosen the rear axle nut.

4. Remove:
  - End cap ⑤
  - Rear axle nut
  - Swingarm ⑥

## CHECKING THE SWINGARM

1. Check:
  - Swingarm ①
  - Bend/damage → Replace.
2. Check:
  - End cap ②
  - Damage/wear → Replace.
3. Check:
  - Bearing ③
  - Damage/pitting → Replace.




## INSTALLING THE SWINGARM

### 1. Install:


- Oil seal **New**
- Swingarm
- Rear axle nut
- Swingarm bolt (front)
- End cap
- Swingarm bolt (rear)
- Rear shock absorber bolt (lower/right)

### 2. Tighten


- Swingarm bolt (front)

 **29 Nm (2.9 m·kg, 21 ft·lb)**


- Swingarm bolt (rear)

 **33 Nm (3.3 m·kg, 24 ft·lb)**

- Rear axle nut

 **60 Nm (6.0 m·kg, 43 ft·lb)**

- Rear shock absorber bolt (lower/right)

 **23Nm (2.3 m·kg, 17 ft·lb)**

### NOTE: \_\_\_\_\_

While apply the rear brake to tighten the rear axle nut.


### 3. Install:

- Exhaust chamber assembly
- Muffler.


Refer to “ENGINE REMOVAL” in chapter 5.



## SHAFT DRIVE



Order	Job/Part	Q'ty	Remarks
	<b>Removing the shaft drive</b>		
	Rear shock absorber (left/right)		Remove the parts in the order listed. Refer to "REAR SHOCK ABSORBER ASSEMBLY AND SWINGARM".
	Swingarm		
	Rear wheel		Refer to "FRONT WHEEL, REAR WHEEL AND BRAKE".
1	Drive shaft housing	1	
2	Rear arm	1	
3	Drive shaft	1	
4	Circlip	1	
5	Spring retainer	1	
6	Compression spring	1	
7	Housing cover	1	
8	O-ring	1	
9	Ring gear	1	
10	Plate cover	1	
11	Bearing	2	



Order	Job/Part	Q'ty	Remarks
12	Spacer	1	
13	Screw	1	
14	Bearing	1	
15	Spacer	1	
16	Drive pinion gear	1	
			For installation, reverse the removal procedure.




## DISASSEMBLING THE SHAFT DRIVE ASSEMBLY

1. Remove:
  - Housing cover
  - O-ring
  - Ring gear

### NOTE:

1/4 of a turn. After all of the bolts are fully loosened, remove them.



2. Remove:
  - Screw ①  
(with the special tool ②)



**Hexagon wrench:**  
90890-01307, YM-01307


3. Remove:
  - Spacer
  - Bearing
  - Shim

### CAUTION:

The drive pinion gear should only be removed if ring gear replacement is necessary.

### NOTE:

Lightly tap on the end of the drive pinion gear with a soft hammer.



## CHECKING THE SHAFT DRIVE

1. Check:
  - Ring gear ①  
Galling/pitting/wear → Replace.
2. Check:
  - Drive pinion gear ②  
Galling/pitting/wear → Replace.
3. Check:
  - Bearing  
Damage/pitting → Replace.




## ASSEMBLING THE SHAFT DRIVE ASSEMBLY

1. Lubricate:
  - Drive pinion gear
  - Ring gear



**Recommended lubricant**  
**Lithium-soap-based grease**

2. Install:
  - Drive pinion gear
  - Shim
  - Bearing
  - Spacer
  - Bearing




3. Install:
  - Screw ① **50 Nm (5.0 m·kg, 36 ft·lb)**  
(with the special tool ②)



**Hexagon wrench:**  
**90890-01307, YM-01307**

4. Install:
  - Ring gear
  - O-ring **New**
  - Housing cover



## INSTALLING THE REAR ARM

1. Apply:
  - Yamaha bond No. 1215 (Three Bond No. 1215®) ①  
(to the mating surfaces of both arm ends)



**Yamaha bond No. 1215**  
**(Three Bond No. 1215®)**  
**90890-85505**

### NOTE:

Clean the contacting surface of rear arm ends before applying the sealant.

2. Tighten:
  - Rear arm bolt



**26 Nm (2.6 m·kg, 29 ft·lb)**



## CHAPTER 5 ENGINE

<b>ENGINE REMOVAL</b> .....	5-1
MUFFLER AND EXHAUST CHAMBER ASSEMBLY .....	5-1
ENGINE .....	5-2
REMOVING THE ENGINE .....	5-3
INSTALLING THE ENGINE .....	5-5
<b>CYLINDER HEAD, CYLINDER AND PISTON</b> .....	5-8
CYLINDER HEAD AND CYLINDER .....	5-8
PISTON .....	5-9
REMOVING THE CYLINDER HEAD .....	5-10
REMOVING THE CYLINDER .....	5-10
REMOVING THE PISTON .....	5-10
CHECKING THE CYLINDER HEAD .....	5-11
CHECKING THE CYLINDER AND PISTON .....	5-12
CHECKING THE PISTON RINGS .....	5-13
CHECKING THE PISTON PIN AND SMALL END BEARINGS .....	5-14
INSTALLING THE PISTON RING AND PISTON .....	5-15
INSTALLING THE CYLINDER AND CYLINDER HEAD .....	5-16
<b>REED VALVE</b> .....	5-18
REMOVING THE REED VALVE .....	5-19
CHECKING THE REED VALVE .....	5-19
ASSEMBLING AND INSTALLING THE REED VALVE .....	5-20
<b>CLUTCH</b> .....	5-21
REMOVING THE CLUTCH .....	5-23
CHECKING THE PRIMARY DRIVE GEAR .....	5-24
CHECKING THE PRIMARY DRIVEN GEAR .....	5-24
CHECKING THE CLUTCH HOUSING .....	5-24
CHECKING THE CLUTCH SHOES .....	5-24
INSTALLING THE CLUTCH .....	5-25
<b>AUTOLUBE PUMP</b> .....	5-27
REMOVING THE AUTOLUBE PUMP .....	5-28
DISASSEMBLING THE AUTOLUBE PUMP .....	5-29
CHECKING THE AUTOLUBE PUMP .....	5-29
ASSEMBLING THE AUTOLUBE PUMP .....	5-30
INSTALLING THE AUTOLUBE PUMP .....	5-30
<b>KICK STARTER</b> .....	5-31
REMOVING THE KICK STARTER .....	5-32
CHECKING THE KICK STARTER .....	5-32
INSTALLING THE KICK STARTER .....	5-33
<b>CDI MAGNETO</b> .....	5-34
REMOVING THE CDI MAGNETO .....	5-35
CHECKING THE CDI MAGNETO .....	5-36
INSTALLING THE CDI MAGNETO .....	5-36
<b>CRANKCASE AND CRANKSHAFT</b> .....	5-38
REMOVING THE CRANKCASE .....	5-40
CHECKING THE CRANKCASE .....	5-40





---


CHECKING THE CRANKSHAFT .....	5-41
INSTALLING THE CRANKSHAFT .....	5-42
<b>MIDDLE GEAR</b> .....	5-44
REMOVING THE MIDDLE DRIVE SHAFT ASSEMBLY .....	5-46
CHECKING THE MEDDLE GEAR .....	5-46
INSTALLING THE MEDDLE GEAR .....	5-46



## ENGINE

## ENGINE REMOVAL


## MUFFLER AND EXHAUST CHAMBER ASSEMBLY



Order	Job/Part	Q'ty	Remarks
	<b>Removing the muffler and exhaust chamber assembly</b>		Remove the parts in the order listed.
1	Muffler assembly	1	
2	Exhaust chamber assembly	1	
3	Gasket (Power reduction plate)	1	
			For installation, reverse the removal procedure.



## ENGINE



Order	Job/Part	Q'ty	Remarks
	<b>Removing the engine</b>		Remove the parts in the order listed.
	Side cover		Refer to "SIDE COVERS, SEAT AND FUEL TANK" in chapter 3.
	Rear shock absorber bolt (lower)		Refer to "REAR SHOCK ABSORBER ASSEMBLY AND SWINGARM" in chapter 4.
	Swingarm		Refer to "SWINGARM" in chapter 4.
	Rear brake cable		Refer to "REAR WHEEL" in chapter 4.
	Oil hose/autolube pump assembly		Refer to "AUTOLUBE PUMP".
	Air filter case/carburetor		Refer to "CARBURETOR" in chapter 6.
1	CDI magneto lead coupler/connector	1/2	Disconnect.
2	Spark plug cap	1	Disconnect.
3	Pivot shaft nut	1	
4	Pivot shaft	1	
5	Engine assembly	1	
			For installation, reverse the removal procedure.

**REMOVING THE ENGINE**

1. Stand the vehicle on a level surface.

**⚠WARNING**

**Securely support the vehicle so that there is no danger of it falling over.**


**NOTE:**

Place the vehicle on the mainstand so that the rear wheel is elevated.

2. Remove:


- Side cover

Refer to "SIDE COVERS SEAT AND FUEL TANK" in chapter 3.



3. Remove:

- Air filter case assembly ①



4. Disconnect:

- Oil hose
- Oil delivery hose ①
- Fuel hose

**⚠WARNING**

**Turn the fuel cock lever to "S" position, and then disconnect the fuel hose.**

5. Remove:


- Carburetor assembly

Refer to "CARBURETOR" in chapter 6.




6. Remove:
- Muffler assembly
  - Exhaust chamber assembly


7. Remove:
- Rear shock absorber bolt (lower/right side)
  - Rear axle nut
  - Rear shock absorber arm
- Refer to "REAR SHOCK ABSORBER ASSEMBLY AND SWINARM" in chapter 4.



8. Remove:
- Brake cable adjusting nut ①
  - Rear brake cable ②
  - Pin ③
  - Spring ④




9. Remove:
- Autolube pump cover (outer) ①



10. Remove:
- Oil hose/autolube pump cable
  - Autolube pump assembly ①  
(remove with the autolube pump cover (inner) ②)


**CAUTION:**

Whenever disconnect the oil delivery hose, be sure cap the oil hose by proper bolt to prevent the engine oil to spilt out.




11. Remove:

- Spark plug cap ①
- Rear shock absorber bolt (lower/left)



12. Disconnect:

- CDI magneto lead coupler/connector ①



13. Remove:

- Pivot shaft ①

### NOTE:

- While removing the engine, pull out the pivot shaft, and then remove the frame assembly.
- Be sure to check the wire, cable and hose disconnected.


## INSTALLING THE ENGINE

### ⚠WARNING

Securely support the engine assembly so that there is no danger of it falling over.


### NOTE:

Place the engine assembly on the mainstand so that the rear wheel is elevated.



1. Install:


- Engine assembly  
To install the frame.




2. Install:
  - Pivot shaft ①
  - Pivot shaft nut


**NOTE:** \_\_\_\_\_  
Install the pivot shaft to temporarily.

3. Tighten:
  - Pivot shaft nut


 **48 Nm (4.8 m·kg, 35 ft·lb)**




4. Connect:
  - CDI magneto lead coupler/connector ①




5. Install:
  - Rear shock absorber bolt (lower/left)

 **23 Nm (2.3 m·kg, 17 ft·lb)**

- Spark plug cap ①



6. Install:
  - Autolube pump assembly ①
  - With the autolube pump cover (inner) ②
  - Autolube pump cable/oil hose ③
  - Autolube pump cover (outer)



7. Install:
  - Spring ①
  - Pin ②
  - Rear brake cable ③
  - Brake cable adjusting nut ④



### 8. Install

- Swingarm bolt (front)

29 Nm (2.9 m·kg, 21 ft·lb)

- Swingarm bolt (rear)

33 Nm (3.3 m·kg, 24 ft·lb)

- Rear axle nut

60 Nm (6.0 m·kg, 43 ft·lb)

- Rear shock absorber bolt (lower/right)

23Nm (2.3 m·kg, 17 ft·lb)

### NOTE:

While apply the rear brake to tighten the rear axle nut.

### 9. Install:

- Exhaust manifold bolt


9 Nm (0.9 m·kg, 6.5 ft·lb)

- Exhaust chamber bolt

18 Nm (1.8 m·kg, 13 ft·lb)

- Muffler bolt

18 Nm (1.8 m·kg, 13 ft·lb)




### 10. Install:

- Carburetor assembly  
Refer to “CARBURETOR” in chapter 6.

### 11. Connect:

- Fuel hose
- Oil delivery hose ①
- Oil hose



### 12. Install:

- Air filter case assembly ①

### 13. Install:

- Side cover  
Refer to “SIDE COVERS SEAT AND FUEL TANK” in chapter 3.

### 14. Bleed:


- Autolube pump  
Refer to “AIR BLEEDING THE AUTOLUBE PUMP” in chapter 3.





# CYLINDER HEAD, CYLINDER AND PISTON


## CYLINDER HEAD AND CYLINDER




Order	Job/Part	Q'ty	Remarks
	<b>Removing the cylinder</b>		
	Exhaust chamber assembly		Remove the parts in the order listed.
	Spark plug cap		Refer to "ENGINE REMOVAL."
1	Spark plug	1	
2	Cylinder head	1	
3	Gasket	1	
4	Cylinder	1	
5	Gasket	1	
			For installation, reverse the removal procedure.




PISTON



Order	Job/Part	Q'ty	Remarks
	<b>Removing the piston</b>		
	Cylinder head		Remove the parts in the order listed.
	Cylinder		
1	Piston pin clip	2	
2	Piston pin	1	
3	Piston	1	
4	Top ring	1	
5	2nd ring/expander ring	1/1	
6	Connecting rod small end bearing	1	
			For installation, reverse the removal procedure.

**REMOVING THE CYLINDER HEAD**

1. Remove:
  - Exhaust chamber assembly
  - Spark plug cap ①
  - Spark plug




2. Remove:
  - Cylinder head
  - Gasket

**NOTE:**

Loosen the nut to in the crisscross pattern and 2 or 3 stages as shown.

**REMOVING THE CYLINDER**

1. Remove:
  - Cylinder
  - Gasket

**REMOVING THE PISTON**


1. Remove:
  - Piston pin clips ①
  - Piston pin ②
  - Piston ③


**CAUTION:**

Do not use a hammer to drive the piston pin out.

**NOTE:**

- Before removing the piston pin clip, cover the crankcase opening with a clean rag to prevent the piston pin clip from falling into the crankcase.
- Before removing the piston pin, deburr the piston pin clip's groove and the piston's pin bore area. If both areas are deburred and the piston pin is still difficult to remove.






## 2. Remove:

- Top ring
- Second ring  
(with expander ring)

**NOTE:**

When removing a piston ring, open the end gap with your fingers and lift the other side of the ring over the piston crown.

**CHECKING THE CYLINDER HEAD**


## 1. Eliminate:

- Combustion chamber carbon deposits  
(with a rounded scraper)

**NOTE:**


Do not use a sharp instrument to avoid damaging or scratching.

- Spark plug bore threads



## 2. Eliminate:

- Exhaust port carbon deposits  
(with a rounded scraper)



## 3. Check:

- Cylinder head  
Damage/scratches → Replace the cylinder head.

## 4. Measure:

- Cylinder head warpage  
Out of specification → Resurface the cylinder head.



**Warpage limit**

**0.03 mm (0.0012 in)**



- Place a straightedge ① and a thickness gauge ② across the cylinder head.
- Measure the warpage.
- If the limit is exceeded, resurface the cylinder head as follows.
- Place a 400-600 grit wet sandpaper on the surface plate and resurface the cylinder head using a figure-eight sanding pattern.

**NOTE:**

To ensure an even surface, rotate the cylinder head several times.

- e. After resurfacing, out of specification → Replace the cylinder head.


## CHECKING THE CYLINDER AND PISTON

1. Check:
  - Piston wall
  - Cylinder wallVertical scratches → Rebore or replace the cylinder, and replace the piston and piston rings as a set.
2. Measure:
  - Piston-to-cylinder clearance

- a. Measure cylinder bore “C” with the cylinder bore gauge.

**NOTE:**

Measure cylinder bore “C” by taking side-to-side and front-to-back measurements of the cylinder. Then, find the average of the measurements.



### Bore "C"


## Bore

**39.993-40.012 mm (1.5745-1.5753 in)**

### Taper limit “T”

## Warp limit

**0.050 mm (0.0020 in)**



"C" = maximum of  $D_1 - D_6$

"T" = (maximum of  $D_1$  or  $D_2$ ) - (maximum of  $D_5$  or  $D_6$ )

- b. If out of specification, replace the cylinder, and replace the piston and piston rings as a set.
- c. Measure piston skirt diameter "D" with the micrometer.

(a) 5 mm (0.20 in) from the bottom edge of the piston



#### Diameter D

39.952-39.972 mm (1.5729-1.5737 in)

- d. If out of specification, replace the piston and piston rings as a set.
- e. Calculate the piston-to-cylinder clearance with the following formula.  
Piston-to-cylinder clearance =  
Cylinder bore "C" - Piston skirt diameter "D"




#### Piston-to-cylinder clearance

0.034-0.047 mm (0.0013-0.0019 in)

#### Limit

0.10 mm (0.0039 in)

- f. If out of specification, replace the cylinder, and replace the piston and piston rings as set.



### CHECKING THE PISTON RINGS

#### 1. Measure:

- Piston ring side clearance  
Out of specification → Replace the piston and piston rings as a set.

#### NOTE:

Before measuring the piston ring side clearance, eliminate any carbon deposits from the piston ring grooves and piston rings.




#### Piston ring side clearance

##### Ring side clearance

0.020-0.060 mm (0.0008-0.0024 in)

##### Limit

0.080 mm (0.0032 in)



## 2. Measure:

- Piston ring end gap

Out of specification → Replace the piston ring and cylinder as a set.

**Piston ring end gap**

**0.15-0.35 mm (0.0059-0.0138 in)**

**Limit**

**0.50 mm (0.0197 in)**




- Install a piston ring into the cylinder.

**NOTE:**

Level the piston ring into the cylinder with the piston crown.

- 40 mm (1.57 in)

**CHECKING THE PISTON PIN AND SMALL END BEARINGS**

## 1. Check:

- Piston pin

Blue discoloration/grooves → Replace the piston pin.

## 2. Check:


- Connecting rod small end bearing

Blue discoloration/grooves → Replace.

## 3. Measure:

- Piston pin outside diameter ①


Out of specification → Replace the piston pin and small end bearing as a set.

**Piston pin outside diameter**

**9.994-10.000 mm (0.3935-0.3937 in)**

**Limit**

**9.974 mm (0.3927 in)**



## 4. Measure:

- Piston pin bore diameter (b)

Out of specification → Replace the piston, piston pin and small end bearing as a set.

**Piston pin bore inside diameter**

10.004-10.015 mm (0.3939-0.3943 in)

**Limit**

10.035 mm (0.3951 in)

## 5. Calculate:

- Piston-pin-to-piston-pin-bore clearance

Out of specification → Replace the piston and piston pin as a set.

Piston-pin-to-piston-pin-bore clearance


=Piston pin bore diameter (b)-Piston pin outside diameter (a)

**Piston-pin-to-piston-pin-bore clearance**

0.004-0.021 mm (0.0002-0.0008 in)

**Limit**

0.061 mm (0.0024 in)

**INSTALLING THE PISTON RING AND PISTON**


## 1. Lubricate:

- Connecting rod big end bearing
- Connecting rod small end bearing (with the recommended lubricant)



**Recommended lubricant**  
**Engine oil**






## 2. Install:

- Top ring ①
- 2nd ring ②  
(with expander ring ③)

**NOTE:**

- Be sure to install the top ring and 2nd ring so that the manufacturer's marks or numbers face up.
- Align the piston ring gap with the pin ④.
- After installing the piston ring, check the smooth movement of it.



## 3. Install:

- Piston ①
- Piston pin
- Piston pin clips ② **New**

**NOTE:**

- Apply engine oil the piston pin.
- Make sure the arrow mark (a) on the piston points towards the exhaust side of the cylinder.
- Before installing the piston pin clip, cover the crankcase opening with a clean rag to prevent the clip from falling into the crankcase.

**INSTALLING THE CYLINDER AND CYLINDER HEAD**

## 1. Install:



- Gasket **New**

## 2. Lubricate:

- Piston
- Piston rings
- Cylinder wall  
(with the recommended lubricant)



**Recommended lubricant**  
**Engine oil**




3. Install:
- Cylinder ①

**NOTE:**

While compressing the piston rings with one hand, install the cylinder with the other hand.

- Gasket **New**
- Cylinder head

4. Tighten:
- Cylinder head nut


 **10 Nm (1.0 m•kg, 7.2 ft•lb)**

**NOTE:**


Tighten the cylinder head nut 2 stages and in a crisscross pattern.

5. Install:
- Spark plug

6. Tighten:
- Spark plug


 **20 Nm (2.0 m•kg, 14 ft•lb)**

7. Install:
- Spark plug cap
  - Exhaust chamber assembly

 **9 Nm (0.9 m•kg, 6.5 ft•lb)**



## REED VALVE




Order	Job/Part	Q'ty	Remarks
	<b>Removing the reed valve</b>		
	Side cover		Remove the parts in the order listed. Refer to "SIDE COVERS, SEAT AND FUEL TANK" in chapter 3.
	Engine		Refer to "ENGINE REMOVAL".
1	Intake manifold	1	
2	Upper valve seat gasket	1	
3	Reed valve assembly	1	
4	Lower valve seat gasket	1	
			For installation, reverse the removal procedure.




## REMOVING THE REED VALVE

1. Remove:
  - Air filter case assembly
  - Carburetor assembly
 Refer to "REMOVING THE ENGINE"
2. Remove:
  - Intake manifold
  - Upper valve seat gasket
  - Reed valve assembly
  - Lower valve seat gasket



## CHECKING THE REED VALVE

1. Check:
  - Reed valve assembly
 Cracks/damage → Replace the reed valve assembly.



2. Check:
  - Reed valve bending (a)
 Out of specification → Replace the reed valve.



**Reed valve bending limit**  
0.2 mm (0.01 in)

3. Check:
  - Valve stopper height (b)
 Out of specification → Replace the reed valve stopper.




**Reed valve stopper height**  
4.6-5.0 mm (0.18-0.20 in)  
**Limit**  
7.4-7.8 mm (0.291-0.307 in)



## ASSEMBLING AND INSTALLING THE REED VALVE

### 1. Install:

- Reed valve
- Reed valve stopper



### 2. Install:


- Lower valve seat gasket **New** ①
- Reed valve assembly ②
- Upper valve seat gasket **New** ③
- Intake manifold

### 3. Install:


- Carburetor assembly
  - Air filter case assembly
- Refer to "INSTALLING THE ENGINE"



## CLUTCH



Order	Job/Part	Q'ty	Remarks
	<b>Removing the clutch</b>		
	Side cover		Remove the parts in the order listed. Refer to "SIDE COVERS, SEAT AND FUEL TANK" in chapter 3.
	Engine		Refer to "ENGINE REMOVAL".
1	Crankcase cover protector	1	
2	Right crankcase cover	1	
3	Gasket	1	
4	Dowel pin	2	
5	Circlip	1	
6	Clutch housing	1	
7	Primary drive gear nut/washer	1/1	
8	Clutch carrier assembly	1	
9	Spacer	1	
10	Primary drive gear	1	
11	Absorber (large)/absorber (small)	1/1	




Order	Job/Part	Q'ty	Remarks
12	Straight key	1	For installation, reverse the removal procedure.
13	Thrust plate	1	
14	Collar	1	




## REMOVING THE CLUTCH


1. Remove:
  - Engine.  
Refer to "REMOVING THE ENGINE".
2. Drain:
  - Transmission oil  
(from the crankcase)  
Refer to "CHANGING THE TRANSMISSION OIL" in chapter 3.



3. Remove:
  - Crankcase cover protector ①
  - Right crankcase cover ②
  - Gasket
  - Dowel pin



4. Remove:
  - Circlip ①
  - Clutch housing ②




5. Remove:
  - Primary drive gear nut ①
  - Washer
  - Clutch carrier assembly

**NOTE:** \_\_\_\_\_  
Place an aluminum plate (a) between the teeth of the primary drive gear ② and driven gear ③.  
\_\_\_\_\_

6. Remove:
  - Primary drive gear






### CHECKING THE PRIMARY DRIVE GEAR

#### 1. Check:


- Primary drive gear ①  
Damage/wear → Replace the primary drive and clutch carrier assembly.  
Excessive noise during operation → Replace the primary drive and clutch carrier assembly as a set.



### CHECKING THE PRIMARY DRIVEN GEAR

#### 1. Check:


- Primary driven gear  
Damage/wear → Replace the primary drive and clutch carrier assembly as a set.  
Excessive noise during operation → Replace the primary drive and clutch carrier assembly as a set.



### CHECKING THE CLUTCH HOUSING

#### 1. Check:

- Clutch housing  
Damage/wear → Replace the clutch housing.



#### 2. Measure:

- Clutch housing inside diameter  
Out of specification → Replace the clutch housing.



**Clutch housing inside diameter**

**105 mm (4.13 in)**

**Limit**

**106 mm (4.17 in)**

### CHECKING THE CLUTCH SHOES


The following procedure applies to all of the clutch shoes.

#### 1. Check:

- Clutch shoe  
Damage/wear → Replace the clutch shoes and springs as a set.  
Glazed areas → Sand with course sandpaper.

#### NOTE:

- After sanding the glazed areas, clean the clutch with a cloth.
- Do not apply the grease or oil on the clutch shoes.



## 2. Measure:

- Clutch shoe thickness


Out of specification → Replace the clutch shoes and springs as a set.

**Clutch shoe thickness**

**1.0 mm (0.04 in)**

**Wear limit**

**0.7 mm (0.03 in)**



## 3. Measure:

- Clutch shoe spring free length


Out of specification → Replace the clutch shoes and springs as a set.

**Clutch shoe spring free length**

**34.5 mm (1.36 in)**

**Wear limit**

**35.5 mm (1.40 in)**


**INSTALLING THE CLUTCH**

## 1. Install:

- Absorber (large) ①
- Absorber (small) ②

**NOTE:**

Install the absorber (large) to “L” side (a) and install the absorber (small) to “S” side (b).



## 2. Install:

- Primary drive gear
- Clutch carrier assembly
- Clutch housing
- Circlip **New**  
(to the clutch carrier assembly)

## 3. Tighten:

- Primary drive gear nut ①


**30 Nm (3.0 m•kg, 22 ft•lb)**

**NOTE:**

Place an aluminum plate (a) between the teeth of the primary drive gear (2) and driven gear (3).


## 4. Install:

- Dowel pin
- Gasket **New**




## 5. Install:

- Right crank case cover ①

 **8 Nm (0.8 m•kg, 5.8 ft•lb)**

- Crankcase cover protector ②

 **9 Nm (0.9 m•kg, 6.5 ft•lb)**


## 6. Fill:

- Transmission oil


Refer to “CHANGING THE TRANSMISSION OIL” in chapter 3.




## AUTOLUBE PUMP




Order	Job/Part	Q'ty	Remarks
	<b>Removing the autolube pump</b>		
	Muffler/exhaust chamber assembly		Remove the parts in the order listed.
1	Autolube pump cover (outer)	1	Refer to "ENGINE REMOVAL".
2	Oil delivery hose	1	
3	Autolube pump cable	1	
4	Oil hose	1	Be sure cap the oil hose by proper bolt to prevent the engine oil to spilt out.
5	Autolube pump assembly	1	
6	Autolube pump cover (inner)	1	
7	Circlip	1	
8	Worm wheel gear	1	
9	O-ring	1	
10	Oil seal	1	
11	Adjusting bolt	1	
12	Locknut	1	
			For installation, reverse the removal procedure.

**REMOVING THE AUTOLUBE PUMP****1. Remove:**

- Muffler assembly
- Exhaust chamber assembly  
Refer to "ENGINE REMOVAL".
- Autolube pump cover (outer) ①

**2. Remove:**

- Autolube pump assembly ①  
(with autolube pump cover (inner) ②)

**3. Remove:**


- Oil pump cable ①
- Oil delivery hose ②  
(disconnect the autolube pump side)

**4. Disconnect:**

- Oil hose ③  
(disconnect the autolube pump side)

**CAUTION:**


**Whenever disconnect the oil hose, be sure cap the oil hose by proper bolt to prevent the engine oil to spilt out.**



## DISASSEMBLING THE AUTOLUBE PUMP

1. Remove:

- Circlip ①
- Worm wheel gear ②
- Pin ③
- O-ring ④
- Oil seal ⑤




## CHECKING THE AUTOLUBE PUMP

1. Check:

- Autolube pump  
Damage/cracks → Replace the autolube pump assembly.


2. Check:

- Worm wheel gear  
Worn/damage → Replace the oil pump drive gear.




3. Check:

- Autolube pump cover  
Damage/cracks → Replace the autolube pump cover.

**ASSEMBLING THE AUTOLUBE PUMP**

## 1. Install:


- Oil seal ① **New**
- O-ring ② **New**
- Pin ③
- Worm wheel gear ④
- Circlip ⑤ **New**

**INSTALLING THE AUTOLUBE PUMP**

## 1. Install:

- Autolube pump assembly ①  
(with autolube pump cover (inner) ②)

**4 Nm (0.4 m•kg, 2.9 ft•lb)**




## 2. Connect:

- Oil hose ①

## 3. Install:

- Oil pump cable ②
- Oil delivery hose ③



## 4. Install:

- Autolube pump cover (outer) ①

**4 Nm (0.4 m•kg, 2.9 ft•lb)**

## 5. Install:


- Air cleaner case

**NOTE:**

Whenever autolube pump disassembly and reassembly be sure to air bleed and pump stroke the autolube pump. Refer to "AIR BLEEDING THE AUTOLUBE PUMP" and "ADJUSTING THE AUTOLUBE PUMP MINIMUM STROKE" in chapter 3.





## KICK STARTER



Order	Job/Part	Q'ty	Remarks
	<b>Removing the kick starter</b>		
	Side cover		Remove the parts in the order listed. Refer to "SIDE COVERS, SEAT AND FUEL TANK" in chapter 3.
	Engine		Refer to "ENGINE REMOVAL".
	Clutch		Refer to "CLUTCH".
1	Kick crank/bolt	1/1	
2	Pump drive gear	1	
3	Torsion spring	1	
4	Spring guide	1	
5	Kick shaft	1	
6	Kick pinion gear/clip	1/1	
7	Oil seal	1	For installation, reverse the removal procedure.





**REMOVING THE KICK STARTER**

1. Remove
  - Engine  
Refer to "REMOVING THE ENGINE".
2. Remove:
  - Clutch assembly.  
Refer to "REMOVING THE CLUTCH".
3. Remove:
  - Oil pump drive gear
4. Remove:
  - Kick crank ①
5. Remove:
  - Torsion spring ①
  - Spring guide ②
  - Kick shaft ③

**NOTE:**

Unhook the torsion spring ① from the stopper ① in the crankcase.


6. Remove:
  - Kick pinion gear
  - Clip

**CHECKING THE KICK STARTER**


1. Check:
  - Kick shaft ①  
Bend/damage → Replace the kick shaft.
  - Kick gear tooth
  - Kick pinion gear tooth  
Worn/crack → Replace the kick shaft or kick pinion gear
2. Measure:
  - Kick gear clip friction force  
Out of specification → Replace the kick gear clip.  
Use a spring gauge ①.



**Kick gear clip friction force**  
1-5 N (0.34-1.33 lbf) (0.15-0.40 kgf)

**INSTALLING THE KICK STARTER****1. Install:**

- Clip ①
- Kick pinion gear ②
- Kick shaft ③

**2. Install:**

- Torsion spring ①
- Spring guide ②

**NOTE:**


Turn the torsion spring clockwise and hook onto the stopper (a) in the crankcase.

**3. Install:**

- Oil pump drive gear ③

**NOTE:**

Align the oil pump drive gear tooth with oil pump drive gear tooth, and then install it.

**4. Install:**

- Kick crank ①

**5. Tighten:**

- Kick crank bolt

10 Nm (1.0 m·kg, 7.2 ft·lb)

**6. Install:**


- Clutch assembly  
Refer to "INSTALLING THE CLUTCH"

**7. Install:**


- Engine  
Refer to "INSTALLING THE ENGINE"



CDI MAGNETO




Order	Job/Part	Q'ty	Remarks
	<b>Removing the CDI magneto</b>		
	Side cover		Remove the parts in the order listed. Refer to "SIDE COVERS, SEAT AND FUEL TANK" in chapter 3.
1	Magneto cover	1	
2	Rotor nut	1	
3	Spring washer	1	
4	Washer	1	
5	CDI magneto rotor	1	
6	Woodruff key	1	
7	CDI magneto coupler/connecter	1/2	
8	Stator assembly	1	
			For installation, reverse the removal procedure.



## REMOVING THE CDI MAGNETO


1. Remove:
  - Magneto cover ①



2. Loosen:
  - Rotor nut ①
 Use with the rotor holding tool ②.




**Rotor holding tool**  
90890-01235, YU-01235




3. Remove:
  - Rotor nut
  - Spring washer
  - Washer
  - CDI magneto rotor ①
 Use with the flywheel puller ②.
  - Woodruff key



**Flywheel puller**  
90890-01189, YU-01189



4. Disconnect:
  - CDI magneto lead coupler/connector ①



5. Remove:
  - Stator assembly ①



## CHECKING THE CDI MAGNETO

### 1. Check:

- Magneto rotor inner surface
- Stator outer surface

Damage → Check the crankshaft runout and crankshaft bearing.

If necessary, replace CDI magneto and/or stator.

### 2. Check:

- Woodruff key

Damage → Replace the woodruff key.


## INSTALLING THE CDI MAGNETO



### 1. Install:

- Stator assembly

### 2. Tighten:

- Stator assembly screw

 **9 Nm (0.9 m·kg, 6.5 ft·lb)**



### 3. Install:


- Woodruff key ①  
(to install the crankshaft key way)

### 4. Install:

- CDI magneto rotor ①
- Washer ②
- Spring washer ③
- Rotor nut ④

### NOTE:

- Clean the tapered portion of the crankshaft and the CDI magneto rotor.
- When installing the CDI magneto rotor, make sure the woodruff key is properly seated in the keyway of the crankshaft.



5. Tighten:

- Rotor nut ①

Use the rotor holding tool ②

**43 Nm (4.3 m·kg, 31 ft·lb)**

## NOTE:

While holding the CDI magneto rotor with the rotor holding tool, tighten the rotor nut.



**Rotor holding tool**

**90890-01235, YU-01235**

6. Install:

- Magneto cover


**4 Nm (0.4 m·kg, 2.9 ft·lb)**

7. Connect:


- CDI magneto coupler/connecter



## CRANKCASE AND CRANKSHAFT




Order	Job/Part	Q'ty	Remarks
	<b>Separating the crankcase and removing the crankshaft</b>		Remove the parts in the order listed.
	Side cover		Refer to "SIDE COVERS, SEAT AND FUEL TANK" in chapter 3.
	Engine		Refer to "ENGINE REMOVAL".
	Cylinder head/cylinder/piston		Refer to "CYLINDER HEAD, CYLINDER AND PISTON".
	Reed valve		Refer to "REED VALVE".
	Clutch		Refer to "CLUTCH".
	Kick starter		Refer to "KICK STARTER".
	CDI magneto		Refer to "CDI magneto".
	Shaft drive		Refer to "SHAFT DRIVE" in chapter 4.
	Middle gear		Refer to "MIDDLE GEAR".
1	Mainstand assembly	1	
2	Crankcase (left)	1	
3	Dowel pin	2	



Order	Job/Part	Q'ty	Remarks
4	Crankshaft assembly	1	For installation, reverse the removal procedure.
5	Crankcase (right)	1	
6	Bearing	2	
7	Oil seal	2	






### REMOVING THE CRANKCASE

1. Remove:
  - Crankcase screw

#### NOTE:

Loosen each screw 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the screw are fully loosened, remove them.



2. Separate:

- Crankcase (left)
- Use the bolts (M8×1.25, length 95 mm (3.74 in)) ① and a flywheel puller ②.



**Flywheel puller**

**90890-01362, YU-33270**

② 95 mm (3.74 in)

#### NOTE:


- Fully tighten the tool holding bolts, but make sure the tool body is parallel with the case. If necessary, one screw may be backed out slightly to level tool body.
- As pressure is applied, alternately tap on the front engine mounting boss and transmission shafts.

3. Remove:

- Crankshaft

### CHECKING THE CRANKCASE

1. Thoroughly wash the crankcase halves in a mild solvent.
2. Thoroughly clean all the gasket surfaces and crankcase mating surfaces.




### 3. Check:

- Crankcase (left) ①
  - Crankcase (right) ②
- Cracks/damage → Replace the crankcase.

### 4. Check:

- Bearing
- Unsmooth operation → Replace the bearing.




## CHECKING THE CRANKSHAFT


### 1. Measure:

- Runout ①
  - Small end free play ②
  - Connecting rod big end side clearance ③
  - Crank width ④
- Out of specification → Replace the crankshaft assembly.


Use the dial gauge and thickness gauge.




**Dial gauge and stand**  
**90890-01252**



**Runout**  
**0.050 mm (0.0020 in)**  
**Small end free play**  
**0.40-0.80 mm (0.02-0.03 in)**  
**Connecting rod big end side clearance**  
**0.350-0.550 mm**  
**(0.0138-0.0217 in)**  
**Crank width**  
**37.90-37.95 mm (1.492-1.494 in)**





### INSTALLING THE CRANKSHAFT

1. Install:

- Crankshaft ①

Use the crank installing tools ②, ③, ④.



**Crankshaft installing pot ②**

90890-01274, YU-90058

**Crankshaft installing bolt ③**

90890-01275, YU-90060

**Adapter (M12) ④**


90890-001278, YU-090063

### NOTE:

- Hold the connecting rod at top dead center with one hand while turning the nut of the installing tool with the other. Operate the installing tool until the crankshaft bottoms against the bearing.
- Before installing the crankshaft, clean the contacting surface of crankcase.
- Apply the lithium soap base grease on the oil seal lip.

### CAUTION:

**Do not use a hammer to drive in the crankshaft.**



2. Apply:

- Yamaha bond No. 1215 (Three Bond No. 1215®) ①  
(to the mating surfaces of both case halves)



**Yamaha bond No. 1215  
(Three Bond No. 1215®)**

90890-85505

### NOTE:


Clean the contacting surface of left and right crankcase before applying the sealant.




3. Install:
  - Dowel pin
  - Right crankcaseTo the left crankcase.

**NOTE:**

- Fit the right crankcase onto the left crankcase. Tap lightly on the case with soft hammer.
- When installing the crankcase, the connecting rod should be positioned at TDC (top dead center).



4. Tighten
  - Screw (crankcase)

 **8 Nm (0.8 m•kg, 5.8 ft•lb)**


**NOTE:**

Tighten the crankcase tightening screws in stage, using a crisscross pattern.


5. Remove:
  - SealantForced out on the cylinder mating surface.
6. Apply:
  - Engine oilTo the crank pin, bearing and connecting rod end washer.
7. Check:
  - Crankshaft and transmission operationUnsmooth operation → Repair.




## MIDDLE GEAR



Order	Job/Part	Q'ty	Remarks
	<b>Removing the middle gear</b>		
	Engine		Remove the parts in the order listed.
	Clutch		Refer to "ENGINE REMOVAL".
	Kick starter		Refer to "CLUTCH".
	Rear wheel		Refer to "KICK STARTER".
	Shaft drive		Refer to "FRONT WHEEL, REAR WHEEL AND BRAKE" in chapter 4.
1	Oil seal	1	Refer to "SHAFT DRIVE" in chapter 4.
2	Screw	1	
3	Distance collar	1	
4	Bearing	1	
5	Driven pinion	1	
6	Thrust shim	1	
7	Bearing retainer	1	



Order	Job/Part	Q'ty	Remarks
8	Main axle assembly	1	For installation, reverse the removal procedure.
9	Pinion shim	1	



### REMOVING THE MIDDLE DRIVE SHAFT ASSEMBLY

1. Remove:

- Oil seal
- Screw ①

Attach the hexagonal wrench ②.




**Hexagon wrench**

**90890-01306, YM-01306**


**NOTE:**

Loosen the screw clockwise.



2. Remove:

- Distance collar ①
- Bearing ②
- Driven pinion ③
- Thrust shim ④



### CHECKING THE MIDDLE GEAR

1. Check:


- Main axle ①
- Galling/pitting/wear → Replace.

2. Check:

- Driven pinion ②
- Galling/pitting/wear → Replace.

3. Check:


- Bearing
- Damage/pitting → Replace.



### INSTALLING THE MIDDLE GEAR


1. Install:

- Thrust shim ①
- Driven pinion ②
- Bearing ③
- Distance collar ④



## 2. Install:

- Screw ①  
Attach the hexagon wrench ②.

 60 Nm (6.0 m•kg, 43 ft•lb)



**Hexagon wrench**  
**90890-01306, YM-01306**

**NOTE:** \_\_\_\_\_

Tighten the screw counterclockwise.

## 3. Install:

- Oil seal **New**



---

CHAPTER 6  
CARBURETOR

CARBURETOR .....

REMOVING THE CARBURETOR .....

DISASSEMBLING THE CARBURETOR.....

CHECKING THE CARBURETOR .....

ASSEMBLING THE CARBURETOR.....

INSTALLING THE CARBURETOR .....

6-1

6-3

6-4

6-4


6-6

6-8




## CARBURETOR


## CARBURETOR



Order	Job/Part	Q'ty	Remarks
	<b>Removing the carburetor</b>		
	Side cover		Remove the parts in the order listed. Refer to "SIDE COVERS, SEAT AND FUEL TANK" in chapter 3.
1	Air filter assembly	1	
2	Fuel hose	1	Set the fuel cock to "S".
3	Oil delivery hose	1	
4	Mixing chamber top	1	
5	Carburetor clamp screw	1	Loosen.
6	Carburetor assembly	1	
7	Throttle valve/needle set	1/1	
8	Throttle spring	1	
9	Starter plunger	1	
10	Plunger spring	1	
			For installation, reverse the removal procedure.




Order	Job/Part	Q'ty	Remarks
	<b>Disassembling the carburetor</b>		Disassemble the parts in the order listed.
①	Throttle stop screw set	1	
②	Float chamber body	1	
③	Float chamber gasket	1	
④	Float pin	1	
⑤	Float	1	
⑥	Needle valve	1	
⑦	Main jet	1	
⑧	Main nozzle	1	
⑨	Pilot jet	1	
			For assembly, reverse the disassembly procedure.




## REMOVING THE CARBURETOR


1. Remove:
  - Side cover
  - Seat
  - Clip
  - Air filter assembly ①



2. Remove:
  - Oil delivery hose ①
  - Fuel hose ②




3. Remove:
  - Mixing chamber top ①
4. Loosen:
  - Carburetor clamp screw ②
5. Remove:
  - Carburetor assembly ③



6. Remove:
  - Throttle valve ①
  - Needle set ②
  - Throttle spring ③
  - Starter plunger ④
  - Plunger spring ⑤


**DISASSEMBLING THE CARBURETOR**

1. Loosen the drain plug, and then drain the fuel from float chamber body.




2. Remove:
  - Throttle stop screw set ①

3. Remove:
  - Float chamber body
  - Float chamber gasket




4. Remove:
  - Float pin ①
  - Float ②
  - Needle valve assembly ③



5. Remove:
  - Main jet ①
  - Main nozzle ②
  - Pilot jet ③

**CHECKING THE CARBURETOR**


1. Check:
  - Carburetor bodyCracks/damage → Replace.




2. Check:
  - Fuel passages  
Obstruction → Clean.




- a. Wash the carburetor in a petroleum-based solvent. Do not use any caustic carburetor cleaning solution.
- b. Blow out all of the passages and jets with compressed air.




3. Check:
  - Float chamber body  
Dirt → Clean.




4. Check:
  - Float  
Damage → Replace.



5. Check:
  - Needle valve
  - Needle valve seat  
Damage/obstruction/wear → Replace the needle valve, needle valve seat and O-ring as a set.



6. Check:
  - Throttle valve  
Damage/scratches/wear → Replace.



## 7. Check:

- Main jet ①
- Main nozzle ②
- Pilot jet ③

Blow out the jets with compressed air.

## 8. Check:

- Throttle valve movement

Insert the throttle valve into the carburetor body and move it up and down.

Tightness → Replace the throttle valve.

## 9. Check:

- Starter plunger
- Starter plunger spring

Bends/cracks/damage → Replace.

## 10. Check:

- Fuel hose
- Oil delivery hose


Cracks/damage/wear → Replace.

Obstruction → Clean.

Blow out the hoses with compressed air.



**ASSEMBLING THE CARBURETOR****CAUTION:**

Before assembling the carburetor, wash all of the parts in a petroleum-based solvent. Always use a new gasket.



## 1. Install:

- Pilot jet ①
- Main nozzle ②
- Main jet ③



2. Install:
- Needle valve ①
  - Float ②
  - Float pin ③

**NOTE:**

Install the float pin as shown.

3. Measure:
- Float height (a)  
Out of specification → Replace the needle valve and the float



### Float height



**15.5-17.5 mm (0.61-0.69 in)**

- Hold the carburetor in an upside down position.
- Measure the distance between the mating surface of the float chamber and top of the float using a vernier calipers.

**NOTE:**

The float arm should be resting on the needle valve, but not compressing the needle valve.


- c. If the float height is not within specification, replace the needle valve and float.



4. Install:
- Float chamber gasket ① **New**
  - Float chamber ②


5. Install:
- Throttle screw set ①





## 6. Install:

- Throttle valve spring ①
- Needle set ②
- Throttle valve ③
- Plunger spring ④
- Starter plunger ⑤



## 7. Install:

- Gasket **New** ①
- Mixing chamber top ②

**NOTE:**

Align the slot on the throttle valve with projection of the mixing chamber top, and then install them.


**INSTALLING THE CARBURETOR**

## 1. Adjust:

- Engine idling speed  
Refer to "ADJUSTING THE ENGINE IDLING SPEED" in chapter 3.

## 2. Adjust:


- Throttle cable free play  
Refer to "ADJUSTING THE THROTTLE CABLE FREE PLAY" in chapter 3.



## **CHAPTER 7**

### **ELECTRICAL SYSTEM**

<b>ELECTRICAL COMPONENTS .....</b>	<b>7-1</b>
<b>CHECKING SWITCH CONTINUITY .....</b>	<b>7-2</b>
<b>CHECKING THE SWITCHES .....</b>	<b>7-3</b>
<b>IGNITION SYSTEM .....</b>	<b>7-4</b>
CIRCUIT DIAGRAM .....	7-4
TROUBLESHOOTING .....	7-5



## ELECTRICAL SYSTEM

### ELECTRICAL COMPONENTS

① Ignition control switch


② Diode




③ Control unit

④ CDI unit

⑤ Ignition coil

⑥ Stator assembly





## CHECKING SWITCH CONTINUITY

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, check the wiring connections and if necessary, replace the switch.

### CAUTION:

Never insert the tester probes into the coupler terminal slots ①. Always insert the probes from the opposite end of the coupler, taking care not to loosen or damage the leads.



Pocket tester  
90890-03112

### NOTE:

- Before checking for continuity, set the pocket tester to "0" and to the " $\Omega \times 1$ " range.
- When checking for continuity, switch back and forth between the switch positions a few times.

The terminal connections for switches (e.g., main switch, engine stop switch) are shown in an illustration similar to the one on the left.


The switch positions ① are shown in the far left column and the switch lead colors ② are shown in the top row in the switch illustration.

### NOTE:

"○ — ○" indicates a continuity of electricity between switch terminals (i.e., a closed circuit at the respective switch position).

The example illustration on the left shows that:

There is continuity between red and brown when the switch is set to "ON".




## CHECKING THE SWITCHES

Check each switch for damage or wear, proper connections, and also for continuity between the terminals. Refer to “CHECKING SWITCH CONTINUITY”.


Damage/wear → Repair or replace.

Improperly connected → Properly connect.


Incorrect continuity reading → Replace the switch.



① Ignition control switch



# IGNITION SYSTEM CIRCUIT DIAGRAM



## COLOR CODE

B.....	Black	W/R.....	White/ Red
O.....	Orange	Y/W.....	Yellow/ White
R.....	Red		
W.....	White		
W/B.....	White/ Black		
B/Y.....	Black/ Yellow		
B/R.....	Black/ Red		

① Ignition control switch

② Diode

③ Control unit


④ C. D. I. magneto

⑤ C. D. I. unit

⑥ Ignition coil

⑦ Spark plug

⑧ Ground



### TROUBLESHOOTING

**The ignition system fails to operate (no spark or intermittent spark).**

Check:

1. Spark plug
2. Ignition spark gap
3. Spark plug cap resistance
4. Ignition coil resistance
5. Pickup coil resistance
6. Charge coil resistance
7. Lighting coil resistance
8. Ignition control switch
9. Control unit
10. Wiring connections (of the entire ignition system)

#### NOTE:

- Before troubleshooting, remove the following part(s):
  1. Seat
  2. Front fender
- Troubleshoot with the following special tool(s).



**Ignition checker**  
90890-06754, YM-06754  
**Pocket tester**  
90890-03112, YM-03112

#### 1. Spark plug

- Check the condition of the spark plug.
- Check the spark plug type.
- Measure the spark plug gap.  
Refer to "CHECKING THE SPARK PLUG" in chapter 3.



**Standard spark plug**  
**NGK/BP4HS or DENSO/W14FPL**  
(Except for CANADA and EUROPE)  
**NGK/BPR4HS**  
(For CANADA and EUROPE)  
**Spark plug gap**  
**0.6–0.7 mm (0.024–0.028 in)**

- Is the spark plug in good condition, is it of the correct type, and is its gap within specification?



YES




NO

Re-gap or replace the spark plug.

#### 2. Ignition spark gap

- Disconnect the spark plug cap from the spark plug.
- Connect the ignition checker ① as shown.
- ② Spark plug cap
- Set the main switch to "ON".
- Crank the engine by pushing the start switch and gradually increase the spark gap until a misfire occurs.
- Measure the ignition spark gap ③.



**Minimum ignition spark gap**  
**6.0 mm (0.24 in)**

- Is there a spark and is the spark gap within specification?




NO




YES

The ignition system is OK.



### 3. Spark plug cap resistance

- Remove the spark plug cap from the spark plug lead.
- Connect the pocket tester ( $\Omega \times 1k$  range) to the spark plug cap as shown.
- Measure the spark plug cap resistance.



**Spark plug cap resistance**  
**5.0 k $\Omega$  at 20°C (68°F)**

- Is the spark plug cap OK?



YES



NO

Replace the spark plug cap.


### 4. Ignition coil resistance

- Disconnect the ignition coil connector from the ignition coil terminal.
- Connect the pocket tester ( $\Omega \times 1$  range) to the ignition coil as shown.

**Positive tester probe → terminal ①**

**Negative tester probe →**

**ignition coil base ②**



- Measure the primary coil resistance.




**Primary coil resistance**  
**0.32–0.48  $\Omega$  at 20°C (68°F)**

- Connect the pocket tester ( $\Omega \times 1k$  range) to the ignition coil as shown.

**Negative tester probe → terminal ①**

**Positive tester probe →**

**spark plug lead ②**



- Measure the secondary coil resistance.



**Secondary coil resistance**  
**5.68–8.52 k $\Omega$  at 20°C (68°F)**

- Is the ignition coil OK?




YES



NO

Replace the ignition coil.






5. Pickup coil resistance

- Disconnect the pickup coil coupler from the wire harness.
- Connect the pocket tester ( $\Omega \times 1$  range) to the pickup coil terminal as shown.

**Positive tester probe  $\rightarrow$  white/red ①**

**Negative tester probe  $\rightarrow$  black ②**



- Measure the pickup coil resistance.



**Pickup coil resistance**

**18.0–22.0  $\Omega$  at 20°C (68°F)**

**(between white/red and black)**

- Is the pickup coil OK?

**YES**

**NO**


Replace the stator  
coil/pickup coil  
assembly.

6. Charge coil resistance

- Disconnect the charge coil coupler from the wire harness.
- Connect the pocket tester ( $\Omega \times 100$  range) to the charge coil terminal as shown.

**Positive tester probe  $\rightarrow$  black/red ①**

**Negative tester probe  $\rightarrow$  black ②**



- Measure the charge coil resistance.



**Charge coil resistance**

**297–363  $\Omega$  at 20°C (68°F)**


**(between black/red and black)**

- Is the charge coil OK?

**YES**

**NO**

Replace the stator  
coil assembly.




### 7. Lighting coil resistance

- Disconnect the lighting coil coupler from the wire harness.
- Connect the pocket tester ( $\Omega \times 1$  range) to the lighting coil terminal as shown.

**Positive tester probe → white ①**

**Negative tester probe → black ②**



- Measure the charge coil resistance.



**Lighting coil resistance**  
**0.57–0.69  $\Omega$  at 20°C (68°F)**  
**(between white and black)**

- Is the lighting coil OK?

YES

NO

Replace the stator coil assembly.

### 8. Ignition control switch

- Check the ignition control switch for continuity. Refer to “CHECKING THE SWITCHES”.
- Is the ignition control switch OK?

YES

NO


Replace the ignition control switch.

### 9. Control unit resistance

- Disconnect the control unit ① coupler from the wire harness.
- Connect the pocket tester ( $\Omega \times 1k$  range) to the control unit terminal as shown.

**Positive tester probe ②**

**Negative tester probe ③**



- Measure the control unit resistance.



**Control unit resistance**


	Tester negative lead					Range
	B/R	W/R	W/B	B/Y	B	
Tester positive lead	B/R	100 – 200 k $\Omega$	80 – 200 k $\Omega$	80 – 200 k $\Omega$	80 – 200 k $\Omega$	$\times 1 \text{ k}\Omega$
	W/R	$\infty$	$\infty$	$\infty$	$\infty$	
	W/B	80 – 200 k $\Omega$	30 – 50 k $\Omega$	10 – 20 k $\Omega$	1 – 5 k $\Omega$	
	B/Y	80 – 200 k $\Omega$	30 – 80 k $\Omega$	10 – 20 k $\Omega$	10 – 20 k $\Omega$	
	B	80 – 200 k $\Omega$	20 – 50 k $\Omega$	1 – 5 k $\Omega$	7 – 15 k $\Omega$	

- Is the control unit OK?

YES

NO

Replace the control unit assembly.



## 10. Wiring

- Check the entire ignition system wiring. Refer to "CIRCUIT DIAGRAM".
- Is the ignition system wiring properly connected and without defects?



YES

Replace the C.D.I.  
unit.



NO

Properly connect  
or repair the igni-  
tion system wiring.

## CHAPTER 8

### TROUBLESHOOTING

<b>GENERAL INFORMATION .....</b>	<b>8-1</b>
<b>STARTING FAILURES .....</b>	<b>8-1</b>
ENGINE .....	8-1
FUEL SYSTEM .....	8-1
ELECTRICAL SYSTEM .....	8-2
<b>INCORRECT ENGINE IDLING SPEED .....</b>	<b>8-2</b>
ENGINE .....	8-2
FUEL SYSTEM .....	8-2
ELECTRICAL SYSTEM .....	8-2
<b>POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE .....</b>	<b>8-3</b>
ENGINE .....	8-3
FUEL SYSTEM .....	8-3
<b>FAULTY CLUTCH .....</b>	<b>8-3</b>
ENGINE OPERATES BUT VEHICLE WILL NOT MOVE .....	8-3
FUEL SYSTEM .....	8-3
ELECTRICAL SYSTEM .....	8-3
<b>OVERHEATING .....</b>	<b>8-3</b>
ENGINE .....	8-3
FUEL SYSTEM .....	8-3
CHASSIS .....	8-3
ELECTRICAL SYSTEM .....	8-3
<b>POOR BRAKING PERFORMANCE .....</b>	<b>8-4</b>
<b>FAULTY FRONT FORK LEGS .....</b>	<b>8-4</b>
<b>UNSTABLE HANDLING .....</b>	<b>8-4</b>

EAS28450

## TROUBLESHOOTING

EAS28460

### GENERAL INFORMATION

**NOTE:**

The following guide for troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to basic troubleshooting. Refer to the relative procedure in this manual for checks, adjustments, and replacement of parts.

EAS28470

### STARTING FAILURES

**ENGINE****Cylinder(s) and cylinder head(s)**

- Loose spark plug
- Loose cylinder head or cylinder
- Damaged cylinder head gasket
- Damaged cylinder gasket
- Worn or damaged cylinder

**Piston(s) and piston ring(s)**

- Improperly installed piston ring
- Damaged, worn or fatigued piston ring
- Seized piston ring
- Seized or damaged piston

**Air filter**

- Improperly installed air filter
- Clogged air filter element

**Crankcase and crankshaft**

- Improperly assembled crankcase
- Seized crankshaft

**Reed valve**

- Deformed reed valve stopper
- Improperly sealed reed valve stopper
- Incorrect tightened manifold
- Damaged gasket
- Damaged reed valve

**FUEL SYSTEM****Fuel tank**

- Empty fuel tank
- Deteriorated or contaminated fuel

**Fuel cock**

- Clogged or damaged fuel hose

**Carburetor(s)**

- Improperly adjusted throttle stop screw
- Deteriorated or contaminated fuel
- Clogged pilot jet
- Clogged pilot air passage
- Sucked-in air
- Damaged float
- Worn needle valve
- Improperly installed needle valve seat
- Incorrect fuel level
- Improperly installed pilot jet
- Clogged starter jet
- Faulty starter plunger
- Improperly adjusted starter cable

**ELECTRICAL SYSTEM**

**Spark plug(s)**

- Incorrect spark plug gap
- Incorrect spark plug heat range
- Fouled spark plug
- Worn or damaged electrode
- Worn or damaged insulator
- Faulty spark plug cap

**Ignition coil(s)**

- Cracked or broken ignition coil body
- Broken or shorted primary or secondary coils
- Faulty spark plug lead

**Ignition system**

- Faulty CDI unit
- Faulty pickup coil
- Faulty charge coil
- Faulty lighting coil
- Faulty control unit
- Faulty diode
- Broken generator rotor woodruff key

**Switches and wiring**

- Faulty ignition control switch
- Broken or shorted wiring
- Improperly grounded circuit
- Loose connections

EAS28490

**INCORRECT ENGINE IDLING SPEED**

**ENGINE**

**Air filter**

- Clogged air filter element

**FUEL SYSTEM**

**Carburetor(s)**

- Faulty starter plunger
- Loose or clogged pilot jet
- Loose or clogged pilot air jet
- Damaged or loose carburetor joint
- Improperly adjusted engine idling speed
- Improper throttle cable free play
- Flooded carburetor

**ELECTRICAL SYSTEM**

**Spark plug(s)**

- Incorrect spark plug gap
- Incorrect spark plug heat range
- Fouled spark plug
- Worn or damaged electrode
- Worn or damaged insulator
- Faulty spark plug cap

**Ignition coil(s)**

- Broken or shorted primary or secondary coils
- Faulty spark plug lead
- Cracked or broken ignition coil

**Ignition system**

- Faulty CDI unit
- Faulty pickup coil
- Faulty charge coil
- Faulty lighting coil
- Faulty control unit
- Faulty diode
- Broken generator rotor woodruff key

EAS28510

## **POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE**

Refer to “STARTING FAILURES”.

### **ENGINE**

#### **Autolube pump**

- Faulty autolube pump

#### **Air filter**

- Clogged air filter element

#### **Exhaust system**

- Carbon buildup

### **FUEL SYSTEM**

#### **Carburetor(s)**

- Incorrect fuel level
- Loose or clogged main jet

EAS28580

## **FAULTY CLUTCH**

### **ENGINE OPERATES BUT VEHICLE WILL NOT MOVE**

#### **Clutch spring(s)**

- Damaged clutch spring

#### **Transmission gear(s)**

- Damaged transmission gear

#### **Shaft drive**

- Broken shaft drive

### **CLUTCH SLIPS**

#### **Clutch shoe spring(s)**

- Damaged, loose or worn clutch shoe spring

#### **Clutch shoe(s)**

- Damaged or worn clutch shoe

### **POOR STARTING PERFORMANCE**

#### **Clutch shoe(s)**

- Bent, damaged or worn clutch shoe
- Poor speed performance

EAS28590

## **OVERHEATING**

### **ENGINE**

#### **Cylinder head(s) and piston(s)**

- Heavy carbon buildup

#### **Autolube pump**

- Faulty autolube pump
- Incorrect engine oil grade

### **FUEL SYSTEM**

#### **Carburetor(s)**

- Incorrect main jet setting
- Incorrect fuel level
- Damaged or loose carburetor joint

#### **Air filter**

- Clogged air filter element

### **CHASSIS**

#### **Brake(s)**

- Dragging brake

### **ELECTRICAL SYSTEM**

#### **Spark plug(s)**

- Incorrect spark plug gap
- Incorrect spark plug heat range

#### **Ignition system**

- Faulty CDI unit

EAS28630

## **POOR BRAKING PERFORMANCE**

- Worn brake shoe
- Worn or rusty brake drum
- Incorrect brake pedal position (above the top of the rider footrest)
- Incorrect brake lever free play
- Incorrect brake camshaft lever position
- Incorrect brake shoe position
- Damaged or fatigued brake shoe spring
- Oil or grease on the brake shoe
- Oil or grease on the brake drum

EAS28660

## **FAULTY FRONT FORK LEGS**

- Bent, damaged or rusty inner tube
- Cracked or damaged outer tube
- Damaged damper rubber
- Bent or damaged inner tube
- Bent or damaged outer tube
- Damaged fork spring
- Incorrect grease viscosity

EAS28670

## **UNSTABLE HANDLING**

### **Handlebar**

- Bent or improperly installed handlebar

### **Steering head components**

- Improperly installed upper bracket
- Improperly installed lower bracket (improperly tightened ring nut)

### **Bent steering stem**

- Damaged ball bearing or bearing race

### **Front fork leg(s)**

- Broken fork spring
- Bent or damaged inner tube
- Bent or damaged outer tube

### **Swingarm**

- Bent or damaged swingarm

### **Rear shock absorber assembly(-ies)**

- Faulty rear shock absorber spring
- Leaking oil

### **Tire(s)**

- Uneven tire pressures (front and rear)
- Incorrect tire pressure
- Uneven tire wear

### **Wheel(s)**

- Deformed panel wheel
- Damaged wheel bearing
- Bent or loose wheel axle
- Excessive wheel runout

### **Frame**

- Bent frame
- Damaged steering head pipe
- Improperly installed bearing race








PRINTED IN U.S.A.

PW50W WIRING DIAGRAM

- ① Safety switch
- ② Diode
- ③ Control unit
- ④ C. D. I. magneto
- ⑤ C. D. I. unit
- ⑥ Ignition coil
- ⑦ Spark plug
- ⑧ Ground



COLOR CODE

B.....Black  
O.....Orange  
R .....Red

W.....White  
W/ B .....White/ Black  
B/ Y .....Black/ Yellow

B/ R .....Black/ Red  
W/ R.....White/ Red  
Y/ W .....Yellow/ White

PW50W 2007 WIRING DIAGRAM

- ① Ignition control switch
- ② Diode
- ③ Control unit
- ④ C. D. I. magneto
- ⑤ C. D. I. unit
- ⑥ Ignition coil
- ⑦ Spark plug
- ⑧ Ground

