

VMX12N(C)

SERVICE MANUAL

LIT-11616-14-12

5GK-28197-E0

EAS00000

VMX12N(C) SERVICE MANUAL © 2000 by Yamaha Motor Corporation, U.S.A. First edition, June 2000 All rights reserved. Any reproduction or unauthorized use without the written permission of Yamaha Motor Corporation, U.S.A. is expressly prohibited. Printed in U.S.A. P/N LIT-11616-14-12 EAS00003

NOTICE

This manual was produced by the Yamaha Motor Company, Ltd. primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual. Therefore, anyone who uses this book to perform maintenance and repairs on Yamaha vehicles should have a basic understanding of mechanics and the techniques to repair these types of vehicles. Repair and maintenance work attempted by anyone without this knowledge is likely to render the vehicle unsafe and unfit for use.

This model has been designed and manufactured to perform within certain specifications in regard to performance and emissions. Proper service with the correct tools is necessary to ensure that the vehicle will operate as designed. If there is any question about a service procedure, it is imperative that you contact a Yamaha dealer for any service information changes that apply to this model. This policy is intended to provide the customer with the most satisfaction from his vehicle and to conform to federal environmental quality objectives.

Yamaha Motor Company, Ltd. is continually striving to improve all of its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

NOTE:

- This Service Manual contains information regarding periodic maintenance to the emission control system. Please read this material carefully.
- Designs and specifications are subject to change without notice.

IMPORTANT MANUAL INFORMATION

Particularly important information is distinguished in this manual by the following.

| | The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED! |
|-----------|--|
| A WARNING | Failure to follow WARNING instructions <u>could result in severe injury or death</u> to the motorcycle operator, a bystander or a person checking or repairing the motorcycle. |
| CAUTION: | A CAUTION indicates special precautions that must be taken to avoid damage to the motorcycle. |
| NOTE: | A NOTE provides key information to make procedures easier or clearer. |

EAS00007

HOW TO USE THIS MANUAL

This manual is intended as a handy, easy-to-read reference book for the mechanic. Comprehensive explanations of all installation, removal, disassembly, assembly, repair and check procedures are laid out with the individual steps in sequential order.

- The manual is divided into chapters. An abbreviation and symbol in the upper right corner of each page indicate the current chapter. Refer to "SYMBOLS".
- ② Each chapter is divided into sections. The current section title is shown at the top of each page, except in chapter 3 ("PERIODIC CHECKS AND ADJUSTMENTS"), where the sub-section title(s) appears.
- ③ Sub-section titles appear in smaller print than the section title.
- ④ To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section.
- (5) Numbers are given in the order of the jobs in the exploded diagram. A circled number indicates a disassembly step.
- ⑥ Symbols indicate parts to be lubricated or replaced. Refer to "SYMBOLS".
- ⑦ A job instruction chart accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.
- ③ Jobs requiring more information (such as special tools and technical data) are described sequentially.





SYMBOLS

The following symbols are not relevant to every vehicle.

Symbols (1) to (9) indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic checks and adjustments
- ④ Engine
- ⑤ Cooling system
- 6 Carburetion
- ⑦ Chassis
- ⑧ Electrical system
- ③ Troubleshooting

Symbols (1) to (7) indicate the following.

- 1 Serviceable with engine mounted
- 1) Filling fluid
- 1 Lubricant
- (3) Special tool
- (4) Tightening torque
- (5) Wear limit, clearance
- (6) Engine speed
- 17 Electrical data

Symbols (B) to (2) in the exploded diagrams indicate the types of lubricants and lubrication points.

- 18 Engine oil
- 19 Gear oil
- 2 Molybdenum disulfide oil
- ② Wheel bearing grease
- 2 Lithium soap base grease
- 23 Molybdenum disulfide grease

Symbols (2) to (2) in the exploded diagrams indicate the following.

- ② Apply locking agent (LOCTITE[®])
- 25 Replace the part

TABLE OF CONTENTS



CONTENTS CHAPTER 1. GENERAL INFORMATION

| MOTORCYCLE IDENTIFICATION | 1-1 |
|---|-----|
| VEHICLE IDENTIFICATION NUMBER | 1-1 |
| MODEL CODE | 1-1 |
| | |
| IMPORTANT INFORMATION | 1-2 |
| PREPARATION FOR REMOVAL AND DISASSEMBLY | 1-2 |
| REPLACEMENT PARTS | 1-2 |
| GASKETS, OIL SEALS AND O-RINGS | 1-2 |
| LOCK WASHERS/PLATES AND COTTER PINS | 1-3 |
| BEARINGS AND OIL SEALS | 1-3 |
| CIRCLIPS | |
| CHECKING THE CONNECTIONS | 1-4 |
| | |

| SPECIAL TOOLS1-5 |
|------------------|
|------------------|

CHAPTER 2. SPECIFICATIONS

| GENERAL SPECIFICATIONS | 2-1 |
|--|------|
| ENGINE SPECIFICATIONS | 2-2 |
| CHASSIS SPECIFICATIONS | 2-12 |
| ELECTRICAL SPECIFICATIONS | 2-15 |
| CONVERSION TABLE | 2-18 |
| GENERAL TIGHTENING TORQUE SPECIFICATIONS | 2-18 |
| TIGHTENING TORQUES | 2-19 |
| ENGINE TIGHTENING TORQUES | 2-19 |
| CHASSIS TIGHTENING TORQUES | 2-22 |
| LUBRICATION POINTS AND LUBRICANT TYPES | 2-24 |
| | |
| ENGINE | 2-24 |

| COOLING SYSTEM DIAGRAMS | 2-26 | |
|--|--|---|
| OIL FLOW DIAGRAMS | 2-28 | |
| CABLE ROUTING | 2-32 | ð |
| CHAPTER 3. | | GEN INFO |
| PERIODIC CHECKS AND ADJUSTMEN | TS | |
| | 3-1 | SPEC 2 |
| PERIODIC MAINTENANCE CHART FOR THE EMISSION CONTROL SYSTEM | 3-1 | |
| GENERAL MAINTENANCE AND LUBRICATION CHART | 3-2 | ADJ 3 |
| SEATS AND SIDE COVERS | 3-4 | |
| | | |
| TOP COVER AND COVERS | 3-5 | ENG 4 |
| TOP COVER AND COVERS | 3-5 3-6 | ENG 2 |
| TOP COVER AND COVERS | 3-5 3-6 3-7 | ENG 4 S COOL 5 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE | 3-5 3-6 3-7 3-7 | ENG 4 S COOL 5 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE | 3-5 3-6 3-7 3-7 3-12 | ENG 4 S COOL 5 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED | 3-5 3-6 3-7 3-7 3-12 3-14 | ENG S COOL 5 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY | 3-5 3-6 3-7 3-7 3-12 3-14 3-15 | |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE SPARK PLUGS | 3-5 3-6 3-7 3-7 3-12 3-14 3-15 3-16 | ENG 4 COOL 5 CARB 6 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE SPARK PLUGS CHECKING THE IGNITION TIMING | 3-5 3-6 3-7 3-7 3-12 3-14 3-15 3-16 3-17 | ENG 4 S COOL 5 CARB 6 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE SPARK PLUGS CHECKING THE IGNITION TIMING MEASURING THE COMPRESSION PRESSURE | | ENG 4 S COOL 5 CARB 6 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE SPARK PLUGS CHECKING THE IGNITION TIMING MEASURING THE COMPRESSION PRESSURE CHECKING THE ENGINE OIL LEVEL | | ENG COOL 5 CARB 6 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE SPARK PLUGS CHECKING THE IGNITION TIMING MEASURING THE COMPRESSION PRESSURE CHECKING THE ENGINE OIL LEVEL CHECKING THE ENGINE OIL LEVEL | | ENG COOL COOL CARB CARB CHAS |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE IGNITION TIMING MEASURING THE COMPRESSION PRESSURE CHECKING THE ENGINE OIL LEVEL CHECKING THE ENGINE OIL DIL EVEL CHECKING THE ENGINE OIL DIL EVEL | | ENG COOL COOL CARB CARB CARB CHAS 7 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE SPARK PLUGS CHECKING THE IGNITION TIMING MEASURING THE COMPRESSION PRESSURE CHECKING THE ENGINE OIL LEVEL CHANGING THE ENGINE OIL PRESSURE CHECKING THE ENGINE OIL PRESSURE | | ENG COOL COOL CARB 6 CARB 6 CHAS 7 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE SPARK PLUGS CHECKING THE IGNITION TIMING MEASURING THE COMPRESSION PRESSURE CHECKING THE ENGINE OIL LEVEL CHANGING THE ENGINE OIL PRESSURE CHECKING THE AIR FILTER FI EMENT | | ENG 4 COOL 5 COOL 5 CARB 6 CHAS 7 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE SPARK PLUGS CHECKING THE IGNITION TIMING MEASURING THE COMPRESSION PRESSURE CHECKING THE ENGINE OIL LEVEL CHANGING THE ENGINE OIL DIL EVEL CHECKING THE ENGINE OIL PRESSURE CHECKING THE ENGINE OIL PRESSURE CHECKING THE ENGINE OIL PRESSURE CHECKING THE CLUTCH FLUID LEVEL BLEEDING THE HYDRAULIC CLUTCH SYSTEM CLEANING THE AIR FILTER ELEMENT CHECKING THE AIR FILTER ELEMENT | | ENG COOL COOL CARB CARB CARB CHAS 7 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE IGNITION TIMING MEASURING THE ENGINE OIL LEVEL CHECKING THE ENGINE OIL LEVEL CHECKING THE ENGINE OIL MEASURING THE ENGINE OIL CHECKING THE CLUTCH FLUID LEVEL BLEEDING THE HYDRAULIC CLUTCH SYSTEM CLEANING THE AIR FILTER ELEMENT CHECKING THE CARBURETOR JOINTS CHECKING THE CARBURETOR JOINTS | | ENG 4 COOL 5 COOL 5 CARB 6 CARB 6 CHAS 7 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE SPARK PLUGS CHECKING THE IGNITION TIMING MEASURING THE COMPRESSION PRESSURE CHECKING THE ENGINE OIL LEVEL CHANGING THE ENGINE OIL PRESSURE CHECKING THE CLUTCH FLUID LEVEL BLEEDING THE HYDRAULIC CLUTCH SYSTEM CLEANING THE AIR FILTER ELEMENT CHECKING THE CARBURETOR JOINTS CHECKING THE VACUUM HOSES CHECKING THE VACUUM HOSES | | ENG 4 COOL 5 COOL 5 CARB 6 CARB 6 CHAS 7 CHAS 7 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE SPARK PLUGS CHECKING THE IGNITION TIMING MEASURING THE COMPRESSION PRESSURE CHECKING THE ENGINE OIL LEVEL CHANGING THE ENGINE OIL PRESSURE CHECKING THE CLUTCH FLUID LEVEL BLEEDING THE HYDRAULIC CLUTCH SYSTEM CLEANING THE CARBURETOR JOINTS CHECKING THE CARBURETOR JOINTS CHECKING THE VACUUM HOSES CHECKING THE FUEL HOSES AND FUEL FILTER CHECKING THE FUEL HOSES AND FUEL FILTER | | ENG 4 COOL 5 COOL 5 CARB 6 CARB 6 CHAS 7 ELEC 8 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE SPARK PLUGS CHECKING THE IGNITION TIMING MEASURING THE COMPRESSION PRESSURE CHECKING THE ENGINE OIL LEVEL CHANGING THE ENGINE OIL PRESSURE CHECKING THE ENGINE OIL PRESSURE CHECKING THE CLUTCH FLUID LEVEL BLEEDING THE HYDRAULIC CLUTCH SYSTEM CLEANING THE CARBURETOR JOINTS CHECKING THE VACUUM HOSES CHECKING THE FUEL HOSES AND FUEL FILTER CHECKING THE FUEL HOSES AND FUEL FILTER CHECKING THE EXANKCASE BREATHER HOSE | | ENG 4 COOL 5 COOL 5 CARB 6 CARB 6 CHAS 7 ELEC 8 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE IGNITION TIMING MEASURING THE COMPRESSION PRESSURE CHECKING THE ENGINE OIL LEVEL CHANGING THE ENGINE OIL PRESSURE CHECKING THE CLUTCH FLUID LEVEL BLEEDING THE HYDRAULIC CLUTCH SYSTEM CLEANING THE CARBURETOR JOINTS CHECKING THE VACUUM HOSES CHECKING THE FUEL HOSES AND FUEL FILTER CHECKING THE FUEL HOSES AND FUEL FILTER CHECKING THE ENGL HOSES AND FUEL FILTER CHECKING THE FUEL HOSES AND FUEL FILTER CHECKING THE CRANKCASE BREATHER HOSE CHECKING THE EXHAUST SYSTEM CHECKING THE EXHAUST SYSTEM | | ENG 4 COOL 5 COOL 5 CARB 6 CARB 6 CHAS 7 ELEC 8 |
| TOP COVER AND COVERS AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD ENGINE ADJUSTING THE VALVE CLEARANCE SYNCHRONIZING THE CARBURETORS ADJUSTING THE ENGINE IDLING SPEED ADJUSTING THE THROTTLE CABLE FREE PLAY CHECKING THE IGNITION TIMING MEASURING THE COMPRESSION PRESSURE CHECKING THE ENGINE OIL LEVEL CHANGING THE ENGINE OIL PRESSURE CHECKING THE ENGINE OIL PRESSURE CHECKING THE CLUTCH FLUID LEVEL BLEEDING THE HYDRAULIC CLUTCH SYSTEM CLEANING THE CARBURETOR JOINTS CHECKING THE VACUUM HOSES CHECKING THE FUEL HOSES AND FUEL FILTER CHECKING THE CRANKCASE BREATHER HOSE CHECKING THE COOLANT LEVEL CHECKING THE COOLANT LEVEL | | ENG 4 COOL 5 COOL 5 CARB 6 CARB 6 CHAS 7 CHAS 7 ELEC 8 |

| CHASSIS | 3-33 |
|--|------|
| ADJUSTING THE FRONT BRAKE | 3-33 |
| ADJUSTING THE REAR BRAKE | 3-34 |
| CHECKING THE BRAKE FLUID LEVEL | 3-35 |
| CHECKING THE BRAKE PADS | 3-36 |
| ADJUSTING THE REAR BRAKE LIGHT SWITCH | 3-36 |
| CHECKING THE BRAKE HOSES | 3-37 |
| BLEEDING THE HYDRAULIC BRAKE SYSTEM | 3-37 |
| ADJUSTING THE SHIFT PEDAL | 3-39 |
| CHECKING THE FINAL DRIVE OIL LEVEL | 3-39 |
| CHANGING THE FINAL DRIVE OIL | 3-40 |
| CHECKING AND ADJUSTING THE STEERING HEAD | 3-41 |
| CHECKING THE FRONT FORK | 3-43 |
| ADJUSTING THE FRONT FORK LEGS | 3-43 |
| ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLIES | 3-44 |
| CHECKING THE TIRES | 3-46 |
| CHECKING THE WHEELS | 3-48 |
| CHECKING AND LUBRICATING THE CABLES | 3-49 |
| LUBRICATING THE LEVERS AND PEDALS | 3-49 |
| LUBRICATING THE SIDESTAND | 3-50 |
| LUBRICATING THE CENTERSTAND | 3-50 |
| LUBRICATING THE REAR SUSPENSION | 3-50 |

| ELECTRICAL SYSTEM | 3-51 |
|------------------------------|------|
| CHECKING THE BATTERY | 3-51 |
| CHECKING THE FUSES | 3-55 |
| REPLACING THE HEADLIGHT BULB | 3-56 |
| ADJUSTING THE HEADLIGHT BEAM | 3-58 |

CHAPTER 4. ENGINE

| ENGINE REMOVAL | 4-1 |
|--|------|
| EXHAUST PIPES, MUFFLER AND AIR BAFFLE PLATES | 4-1 |
| BRAKE PEDAL, FOOTREST (RIGHT), MASTER CYLINDER | |
| AND GROUND LEAD | 4-2 |
| LEADS, CABLES AND HOSES | 4-3 |
| ENGINE MOUNTING BOLTS | 4-4 |
| INSTALLING THE ENGINE | 4-6 |
| | |
| CAMSHAFTS | 4-7 |
| CYLINDER HEAD COVERS | 4-7 |
| CAMSHAFTS | 4-9 |
| REMOVING THE CAMSHAFTS | 4-10 |
| CHECKING THE CAMSHAFTS | 4-11 |
| CHECKING THE TIMING CHAIN, CAMSHAFT SPROCKETS, | |
| AND TIMING CHAIN GUIDES | 4-13 |
| CHECKING THE TIMING CHAIN TENSIONER | 4-13 |
| INSTALLING THE CAMSHAFTS | 4-14 |

| CYLINDER HEADS | 4-21 | |
|--|----------------------------------|----------|
| REMOVING THE CYLINDER HEADS | 4-22 | |
| CHECKING THE V-BOOST | 4-22 | |
| ADJUSTING THE BUTTERFLY SHAFT LEVER-TO-ADJUSTING | | |
| BOLT CLEARANCE | 4-22 | |
| SYNCHRONIZING THE V-BOOST | 4-24 | ā |
| CHECKING THE CYLINDER HEADS | 4-25 | |
| INSTALLING THE CYLINDER HEAD | 4-26 | GEI |
| | | |
| VALVES AND VALVE SPRINGS | 4-27 | — |
| REMOVING THE VALVES | 4-28 | |
| CHECKING THE VALVES AND VALVE GUIDES | 4-29 | |
| CHECKING THE VALVE SEATS | 4-31 | SPE |
| | + -01 ∕/₋33 | ••• |
| | 4-33 | |
| | 4 24 | |
| INSTALLING THE VALVES | 4-34 | |
| | | CHI |
| CLUTCH | 4-36 | AD. |
| CRANKCASE COVER (RIGHT SIDE) | 4-36 | |
| CLUTCH ASSEMBLY | 4-37 | |
| REMOVING THE CLUTCH | 4-39 | |
| CHECKING THE FRICTION PLATES | 4-39 | |
| CHECKING THE CLUTCH PLATES | 4-40 | |
| CHECKING THE CLUTCH SPRING PLATE | 4-40 | |
| CHECKING THE CLUTCH HOUSING | 4-41 | |
| CHECKING THE CLUTCH BOSS | 4-41 | |
| CHECKING THE PRESSURE PLATE | 4-41 | |
| CHECKING THE CLUTCH PUSH RODS | 4-42 | COC |
| CHECKING THE PRIMARY DRIVE | 4-42 | |
| INSTALLING THE CLUTCH | 4-42 | |
| | | |
| SHIFT SHAFT | 4-45 | |
| GENERATOR ROTOR COVER | 4-45 | CAR |
| SHIET SHAFT AND STOPPER I EVER | 4-46 | |
| CHECKING THE SHIFT SHAFT | 4 -40 <i>A</i> _47 | |
| | 4-47 | d |
| | 4-47 | Ċ |
| INSTALLING THE SHIFT SHAFT | 4-47 | СНА |
| CENERATOR | 4 40 | |
| | 4-49 | |
| | | - |
| | 4-51 | |
| | 4-52 | |
| | 4-53 | |
| INSTALLING THE GENERATOR | 4-54 | L |



| OIL PAN AND OIL PUMP | 4-55 |
|--|--------|
| OIL PUMP | 4-57 |
| REMOVING THE OIL PAN | 4-59 |
| CHECKING THE OIL PUMP | 4-59 |
| CHECKING THE RELIEF VALVE | 4-60 |
| CHECKING THE OIL DELIVERY PIPE | 4-60 |
| | 4-60 |
| | 4-61 |
| | 4-62 |
| | 4-02 |
| | |
| CRANKCASE | 4-63 |
| SEPARATING THE CRANKCASE | 4-66 |
| ASSEMBLING THE CRANKCASE | 4-67 |
| | |
| CRANKSHAFT | 4-70 |
| REMOVING THE CRANKSHAFT ASSEMBLY | 4-71 |
| CHECKING THE CRANKSHAFT | 4-71 |
| CHECKING THE BALANCER SHAFT | 4-74 |
| | 4-76 |
| INSTALLING THE BALANCER SHAFT | 4-77 |
| | |
| CONNECTING RODS AND PISTONS | 4-78 |
| REMOVING THE CONNECTING RODS AND PISTONS | 4-79 |
| CHECKING THE CYLINDERS AND PISTONS | 4-80 |
| CHECKING THE PISTON RINGS | 4-81 |
| CHECKING THE PISTON PINS | 4-82 |
| INSTALLING THE PISTONS AND CYLINDERS | 4-85 |
| | |
| TRANSMISSION | 4-88 |
| CHECKING THE SHIFT FORKS | 4-91 |
| CHECKING THE SHIFT DRUM ASSEMBLY | 4-91 |
| CHECKING THE TRANSMISSION | 4-92 |
| INSTALLING THE TRANSMISSION | 4-93 |
| | |
| MIDDLE GEAR | 4-95 |
| DISASSEMBLING THE MIDDLE DRIVE SHAFT ASSEMBLY | 4-97 |
| DISASSEMBLING THE MIDDLE DRIVEN SHAFT ASSEMBLY | 4-97 |
| CHECKING THE MIDDLE DRIVE SHAFT ASSEMBLY | 4-98 |
| CHECKING THE MIDDLE DRIVEN SHAFT ASSEMBLY | 4-99 |
| ASSEMBLING THE MIDDLE DRIVE SHAFT ASSEMBLY | 4-99 |
| ASSEMBLING THE MIDDLE DRIVEN SHAFT ASSEMBLY | 4-100 |
| | 4-102 |
| | .4-103 |
| ALIGNING THE MIDDLE GEAK | .4-106 |

CHAPTER 5. COOLING SYSTEM

| RADIATOR AND RADIATOR HOSES | 5-1 |
|-----------------------------|-----|
| CHECKING THE RADIATOR | 5-3 |
| INSTALLING THE RADIATOR | 5-3 |

| THERMOSTAT ASSEMBLY AND CONDUIT | 5-4 |
|------------------------------------|------|
| CHECKING THE THERMOSTAT | 5-8 |
| CHECKING THE RADIATOR CAP | 5-9 |
| ASSEMBLING THE THERMOSTAT ASSEMBL | Y5-9 |
| INSTALLING THE THERMOSTAT ASSEMBLY | 5-10 |

| WATER PUMP | 5-11 |
|------------------------------|------|
| DISASSEMBLING THE WATER PUMP | 5-14 |
| CHECKING THE WATER PUMP | 5-14 |
| ASSEMBLING THE WATER PUMP | 5-16 |
| INSTALLING THE WATER PUMP | 5-17 |

CHAPTER 6. CARBURETION

| CARBURETORS | 6-1 |
|--|------|
| CHECKING THE CARBURETORS | 6-7 |
| ASSEMBLING THE CARBURETORS | 6-9 |
| INSTALLING THE CARBURETORS | 6-10 |
| MEASURING AND ADJUSTING THE FUEL LEVEL | 6-11 |
| CHECKING THE FUEL PUMP | 6-12 |

CHAPTER 7. CHASSIS

| FRONT WHEEL AND BRAKE DISCS | 7-1 |
|--|-----|
| REMOVING THE FRONT WHEEL | 7-4 |
| DISASSEMBLING THE FRONT WHEEL | 7-4 |
| CHECKING THE FRONT WHEEL | 7-5 |
| CHECKING THE BRAKE DISCS | 7-6 |
| CHECKING THE SPEEDOMETER GEAR UNIT | 7-8 |
| ASSEMBLING THE FRONT WHEEL | 7-8 |
| INSTALLING THE FRONT WHEEL | 7-8 |
| ADJUSTING THE FRONT WHEEL STATIC BALANCE | 7-9 |



| REAR WHEEL AND BRAKE DISC | 7-12 |
|--|------|
| REMOVING THE REAR WHEEL | 7-15 |
| CHECKING THE REAR WHEEL | 7-16 |
| CHECKING THE REAR WHEEL DRIVE HUB | 7-16 |
| INSTALLING THE REAR WHEEL | 7-16 |
| ADJUSTING THE REAR WHEEL STATIC BALANCE | 7-17 |
| FRONT AND REAR BRAKES | 7-18 |
| REPLACING THE FRONT BRAKE PADS | 7-20 |
| REPLACING THE REAR BRAKE PADS | 7-22 |
| DISASSEMBLING THE FRONT BRAKE MASTER CYLINDER | 7-31 |
| DISASSEMBLING THE REAR BRAKE MASTER CYLINDER | 7-31 |
| CHECKING THE FRONT AND REAR BRAKE | |
| MASTER CYLINDERS | 7-32 |
| ASSEMBLING AND INSTALLING THE FRONT BRAKE | |
| MASTER CYLINDER | 7-33 |
| ASSEMBLING AND INSTALLING THE REAR BRAKE | |
| MASTER CYLINDER | 7-35 |
| DISASSEMBLING THE FRONT BRAKE CALIPERS | 7-42 |
| DISASSEMBLING THE REAR BRAKE CALIPER | 7-43 |
| CHECKING THE FRONT AND REAR BRAKE CALIPERS | 7-44 |
| ASSEMBLING AND INSTALLING THE FRONT BRAKE CALIPERS | 7-45 |
| ASSEMBLING AND INSTALLING THE REAR BRAKE CALIPER | 7-47 |
| | 7-50 |
| DISASSEMBLING THE CLUTCH MASTER CYLINDER | 7-53 |
| CHECKING THE CLUTCH MASTER CYLINDER | 7-54 |
| ASSEMBLING AND INSTALLING THE CLUTCH | |
| MASTER CYLINDER | 7-55 |
| DISASSEMBLING THE CLUTCH RELEASE CYLINDER | 7-61 |
| CHECKING THE CLUTCH RELEASE CYLINDER | 7-62 |
| ASSEMBLING AND INSTALLING THE CLUTCH | |
| RELEASE CYLINDER | 7-63 |
| FRONT FORK | 7-65 |
| REMOVING THE FRONT FORK LEGS | 7-68 |
| DISASSEMBLING THE FRONT FORK LEGS | 7-69 |
| CHECKING THE FRONT FORK LEGS | 7-70 |
| ASSEMBLING THE FRONT FORK LEGS | 7-71 |
| INSTALLING THE FRONT FORK LEGS | 7-74 |
| HANDLEBAR | 7-75 |
| REMOVING THE HANDLEBAR | 7-78 |
| CHECKING THE HANDLEBAR | 7-78 |
| INSTALLING THE HANDLEBAR | 7-79 |
| STEERING HEAD | 7-81 |
| REMOVING THE LOWER BRACKET | 7-83 |
| CHECKING THE STEERING HEAD | 7-83 |
| | |
| INSTALLING THE STEERING HEAD | 7-84 |

| REAR SHOCK ABSORBER | 7-86 |
|--|-------|
| HANDLING THE REAR SHOCK ABSORBER | 7-87 |
| REMOVING THE REAR SHOCK ABSORBER ASSEMBLIES | 7-87 |
| CHECKING THE REAR SHOCK ABSORBER ASSEMBLIES | 7-88 |
| INSTALLING THE REAR SHOCK ABSORBER ASSEMBLIES | 7-88 |
| | |
| SWINGARM | 7-89 |
| REMOVING THE SWINGARM | 7-91 |
| CHECKING THE SWINGARM | 7-92 |
| INSTALLING THE SWINGARM | 7-92 |
| | 7.04 |
| | 7-94 |
| | 7-94 |
| | 7 07 |
| AND CHECKING THE SHAFT DRIVE FOR LEAKS | |
| | |
| | 7-99 |
| MEASURING THE RING-GEAR-TO-STOPPER-BOLT | 7 400 |
| | 7-100 |
| ADJUSTING THE RING-GEAR-TO-STOPPER-BOLT | |
| | 7-100 |
| DISASSEMBLING THE FINAL DRIVE ASSEMBLY | 7-105 |
| REMOVING AND INSTALLING THE RING GEAR BEARINGS | 7-106 |
| ALIGNING THE FINAL DRIVE PINION GEAR AND RING GEAR . | 7-107 |
| CHECKING THE DRIVE SHAFT | 7-113 |
| INSTALLING THE FINAL DRIVE ASSEMBLY | 7-113 |
| CHAPTER 8. | |
| | |
| ELECTRICAL | |
| | |
| ELECTRICAL COMPONENTS | 8-1 |
| SWITCHES | 8-3 |
| | ~ ~ |

| SWITCHES | 8-3 |
|--|------|
| CHECKING SWITCH CONTINUITY | 8-3 |
| | |
| CHECKING THE SWITCHES | 8-4 |
| | |
| CHECKING THE BULBS AND BULB SOCKETS | 8-6 |
| TYPES OF BULBS | 8-6 |
| CHECKING THE CONDITION OF THE BULBS | 8-6 |
| CHECKING THE CONDITION OF THE BULB SOCKETS | 8-8 |
| | |
| IGNITION SYSTEM | 8-9 |
| CIRCUIT DIAGRAM | 8-9 |
| TROUBLESHOOTING | 8-10 |



| ELECTRIC STARTING SYSTEM | 8-14 |
|--|------|
| CIRCUIT DIAGRAM | 8-14 |
| STARTING CIRCUIT CUTOFF SYSTEM OPERATION | 8-15 |
| TROUBLESHOOTING | 8-16 |
| | |
| STARTER MOTOR | 8-20 |
| CHECKING THE STARTER MOTOR | |
| ASSEMBLING THE STARTER MOTOR | 8-23 |
| | |
| CHARGING SYSTEM | 8-25 |
| CIRCUIT DIAGRAM | |
| TROUBLESHOOTING | 8-26 |
| | |
| LIGHTING SYSTEM | 8-28 |
| CIRCUIT DIAGRAM | 8-28 |
| TROUBLESHOOTING | 8-29 |
| CHECKING THE LIGHTING SYSTEM | 8-30 |
| | |
| SIGNALING SYSTEM | 8-33 |
| CIRCUIT DIAGRAM | 8-33 |
| TROUBLESHOOTING | 8-35 |
| CHECKING THE SIGNALING SYSTEM | 8-36 |
| | |
| COOLING SYSTEM | 8-42 |
| CIRCUIT DIAGRAM | 8-42 |
| TROUBLESHOOTING | 8-43 |
| | |
| FUEL PUMP SYSTEM | 8-46 |
| CIRCUIT DIAGRAM | 8-46 |
| FUEL PUMP CIRCUIT OPERATION | 8-47 |
| TROUBLESHOOTING | 8-48 |
| CHECKING THE FUEL PUMP | 8-51 |
| | |
| V-BOOST SYSTEM | |
| | 8-52 |
| | 8-53 |
| | |
| CHAPIER 9. | |
| TROUBLESHOOTING | |

| STARTING PROBLEMS | 9-1 |
|--------------------|-----|
| ENGINE | |
| FUEL SYSTEM | 9-1 |
| ELECTRICAL SYSTEMS | |

| INCORRECT ENGINE IDLING SPEED9-2 | 2 |
|--|--------------|
| ENGINE9-2 | 2 |
| FUEL SYSTEM9-2 | 2 |
| ELECTRICAL SYSTEMS9-2 | 2 |
| | 6 |
| | |
| | |
| | |
| | |
| | |
| FAULTY GEAR SHIFTING9-3 | |
| SHIFTING IS DIFFICULT9-3 | 3 |
| SHIFT PEDAL DOES NOT MOVE9-3 | |
| JUMPS OUT OF GEAR9-3 | |
| | |
| | |
| | |
| | <u>CHK</u> |
| | ADJ 🖸 |
| | |
| OVERHEATING9-4 | |
| ENGINE9-4 | |
| COOLING SYSTEM9-2 | |
| FUEL SYSTEM9-4 | |
| CHASSIS9-4 | |
| ELECTRICAL SYSTEMS9-4 | |
| | |
| OVERCOOLING 9-4 | |
| COOLING SYSTEM 9-4 | |
| | |
| | |
| POOR BRAKING PERFORMANCE9-4 | |
| | |
| FAULTY FRONT FORK LEGS | |
| LEAKING OIL9-5 | |
| MALFUNCTION9-5 | 5 For |
| | |
| | |
| UNSTABLE HANDLING | |
| | |
| FAULTY LIGHTING OR SIGNALING SYSTEM9-6 | |
| HEADLIGHT DOES NOT LIGHT9-6 | 3 · · |
| HEADLIGHT BULB BURNT OUT9-6 | |
| TAIL/BRAKE LIGHT DOES NOT LIGHT9-6 | |
| TAIL/BRAKE LIGHT BULB BURNT OUT | |
| TURN SIGNAL DOES NOT LIGHT9-6 | |
| TURN SIGNAL BLINKS SLOWLY9-6 | s 7 |
| TURN SIGNAL REMAINS LIT9-6 | |
| TURN SIGNAL BLINKS QUICKLY9-6 | |
| HORN DOES NOT SOUND9-6 | SHTG |
| | |







GENERAL INFORMATION MOTORCYCLE IDENTIFICATION

VEHICLE IDENTIFICATION NUMBER

The vehicle identification number ① is stamped into the right side of the steering head pipe.

MODEL CODE

The model code label ① is affixed to the frame. This information will be needed to order spare parts.









IMPORTANT INFORMATION PREPARATION FOR REMOVAL AND DISASSEMBLY

- 1. Before removal and disassembly, remove all dirt, mud, dust and foreign material.
- 2. Use only the proper tools and cleaning equipment. Refer to the "SPECIAL TOOLS".
- 3. When disassembling, always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.
- 4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
- 5. Keep all parts away from any source of fire.

REPLACEMENT PARTS

Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.



GASKETS, OIL SEALS AND O-RINGS

- 1. When overhauling the engine, replace all gaskets, seals and O-rings. All gasket surfaces, oil seal lips and O-rings must be cleaned.
- 2. During reassembly, properly oil all mating parts and bearings and lubricate the oil seal lips with grease.











LOCK WASHERS/PLATES AND COTTER PINS

After removal, replace all lock washers/plates ① and cotter pins. After the bolt or nut has been tightened to specification, bend the lock tabs along a flat of the bolt or nut.

BEARINGS AND OIL SEALS

Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals, lubricate the oil seal lips with a light coat of lithium soap base grease. Oil bearings liberally when installing, if appropriate.

1) Oil seal

OAUTIONA

Do not spin the bearing with compressed air because this will damage the bearing surfaces.

① Bearing

CIRCLIPS

Before reassembly, check all circlips carefully and replace damaged or distorted circlips. Always replace piston pin clips after one use. When installing a circlip ①, make sure the sharp-edged corner ② is positioned opposite the thrust ③ that the circlip receives.

④ Shaft



CHECKING THE CONNECTIONS

Check the leads, couplers, and connectors for stains, rust, moisture, etc.

- 1. Disconnect:
- lead
- coupler
- connector
- 2. Check:
- lead
- coupler
- connector

Moisture \rightarrow Dry with an air blower.

Rust/stains \rightarrow Connect and disconnect several times.

- 3. Check:
- all connections
 Loose connection → Connect properly.

NOTE:

If the pin on the terminal is flattened, bend it up.

- 4. Connect:
- lead
- coupler
- connector

NOTE: _

Make sure all connections are tight.

- 5. Check:
- continuity (with the pocket tester)

Pocket tester YU-03112

NOTE:

- If there is no continuity, clean the terminals.
- When checking the wire harness, perform steps (1) to (3).
- As a quick remedy, use a contact revitalizer available at most part stores.











SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools as this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools, part numbers or both may differ depending on the country.

When placing an order, refer to the list provided below to avoid any mistakes.

| Tool No. | Tool name/Function | Illustration |
|--|--|---|
| YM-01122 | Valve guide remover (5.5 mm) This tool is needed to remove and | Tanana and |
| | Install the valve guide. | ~ |
| YM-01196 | This tool is needed to rebore the new valve guide. | B |
| YM-01229 | Coupling gear/middle shaft tool This tool is needed when removing or installing the coupling gear nut. | |
| YM-01230 | Final gear backlash band This tool is needed when measuring final gear backlash. | C C C C C C C C C C C C C C C C C C C |
| YU-01304 | Piston pin puller set This tool is used to remove the piston pin. | O D D D D D D D D D D D D D D D D D D D |
| YU-01312-A | Fuel level gauge This gauge is used to measure the fuel level in the float chamber. | |
| Tester YU-24460-01 Adapter YU-33984 | Radiator cap tester Adapter This tester and its adapter are needed for checking the cooling system. | |

| | SPECI | AL TOOLS | GEN INFO |
|--|--|----------|--|
| Tool No. | Tool name/Function | Illus | tration |
| Puller YU-33270 Attachment YM-33282 | Flywheel puller Attachment These tools are needed to remove the rotor. | | Co |
| Weight YM-33963 Attachment YM-8020 | Fork seal driver weight Attachment (f40) These tools are needed when installing the slide metal, oil seal and dust seal into the fork. | | |
| Rod holder YM-33962 T-handle YM-01326 | Damper rod holder (29 mm) T-handle These tools are needed to loosen and tighten the damper rod holding bolt. | | 5 |
| YU-33975 | Steering nut wrench This tool is needed to loosen and tighten the steering stem ring nut. | | \rightarrow |
| YU-38411 | Oil filter wrench This tool is needed to remove and install the oil filter. | | |
| YU-01701 | Sheave holder This tool is needed to hold the rotor when removing or installing the rotor bolt. | | No contraction of the second s |
| YU-03017 | Cylinder bore gauge (50 ~ 100 mm) This tool is used to measure the cylin- der bore. | | |
| YU-33223 | Compression gauge These tools are needed to measure engine compression. | | |

1

| GEN | 5 |
|-----|-----|
| | 0 0 |

| Tool No. | Tool name/Function | Illustration |
|---|---|--------------|
| YU-08030-A | Vacuum gauge This gauge is needed for carburetor synchronization. | |
| YU-03097 | Dial gauge This tool is used to measure the middle gear backlash. | |
| YU-03112 | Pocket tester This instrument is needed for checking the electrical system. | |
| YU-8036-A | Inductive tachometer This tool is needed for observing engine rpm. | |
| YM-33277-A | Timing light This tool is necessary for checking igni- tion timing. | |
| Gauge 90890-03153 Oil pressure adaptor B 90890-03124 | Pressure gauge Oil pressure adaptor B These tools are needed to measure engine oil pressure. | |
| YM-4015 | Valve guide installer (5.5 mm) This tool is needed to install the valve guide. | |
| Compressor YM-04019 Attachment YM-01253-1 | Valve spring compressor/attachment These tools are needed to remove and install the valve assemblies. | A COLO |

| SPECIAL TOOLS | | | | ð 0 |
|---------------|---|-------|-----------|-----|
| Tool No. | Tool name/Function | Illus | tration | |
| YM-04050 | Bearing retainer wrench This tool is needed when removing or installing the final drive shaft bearing. | | | |
| YM-04054 | Middle drive shaft nut wrench (55 mm) This tool is needed when removing or installing the middle drive shaft nut. | | 8 | |
| YM-33222 | Middle drive gear holder This tool is needed to remove and install the middle drive pinion gear. This tool is also used for the gear back- lash adjustment. | | | |
| YM-04062 | Universal joint holder This tool is needed when removing or installing the driven pinion gear nut. | | | |
| 90890-04080 | Middle gear backlash tool This tool is needed for the gear back- lash adjustment. | | | |
| YM-91042 | Clutch holding tool This tool is needed to hold the clutch when removing or installing the clutch boss nut. | | · · · · · | , |
| YM-33286 | Damper spring compressor This tool is needed when removing or installing the damper spring. | A | | |
| YM-33961 | Tappet adjusting tool This tool is needed to rotate the cam- shaft for access to the valve lifter and valve pad. | G | | |

1

GEN INFO

Q

| | Tool name/Eurotion | Illustration |
|----------------|--|---|
| 1001 100. | | IIIUSUAUOII |
| YM-8037 | Piston ring compressor This tool is used to compress the piston rings when installing the piston into the cylinder. | |
| YM-34487 | Ignition checker | a compared to the second se |
| ACC-1100-15-01 | Quick gasket [®] This sealant (bond) is used on crank- case mating surfaces, etc. | |
| YM-01524 | Ring gear fix bolt (M14) This tool is used to measure the gear lash. | M14×P1.5 |

GENERAL SPECIFICATIONS



SPECIFICATIONS

GENERAL SPECIFICATIONS

| Item | Standard | Limit |
|--------------------------------------|----------------------------------|-------|
| Dimensions | | |
| Overall length | 2,300 mm (90.6 in) | |
| Overall width | 795 mm (31.3 in) | |
| Overall height | 1,160 mm (45.7 in) | |
| Seat height | 765 mm (30.1 in) | |
| Wheelbase | 1,590 mm (62.6 in) | |
| Minimum ground clearance | 145 mm (5.7 in) | |
| Minimum turning radius | 2,900 mm (114.2 in) | |
| Weight | | |
| Wet (with oil and a full fuel tank) | 283 kg (624 lb) | |
| | 284 kg (626 lb) (for California) | |
| Dry (without oil and fuel) | 263 kg (580 lb) | |
| | 263 kg (580 lb) (for California) | |
| Maximum load (total of cargo, rider, | 216 kg (476 lb) | |
| passenger, and accessories) | 215 kg (474 lb) (for California) | |

2



| Item | Standard | Limit |
|---|---|-------|
| Engine | | |
| Engine type | Liquid-cooled, 4-stroke, DOHC | |
| Displacement | 1,198 cm ³ | |
| Cylinder arrangement | V-type 4-cylinder | |
| Bore \times stroke | 76 × 66 mm (2.99 × 2.60 in) | |
| Compression ratio | 10.5 : 1 | |
| Engine idling speed | 950 ~ 1,050 r/min | |
| | 1,050 ~ 1,150 r/min (for California) | |
| Vacuum pressure at engine idling | 26.7 kPa (200 mm Hg, 7.88 in Hg) | |
| speed | 33.3 kPa (250 mm Hg, 9.83 in Hg) | |
| | (for California) | |
| Standard compression pressure | 1,450 kPa | |
| (at sea level) | (14.5 kgf/cm ² , 210 psi) at 350 r/min | |
| Fuel | | |
| Recommended fuel | Unleaded fuel | |
| Fuel tank capacity | | |
| Total (including reserve) | 15 L (13.2 Imp qt, 15.9 US qt) | |
| Reserve only | 3 L (2.64 Imp qt, 3.17 US qt) | |
| Engine oil | | |
| Lubrication system | Wet sump | |
| Recommended oil | | |
| $ \begin{array}{cccccccccccccccccccccccccccccccccccc$ | Yamalube 4 (20W40) or SAE 20W40 type SE motor oil (5 °C/40 °F or above) (Non-Friction modofied) Yamalube 4 (10W30) or SAE 10W30 type SE motor oil (15 °C/60 °F or below) (Non-Friction modofied) | |
| Quantity | | |
| Total amount | 4 L (3.52 Imp qt, 4.23 US at) | |
| Without oil filter cartridge replace- | 3.2 L (2.82 Imp gt, 3.38 US gt) | |
| ment | | |
| With oil filter cartridge replacement | 3.4 L (2.99 Imp qt, 3.59 US qt) | |
| Oil pressure (hot) | 25 kPa (0.25 kgf/cm², 3.6 psi) at | |
| | 1,000 r/min | |
| Relief valve opening pressure | 440 ~ 560 kPa | |
| | (4.4 ~ 5.6 kgf/cm ² , 63.8 ~ 81.2 psi) | |
| Final gear oil | | |
| Recommended oil | SAE 80 API "GL-4" Hypoid Gear Oil | |
| Final gear case oil | | |
| Total amount | 0.2 L (0.18 Imp qt, 0.21 US qt) | |



| Item | Standard | Limit |
|---|---|-------------|
| Oil filter | | |
| Oil filter type | Cartridge (paper) | |
| Bypass valve opening pressure | 170 ~ 240 kPa | |
| | (1.7 ~ 2.4 kgf/cm ² , 24.7 ~ 34.8 psi) | |
| Oil pump | | |
| Oil pump type | Trochoid | |
| Inner-rotor-to-outer-rotor-tip clearance | 0 ~ 0.12 mm (0 ~ 0.005 in) | 0.17 mm |
| · | , , , , , , , , , , , , , , , , , , , | (0.007 in) |
| Outer-rotor-to-oil-pump-housing | 0.03 ~ 0.08 mm (0.001 ~ 0.003 in) | 0.08 mm |
| clearance | , , | (0.003 in) |
| Cooling system | | |
| Radiator capacity | 3.05 L (2.68 Imp qt, 3.22 US qt) | |
| Radiator cap opening pressure | 75 ~ 105 kPa | |
| | (0.75 ~ 1.05 kgf/cm², 10.9 ~ 15.2 psi) | |
| Radiator core | | |
| Width | 363.8 mm (14.3 in) | |
| Height | 240 mm (9.4 in) | |
| Depth | 16 mm (0.63 in) | |
| Coolant reservoir | | |
| Capacity | 0.3 L (0.26 Imp qt, 0.32 US qt) | |
| <from full="" level="" low="" to=""></from> | 0.2 L (0.18 Imp qt, 0.21 US qt) | |
| Water pump | | |
| Water pump type | Single-suction centrifugal pump | |
| Reduction ratio | 31/21 (1.476) | |
| Max. impeller shaft tilt | | 0.15 mm |
| | | (0.006 in) |
| Starting system type | Electric starter | |
| Spark plugs | | |
| Model (manufacturer) × quantity | DPR8EA-9/X24EPR-U9 (NGK/DENSO) × 4 | |
| Spark plug gap | 0.8 ~ 0.9 mm (0.03 ~ 0.04 in) | |
| Cylinder head | | |
| Max. warpage | | 0.03 mm |
| | | (0.0012 in) |



| Item | Standard | Limit |
|---|---|--|
| Item Camshafts Drive system Camshaft cap inside diameter Camshaft journal diameter Camshaft-journal-to-camshaft-cap clearance Intake camshaft lobe dimensions | Standard Chain drive (center) 25.000 ~ 25.021 mm (0.9843 ~ 0.9851 in) 24.967 ~ 24.980 mm (0.9830 ~ 0.9835 in) 0.020 ~ 0.054 mm (0.0008 ~ 0.0021 in) | Limit |
| Measurement B | $36.25 \sim 36.35 \text{ mm} (1.4272 \sim 1.4311 \text{ in})$ | 36.15 mm (1.42 in) 27 92 mm |
| Exhaust camshaft lobe dimensions | 27.98 ~ 28.08 mm (1.1031 ~ 1.1043 in) (for California) | (1.1 in) 27.87 mm (1.1 in) |
| Measurement A | 36.25 ~ 36.35 mm (1.4272 ~ 1.4311 in) | 36.15 mm |
| Measurement B | 28.02 ~ 28.12 mm (1.1031 ~ 1.1043 in) | (1.42 m) 27.92 mm (1.1 in) |
| Max. camshaft runout | 27.98 ~ 28.08 mm (1.1016 ~ 1.1055 in) (for California) | 27.87 mm (1.1 in) 0.03 mm (0.0012 in) |
| | | |



| Item | Standard | Limit |
|---|---------------------------------------|---------------------------------------|
| Timing chain | | |
| Model/number of links | 219FTS/117 | |
| Tensioning system | Automatic | |
| Valves, valve seats, valve guides | | |
| Valve clearance (cold) | | |
| Intake | 0.11 ~ 0.15 mm (0.0043 ~ 0.0059 in) | |
| Exhaust | 0.26 ~ 0.30 mm (0.0102 ~ 0.0118 in) | |
| Valve dimensions | , , , | |
| | | |
| Head Diameter Face Width | Seat Width Margin | Thickness |
| Valve head diameter A | | |
| Intake | 30.4 ~ 30.6 mm (1.1968 ~ 1.2047 in) | |
| Exhaust | 24.9 ~ 25.1 mm (0.9803 ~ 0.9882 in) | |
| Valve face width B | | |
| Intake | 2.0 ~ 3.3 mm (0.0787 ~ 0.1299 in) | |
| Exhaust | 1.9 ~ 2.6 mm (0.0748 ~ 0.1024 in) | |
| Valve seat width C | | |
| Intake | 0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in) | 1.4 mm |
| Exhaust | 0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in) | (0.06 in) 1.4 mm (0.06 in) |
| Valve margin thickness D | | |
| Intake | 1.1 ~ 1.5 mm (0.043 ~ 0.059 in) | 0.7 mm (0.03 in) |
| Exhaust | 1.1 ~ 1.5 mm (0.043 ~ 0.059 in) | 0.7 mm (0.03 in) |
| Valve stem diameter | | , , , , , , , , , , , , , , , , , , , |
| Intake | 5.475 ~ 5.490 mm (0.2156 ~ 0.2161 in) | 5.445 mm (0.2144 in) |
| Exhaust | 5.460 ~ 5.475 mm (0.2150 ~ 0.2156 in) | 5.42 mm (0.2134 in) |
| Valve guide inside diameter Intake | 5.500 ~ 5.512 mm (0.2165 ~ 0.2170 in) | 5.55 mm |
| Exhaust | 5.500 ~ 5.512 mm (0.2165 ~ 0.2170 in) | (0.2185 ln) 5.55 mm (0.2185 in) |
| Valve-stem-to-valve-guide clearance Intake | 0.010 ~ 0.037 mm (0.0004 ~ 0.0015 in) | 0.08 mm |
| Exhaust | 0.025 ~ 0.052 mm (0.001 ~ 0.002 in) | 0.003 mm (0.004 in) |

2



| Item | Standard | Limit |
|---|--|-----------------|
| Valve stem runout | | 0.01 mm |
| <u>L</u> | | (0.0004 in) |
| | | |
| | | |
| | | |
| Volve aget width | | |
| | 0.9 = 1.1 mm (0.035 = 0.043 in) | |
| Fybaust | $0.9 \approx 1.1 \text{ mm} (0.035 \approx 0.043 \text{ m})$ | |
| Valve springs | 0.3 ~ 1.1 mm (0.035 ~ 0.043 m) | |
| Inner springs | | |
| Free length | | |
| Intake | 39.65 mm (1.56 in) | 37.45 mm |
| | | (1.47 in) |
| Exhaust | 39.65 mm (1.56 in) | 37.45 mm |
| | | (1.47 in) |
| Installed length (valve closed) | | |
| Intake | 31.8 mm (1.25 in) | |
| Exhaust | 31.8 mm (1.25 in) | |
| Compressed spring force (installed) | | |
| Intake | $61.7 \sim 72.5 \text{ N}$ | |
| Exhaust | $(0.29 \sim 7.39 \text{ kgl}, 13.9 \sim 10.3 \text{ lb})$ | |
| Exhaust | $(6.29 \sim 7.39 \text{ kgf} 13.9 \sim 16.3 \text{ lb})$ | |
| Spring tilt | (0.23 × 7.05 kg), 10.5 × 10.5 b) | |
| * | | |
| | | |
| | | |
| | | |
| | | |
| /////////////////////////////////////// | | |
| Intake | | 2.5° /1.7 mm |
| | | (2.5° /0.07 in) |
| Exhaust | | 2.5° /1.7 mm |
| | | (2.5° /0.07 in) |
| Winding direction (top view) | | |
| | Counterclockwise | |
| Exhaust | Counterclockwise | |
| | | |
| | | |
| | ▲ / | |

ENGINE SPECIFICATIONS SPEC



| Item | Standard | Limit |
|-------------------------------------|--|---------------------------------|
| Outer springs | | |
| Free length | | |
| Intake | 41.1 mm (1.62 in) | 38.9 mm |
| | | (1.53 in) |
| Exhaust | 41.1 mm (1.62 in) | 38.9 mm |
| | | (1.53 in) |
| Installed length (valve closed) | | |
| Intake | 33.8 mm (1.33 in) | |
| Exhaust | 33.8 mm (1.33 in) | |
| Compressed spring force (installed) | | |
| Intake | 130.4 ~ 154.0 N | |
| | (13.3 ~ 15.7 kgf, 29.3 ~ 34.6 lb) | |
| Exhaust | 130.4 ~ 154.0 N | |
| 0 | (13.3 ~ 15.7 kgt, 29.3 ~ 34.6 lb) | |
| Spring tilt | | |
| | | |
| Intake | | 2.5° /1.8 mm |
| Fxbaust | | (2.5 / 0.07 m) 2.5° /1.8 mm |
| Exhlust | | $(2.5^{\circ}/0.07 \text{ in})$ |
| Winding direction (top view) | | |
| Intake | Clockwise | |
| Exhaust | Clockwise | |
| | | |
| | | |
| Cylinders | | |
| Cylinder arrangement | V-type 4-cylinder | |
| Bore \times stroke | 76×66 mm (2.99 \times 2.60 in) | |
| Compression ratio | 10.5 : 1 | |
| Bore | 75.967 ~ 76.016 mm (2.9908 ~ 2.9927 in) | |
| Max. taper | | 0.05 mm |
| | | (0.002 in) |
| Max. out-of-round | | 0.05 mm |
| | | (0.002 in) |



| Item | Standard | Limit |
|--|--|------------------------------|
| Pistons | | |
| Piston-to-cylinder clearance | 0.055 ~ 0.075 mm (0.0022 ~ 0.0030 in) | 0.15 mm (0.0059 in) |
| Diameter D | 75.905 ~ 75.955 mm (2.9884 ~ 2.9903 in) | |
| | | |
| Height H Biston nin horo (in the niston) | 6.2 mm (0.24 in) | |
| Diameter Offset Piston pins | 19.004 ~ 19.015 mm (0.7482 ~ 0.7486 in) 0 mm (0 in) | |
| Outside diameter Piston-pin-to-piston-pin-bore clear- ance Piston rings Top ring | 18.991 ~ 19.000 mm (0.7477 ~ 0.7480 in) 0.004 ~ 0.024 mm (0.00016 ~ 0.00094 in) | 0.072 mm (0.0028 in) |
| | | |
| Ring type Dimensions (B × T) End gap (installed) | Barrel 1.0 × 3.1 mm (0.04 × 0.12 in) 0.35 ~ 0.50 mm (0.01 ~ 0.02 in) | 0.75 mm (0 03 in) |
| Ring side clearance | 0.03 ~ 0.07 mm (0.0012 ~ 0.0028 in) | 0.12 mm (0.0047 in) |
| 2nd ring | | (0.00 |
| Ring type Dimensions (B × T) End gap (installed) | Taper 1.2 × 3.1 mm (0.05 × 0.12 in) 0.35 ~ 0.50 mm (0.01 ~ 0.02 in) | 0.75 mm (0.03 in) |
| Ring side clearance | 0.02 ~ 0.06 mm (0.0008 ~ 0.0024 in) | 0.12 mm (0.0047 in) |
| Oil ring | | 、 / |
| | | |
| Dimensions ($B \times T$) | $2.5 \times 3.1 \text{ mm} (0.10 \times 0.12 \text{ in})$ | |
| Enu gap (installed) | 0.∠ ~ 0.0 mm (0.01 ~ 0.03 m) | |



| Item | Standard | Limit |
|--|--|-------------------------|
| Connecting rods | | |
| Crankshaft-pin-to-big-end-bearing clearance | 0.021 ~ 0.039 mm (0.0008 ~ 0.0015 in) | |
| Bearing color code | 1 = Blue 2 = Black 3 = Brown 4 = Green 5 = Yellow 6 = Pink | |
| Crankshaft | | |
| | | |
| Width A | 83.92 ~ 83.97 mm (3.30 ~ 3.31 in) | |
| Width B | 242.72 ~ 243.17 mm (9.56 ~ 9.57 in) | |
| Max. runout C | | 0.03 mm |
| Big end side clearance D Big end radial clearance Crankshaft-journal-to-crankshaft- journal-bearing clearance Bearing color code | $0.320 \sim 0.924 \text{ mm} (0.013 \sim 0.036 \text{ in})$ $0.021 \sim 0.045 \text{ mm} (0.0008 \sim 0.0018 \text{ in})$ $0.040 \sim 0.058 \text{ mm} (0.0016 \sim 0.0023 \text{ in})$ 1 = Blue 2 = Black 3 = Brown 4 = Green | (0.0012 in) |
| Objects | 5 = Yellow 6 = Pink 7 = Red | |
| | Mat multiple dies | |
| Clutch type | line disc | |
| Clutch release method | Left hand exerction | |
| | | |
| Thickness | 20.21 mm (0.11.0.12 in) | 2.9 mm |
| THICKNESS | $2.9 \sim 3.1$ mm (0.11 ~ 0.12 m) | 2.0 1111 (0.110 in) |
| Plate quantity | 8 | (0.110 m) |
| Clutch plates | 0 | |
| Thickness | $22 \sim 24$ mm (0.09 ~ 0.09 in) | |
| Plate quantity | 7 | |
| Max. warpage | | 0.2 mm |
| | | (0.008 in) |
| Clutch springs | | |
| Free length | 7 mm (0.28 in) | |
| Spring quantity | 1 PCS | |
| Minimum length | | 6.5 mm |
| Clutch housing thrust clearance | 0.10 = 0.27 mm (0.004 = 0.011 in) | (U.20 III) |
| Clutch housing thrust clearance | $0.10 \sim 0.27$ mm (0.004 ~ 0.011 m) | |
| Push rod bonding limit | | 0.5 mm |
| | | (0.02 in) |



| Item | Standard | Limit |
|-----------------------------------|---|------------|
| Transmission | | |
| Transmission type | Constant mesh, 5-speed | |
| Primary reduction system | Spur gear | |
| Primary reduction ratio | 87/49 (1.775) | |
| Secondary reduction system | Shaft drive | |
| Secondary reduction ratio | 21/27 × 33/09 (2.851) | |
| Operation | Left-foot operation | |
| Gear ratios | | |
| 1st gear | 43/17 (2.529) | |
| 2nd gear | 39/22 (1.772) | |
| 3rd gear | 31/23 (1.347) | |
| 4th gear | 28/26 (1.076) | |
| 5th gear | 26/28 (0.928) | |
| Max. main axle runout | | 0.08 mm |
| | | (0.003 in) |
| Max. drive axle runout | | 0.08 mm |
| | | (0.003 in) |
| Shifting mechanism | | |
| Shift mechanism type | Guide bar | |
| Max. shift fork guide bar bending | | 0.025 mm |
| | | (0.001 in) |
| Installed shift rod length | 367.8 mm (14.5 in) | |
| Air filter type | Dry element | |
| Fuel pump | | |
| Pump type | Electrical | |
| Model (manufacturer) | UCV5A (MITSUBISHI) | |
| Consumption amperage <max></max> | 1 A | |
| Output pressure | 18 kPa (0.18 kgf/cm ² , 2.6 psi) | |
ENGINE SPECIFICATIONS



| Item | Standard | Limit |
|---|-----------------------------|-----------|
| Carburetors | | |
| Model (manufacturer) $	imes$ quantity | BDS35 (MIKUNI) $	imes$ 4 | |
| Throttle cable free play (at the flange | 3 ~ 5 mm (0.12 ~ 0.20 in) | |
| of the throttle grip) | | |
| ID mark | 1FK 02 | |
| | 2WF 02 (for California) | |
| Main jet | #152.5 | |
| Main air jet | 2.0 | |
| Jet needle | 5EZ43-1 | |
| | 5EZ50-1 (for California) | |
| Needle jet | Y-0 | |
| Pilot air jet 1 | #90 | |
| | #100 (for California) | |
| Pilot air jet 2 | #170 | |
| Pilot outlet | 0.9 | |
| Pilot jet | #37.5 | |
| Bypass 1 | 0.8 | |
| Bypass 2 | 0.8 | |
| Bypass 3 | 0.9 | |
| Valve seat size | 1.5 | |
| Starter jet 1 | #45 | |
| Starter jet 2 | 0.8 | |
| Throttle valve size | #125 | |
| | #130 (for California) | |
| Fuel level (below the line on the vac- | 15 ~ 17 mm (0.59 ~ 0.67 in) | |
| uum chamber) | | |
| Shaft drive | | |
| Middle gear backlash | 0.05 ~ 0.12 mm (0 in) | 0.3 mm |
| | | (0.01 in) |
| Final gear backlash | 0.1 ~ 0.2 mm (0 ~ 0.01 in) | 0.3 mm |
| | | (0.01 in) |

CHASSIS SPECIFICATIONS



CHASSIS SPECIFICATIONS

| Item | Standard | Limit | |
|----------------------------|---------------------------------|-----------|--|
| Frame | | | |
| Frame type | Double cradle | | |
| Caster angle | 29° | | |
| Trail | 119 mm (4.69 in) | | |
| Front wheel | | | |
| Wheel type | Cast wheel | | |
| Rim | | | |
| Size | 18 × MT2.15 | | |
| Material | Aluminum | | |
| Wheel travel | 140 mm (5.51 in) | | |
| Wheel runout | | | |
| Max. radial wheel runout | | 1 mm | |
| | | (0.04 in) | |
| Max. lateral wheel runout | | 0.5 mm | |
| | | (0.02 in) | |
| Rear wheel | | | |
| Wheel type | Cast wheel | | |
| Rim | | | |
| Size | 15M/C × MT3.50 | | |
| Material | Aluminum | | |
| Wheel travel | 100 mm (3.94 in) | | |
| Wheel runout | | | |
| Max. radial wheel runout | | 1 mm | |
| | | (0.04 in) | |
| Max. lateral wheel runout | | 0.5 mm | |
| | | (0.02 in) | |
| Front tire | | | |
| Tire type | Tubeless | | |
| Size | 110/90-18 (61V) | | |
| Model (manufacturer) | G525AW/F20 (BRIDGESTONE/DUNLOP) | | |
| Tire pressure (cold) | | | |
| 0 ~ 90 kg (0 ~ 198 lb) | 225 kPa (2.25 kg/cm², 33 psi) | | |
| 90 ~ 216 kg (198 ~ 476 lb) | 225 kPa (2.25 kg/cm², 33 psi) | | |
| High-speed riding | 225 kPa (2.25 kg/cm², 33 psi) | | |
| Min. tire tread depth | | 1.0 mm | |
| | | (0.04 in) | |

CHASSIS SPECIFICATIONS



| Item | Standard | Limit |
|--------------------------------------|---|------------|
| Rear tire | | |
| Tire type | Tubeless | |
| Size | 150/90-15M/C (74V) | |
| Model (manufacturer) | G526BW/K525 (BRIDGESTONE/DUNLOP) | |
| Tire pressure (cold) | | |
| 0 ~ 90 kg (0 ~ 198 lb) | 225 kPa (2.25 kg/cm ² , 33 psi) | |
| 90 ~ 197 kg (198 ~ 434 lb) | 250 kPa (2.5 kg/cm ² , 36 psi) | |
| High-speed riding | $250 \text{ kPa} (2.5 \text{ kg/cm}^2, 36 \text{ psi})$ | |
| Min_tire tread depth | | 1.0 mm |
| | | (0.04 in) |
| Front brakes | | (/ |
| Brake type | Dual-disc brake | |
| Operation | Right-hand operation | |
| Brake lever free play (at lever end) | 2 ~ 5 mm (0.08 ~ 0.20 in) | |
| Recommended fluid | DOT 4 | |
| Brake discs | | |
| Diameter $	imes$ thickness | 298 × 5 mm (11.73 ~ 0.20 in) | |
| Min. thickness | | 4.5 mm |
| | | (0.18 in) |
| Max. deflection | | 0.3 mm |
| | | (0.012 in) |
| Brake pad lining thickness | 5 mm (0.2 in) | 0.5 mm |
| | | (0.02 in) |
| Master cylinder inside diameter | 15.87 mm (0.62 in) | |
| Caliper cylinder inside diameter | 33.96 mm (1.34 in) and 30.23 mm (1.19 in) | |
| Rear brake | | |
| Brake type | Single-disc brake | |
| Operation | Right-foot operation | |
| Brake pedal position | 20 mm (0.79 in) | |
| Recommended fluid | DOT 4 | |
| Brake discs | | |
| Diameter \times thickness | 282 × 7.5 mm (11.1 × 0.3 in) | |
| Min. thickness | | 7.0 mm |
| | | (0.28 in) |
| Max. deflection | | 0.3 mm |
| | | (0.012 in) |
| Brake pad lining thickness | 5.1 mm (0.2 in) | 0.5 mm |
| | | (0.02 in) |
| Master cylinder inside diameter | 12.7 mm (0.5 in) | · · · · |
| Caliper cylinder inside diameter | 42.85 mm (1.69 in) | |

CHASSIS SPECIFICATIONS



| Item | Standard | Limit |
|--|---|------------------------|
| Front suspension | | |
| Suspension type | Telescopic fork | |
| Front fork type | Coil air spring/oil damper | |
| Front fork travel | 140 mm (5.51 in) | |
| Spring | | |
| Free length | 386.5 mm (15.22 in) | 381.5 mm (15.02 in) |
| Spacer length | 245 mm (9.65 in) | |
| Installed length | 242.4 mm (9.54 in) | |
| Spring rate (K1) | 3.7 N/mm (0.38 kgf/mm, 21.1 lb/in) | |
| Spring stroke (K1) | 0 ~ 78 mm (0 ~ 3.07 in) | |
| Spring rate (K2) | 4.9 N/mm (0.5 kgf/mm, 28.0 lb/in) | |
| Spring stroke (K2) | 78 ~ 140 mm (3.07 ~ 5.51 in) | |
| Optional spring available | No | |
| Standard enclosed gas/air pressure | 40 kPa (0.4 kgf/cm ² , 5.8 psi) | |
| Fork oil | Yamaha fork oil 10 WT | |
| Recommended oil | Fork oil 10 W or equivalent | |
| Quantity (each front fork leg) | 621 cm ³ (21.9 lmp oz, 21.0 US oz) | |
| Level (from the top of the inner | 123 mm (4.84 in) | |
| tube, with the inner tube fully com- | | |
| pressed, and without the fork | | |
| spring) | | |
| Steering | | |
| Steering bearing type | Taper roller bearing | |
| Rear suspension | | |
| Suspension type | Swingarm | |
| Rear shock absorber assembly type | Coil spring/oil damper | |
| Rear shock absorber assembly travel | 85 mm (3.35 in) | |
| Spring | | |
| Free length | 245.5 mm (9.67 in) | 240.5 mm (9.47 in) |
| Installed length | 217.4 mm (8.56 in) | |
| Spring rate (K1) | 19.1 N/mm (1.95 kgf/mm, 109.1 lb/in) | |
| Spring stroke (K1) | 0 ~ 50 mm (0 ~ 1.97 in) | |
| Spring rate (K2) | 26.5 N/mm (2.7 kgf/mm, 151.3 lb/in) | |
| Spring stroke (K2) | 50 ~ 85 mm (1.97 ~ 3.35 in) | |
| Optional spring available | No | |
| Swingarm | | |
| Free play (at the end of the swingarm) | | |
| Radial | | 0 mm (0 in) |
| Axial | | 0 mm (0 in) |



ELECTRICAL SPECIFICATIONS

| Item | Standard | Limit |
|---|--|-------|
| System voltage | 12 V | |
| Ignition system | | |
| Ignition system type | Transistorized coil ignition (digital) | |
| Ignition timing | 3° BTDC at 1,000 r/min | |
| Advanced timing | 33° BTDC at 9,000 r/min | |
| | 43° BTDC at 9,000 r/min (for California) | |
| Advancer type | Vacuum and electrical | |
| Pickup coil resistance/color | 80.8 ~ 121.2 Ω/O–B | |
| Transistorized coil ignition unit model | TID14-93C (HITACHI) | |
| (manufacturer) | | |
| Ignition coils | | |
| Model (manufacturer) | CM11-61 (HITACHI) | |
| Minimum ignition spark gap | 6 mm (0.24 in) | |
| Primary coil resistance | 2.43 ~ 2.97 Ω | |
| Secondary coil resistance | 10.56 ~ 15.84 kΩ | |
| Spark plug caps | | |
| Material | Resin | |
| Resistance | 10 kΩ | |
| Charging system | | |
| System type | AC magneto | |
| Model (manufacturer) | GP9415 (KOKUSAN) | |
| Nominal output | 14 V/22.5 A at 5,000 r/min | |
| Stator coil resistance | 0.33 ~ 0.45 Ω | |
| Voltage regulator | | |
| Regulator type | Semiconductor, short circuit | |
| Model | SH662-12 | |
| No-load regulated voltage | 14.1 ~ 14.9 V | |
| Rectifier | | |
| Model | SH662-12 | |
| Rectifier capacity | 18 A | |
| Withstand voltage | 200 V | |
| Battery | | |
| Battery type | YB16AL-A2 | |
| Battery voltage/capacity | 12 V/16 AH | |
| Specific gravity | 1.280 | |
| Headlight type | Halogen bulb | |
| Indicator light type $	imes$ quantity | Bulb type $\times 3$ | |
| Bulbs (voltage/wattage × quantity) | | |
| Headlight | 12 V 60 W/55 W × 1 | |
| Tail/brake light | 12 V 27 W/8 W × 2 | |
| Front turn signal light | 12 V 21 W × 2 | |
| Rear turn signal light | 12 V 27 W × 2 | |
| License plate light | 12 V 5 W × 2 | |
| Meter light | 14 V 3 W × 2 | |

ELECTRICAL SPECIFICATIONS



| Item | Standard | Limit | | | |
|---------------------------------------|---|-----------|--|--|--|
| Electric starting system | | | | | |
| System type | Constant mesh | | | | |
| Starter motor | | | | | |
| Model (manufacturer) | SM-13 (MITSUBA) | | | | |
| Power output | 0.65 kW | | | | |
| Brushes | | | | | |
| Overall length | 10 mm (0.40 in) | 5 mm | | | |
| | | (0.20 in) | | | |
| Spring force | 8.82 N (899 af. 31.8 oz) | | | | |
| Commutator resistance | $0.025 \sim 0.035 \Omega$ | | | | |
| Commutator diameter | 28 mm (1.1 in) | 27 mm | | | |
| | 20 (| (1.06 in) | | | |
| Mica undercut | 0.7 mm (0.03 in) | | | | |
| Starter relay | | | | | |
| Model (manufacturer) | MS5D-341 (HITACHI) | | | | |
| Amperage | 100 A | | | | |
| Coil resistance | 3.87 ~ 4.73 Ω | | | | |
| Horn | | | | | |
| Horn type | Plane | | | | |
| Model (manufacturer) × quantity | YF-12 (NIKKO) × 1 | | | | |
| Max. amperage | 3 A | | | | |
| Turn signal relay | | | | | |
| Relay type | Semi-transistor | | | | |
| Model (manufacturer) | FB257H (DENSO) | | | | |
| Self-cancelling device built-in | Yes | | | | |
| Turn signal blinking frequency | 75 ~ 95 cvcles/min. | | | | |
| Wattage | $27 \text{ W} \times 2 + 3.4 \text{ W}$ | | | | |
| Oil level switch model (manufacturer) | 1FK (DENSO) | | | | |
| Fuel sender | | | | | |
| Model (manufacturer) | 1FK (NIPPON SEIKI) | | | | |
| Resistance | 700 ~ 1.100 Ω at 25 °C (77 °F) | | | | |
| Sidestand relay | , | | | | |
| Model | 1RL-92 | | | | |
| Coil resistance | 72 ~ 88 Ω | | | | |
| Fuel pump maximum amperage | 1.2 A | | | | |
| Fuel pump relay model (manufac- | G8D-04Y (OMRON) | | | | |
| turer) | | | | | |
| Radiator fan model (manufacturer) | 4XV (TOYO RADIATOR) | | | | |
| Thermo switch model (manufac- | 3LN (NIPPON THERMOSTAT) | | | | |
| turer) | | | | | |
| Temperature sender | | | | | |
| Model (manufacturer) | 11H (NIPPON SEIKI) | | | | |
| Resistance | 153.9 Ω at 50 °C (122 °F) | | | | |
| | 47.5 ~ 56.8 Ω at 80 °C (176 °F) | | | | |
| | 26.2 ~ 29.3 Ω at 100 °C (212 °F) | | | | |

ELECTRICAL SPECIFICATIONS



| Item | Standard | Limit |
|-----------------------------------|----------------------|-------|
| Fuses (amperage $	imes$ quantity) | | |
| Main fuse | 30 A × 1 | |
| Headlight fuse | 15 A × 1 | |
| Signaling system fuse | 10 A × 1 | |
| Ignition fuse | 10 A × 1 | |
| Radiator fan fuse | 10 A × 1 | |
| Reserve fuse | 30 A, 15 A, 10 A × 1 | |

All specification data in this manual are listed in SI and METRIC UNITS.

Use this table to convert METRIC unit data to IMPERIAL unit data.

Ex.

| METRIC | MULTIPLIER | IMPERIAL |
|--------|------------|----------|
| ** mm | 0.03937 | ** in |
| 2 mm | 0.03937 | 0.08 in |

CONVERSION TABLE

| METRIC TO IMPERIAL | | | | | |
|--------------------|-----------------------|------------|---------------------------|--|--|
| Metric unit | | Multiplier | Imperial unit | | |
| Tighton- | m∙kg | 7.233 | ft·lb | | |
| ing torque | m∙kg | 86.794 | in∙lb | | |
| ing torquo | cm⋅kg | 0.0723 | ft·lb | | |
| | cm⋅kg | 0.8679 | in∙lb | | |
| Weight | kg | 2.205 | lb | | |
| weigin | g | 0.03527 | oz | | |
| Speed | km/hr | 0.6214 | mph | | |
| | km | 0.6214 | mi | | |
| | m | 3.281 | ft | | |
| Distance | m | 1.094 | yd | | |
| | cm | 0.3937 | in | | |
| | mm | 0.03937 | in | | |
| | cc (cm ³) | 0.03527 | oz (IMP lip.) | | |
| Volume/ | cc (cm ³) | 0.06102 | cu-in | | |
| Capacity | It (liter) | 0.8799 | qt (IMP liq.) | | |
| | It (liter) | 0.2199 | gal (IMP liq.) | | |
| | kg/mm | 55.997 | lb/in | | |
| Misc | kg/cm ² | 14.2234 | psi (lb/in ²) | | |
| 101130. | Centigrade (°C) | 9/5+32 | Fahrenheit (°F) | | |

GENERAL TIGHTENING TORQUE SPECIFICATIONS

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided for each chapter of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross pattern and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.



A: Width across flats B: Thread diameter

| A (put) | B (bolt) | General tightening torques | | | | |
|------------|-------------|-------------------------------|------|-------|--|--|
| (nut) | (bolt) | Nm | m•kg | ft∙lb | | |
| 10 mm | 6 mm | 6 | 0.6 | 4.3 | | |
| 12 mm | 8 mm | 15 | 1.5 | 11 | | |
| 14 mm | 10 mm | 30 | 3.0 | 22 | | |
| 17 mm | 12 mm | 55 | 5.5 | 40 | | |
| 19 mm | 14 mm | 85 | 8.5 | 61 | | |
| 22 mm | 16 mm | 130 | 13.0 | 94 | | |



TIGHTENING TORQUES ENGINE TIGHTENING TORQUES

| Part to be tightened | Part name | Thread | Q'tv | Tightening torque | | | Remarks |
|--------------------------------------|------------|--------|------|-------------------|-------|-------|---------|
| Fait to be tightened | Fait name | size | Qiy | Nm | m∙kgf | ft∙lb | Remains |
| Camshaft caps | Bolt | M6 | 32 | 10 | 1.0 | 7.2 | |
| Blind plug | Plug | M20 | 6 | 43 | 4.3 | 31 | -6 |
| Cylinder head (exhaust pipe) | Stud bolt | M8 | 8 | 15 | 1.5 | 11 | |
| Spark plugs | | M12 | 4 | 18 | 1.8 | 13 | |
| Cylinder head | Nut | M10 | 16 | 43 | 4.3 | 31 | |
| Cylinder head cover | Bolt | M6 | 16 | 10 | 1.0 | 7.2 | |
| Connecting rod caps | Nut | M8 | 8 | 36 | 3.6 | 25 | |
| AC magneto | Bolt | M12 | 1 | 130 | 13.0 | 94 | _ |
| Camshaft sprocket | Bolt | M7 | 8 | 24 | 2.4 | 17 | |
| Timing chain damper bracket | Bolt | M8 | 1 | 24 | 2.4 | 17 | -6 |
| Timing chain tensioner | Bolt | M6 | 4 | 12 | 1.2 | 8.7 | - |
| Cap bolt (tensioner) | Bolt | M16 | 2 | 20 | 2.0 | 14 | |
| Water pump cover | Bolt | M6 | 5 | 10 | 1.0 | 7.2 | |
| Water pump drain plug | Plug | M14 | 1 | 43 | 4.3 | 31 | |
| Water pump housing | Bolt | M6 | 4 | 10 | 1.0 | 7.2 | |
| Thermostat assembly | Bolt | M6 | 2 | 10 | 1.0 | 7.2 | |
| Thermostat housing cover | Bolt | M6 | 2 | 7 | 0.7 | 5.1 | |
| Crankcase breather assembly | Bolt | M6 | 6 | 10 | 1.0 | 7.2 | |
| Crankcase breather cover | Bolt | M6 | 4 | 10 | 1.0 | 7.2 | |
| Radiator | Bolt | M6 | 4 | 7 | 0.7 | 5.1 | |
| Radiator side cover | Screw | M6 | 4 | 4 | 0.4 | 2.9 | |
| Coolant drain cock | Screw | M4 | 1 | 3 | 0.3 | 2.2 | |
| Radiator cap pipe | Screw | M6 | 3 | 7 | 0.7 | 5.1 | |
| Conduit | Screw | M6 | 3 | 7 | 0.7 | 5.1 | |
| Oil strainer housing | Screw | M6 | 3 | 7 | 0.7 | 5.1 | |
| Oil pump gear housing | Screw | M6 | 4 | 7 | 0.7 | 5.1 | |
| Oil gallery pipe | Bolt | M6 | 2 | 12 | 1.2 | 8.7 | |
| Engine oil drain bolt | Plug | M14 | 1 | 43 | 4.3 | 31 | |
| Oil pan | Bolt | M6 | 12 | 10 | 1.0 | 7.2 | |
| Oil baffle plate | Bolt | M6 | 2 | 12 | 1.2 | 8.7 | |
| Oil delivery pipe (head) | Union bolt | M8 | 2 | 18 | 1.8 | 13 | |
| Oil delivery pipe (cover) | Union bolt | M10 | 1 | 20 | 2.0 | 14 | |
| Oil pipe | Union bolt | M8 | 1 | 18 | 1.8 | 13 | |
| Oil pump housing cover 1 | Screw | M6 | 2 | 7 | 0.7 | 5.1 | |
| Oil pump housing cover 1 | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | |
| Stay 1 | Bolt | M6 | 1 | 12 | 1.2 | 8.7 | |
| Oil filter | | M20 | 1 | 17 | 1.7 | 12 | |
| Carburetor joint | Bolt | M6 | 8 | 10 | 1.0 | 7.2 | |
| Fuel pump | Bolt | M6 | 2 | 12 | 1.2 | 8.7 | |
| Exhaust pipe joint clamp (#1 and #3) | Bolt | M6 | 2 | 7 | 0.7 | 5.1 | |

2



| Dort to be tightened | Dart name Thread | | 0.4 | Tightening torque | | | Domorko |
|--|------------------|------|------|-------------------|-------|-------|---------------------|
| Part to be tightened | Part name | size | Qʻty | Nm | m∙kgf | ft∙lb | Remarks |
| Exhaust pipe joint clamp (#2 and #4) | Bolt | M8 | 1 | 20 | 2.0 | 14 | |
| Exhaust pipe clamp bolt (exhaust chamber) | Bolt | M8 | 4 | 20 | 2.0 | 14 | |
| Exhaust pipes | Nut | M8 | 8 | 20 | 2.0 | 14 | |
| Exhaust pipe cover | Bolt | M6 | 3 | 7 | 0.7 | 5.1 | |
| Exhaust pipe cover | Bolt | M5 | 6 | 6 | 0.6 | 4.3 | |
| Muffler bracket | Bolt | M6 | 2 | 10 | 1.0 | 7.2 | |
| Muffler | Bolt | M10 | 3 | 25 | 2.5 | 18 | |
| Cylinder (cylinder head) | Stud bolt | M10 | 16 | 9 | 0.9 | 6.5 | |
| Main gallery blind plug | Plug | M20 | 1 | 12 | 1.2 | 8.7 | |
| Crankcase | Bolt | M6 | 10 | 12 | 1.2 | 8.7 | |
| Crankcase | Bolt | M8 | 18 | 24 | 2.4 | 17 | |
| Crankcase | Bolt | M10 | 8 | 40 | 4.0 | 29 | |
| Middle gear bearing retainer | Screw | M8 | 4 | 25 | 2.5 | 18 | - 6 |
| Main axle bearing retainer | Screw | M6 | 3 | 7 | 0.7 | 5.1 | - 6 |
| Wire lead clamp | Screw | M6 | 2 | 7 | 0.7 | 5.1 | |
| Generator cover | Bolt | M6 | 11 | 10 | 1.0 | 7.2 | |
| Crankcase cover plate | Screw | M6 | 2 | 7 | 0.7 | 5.1 | |
| Middle gear case cover | Bolt | M6 | 6 | 10 | 1.0 | 7.2 | |
| Clutch cover | Bolt | M6 | 9 | 10 | 1.0 | 7.2 | |
| Oil baffle plate | Screw | M6 | 4 | 7 | 0.7 | 5.1 | - 6 |
| Oil drain plug (crankcase) | Bolt | M8 | 1 | 38 | 3.8 | 27 | |
| Starter clutch | Bolt | M8 | 3 | 24 | 2.4 | 17 | |
| Clutch spring plate | Bolt | M6 | 6 | 8 | 0.8 | 5.8 | |
| Clutch boss | Nut | M20 | 1 | 70 | 7.0 | 50 | |
| Clutch release cylinder | Bolt | M6 | 2 | 12 | 1.2 | 8.7 | |
| Air bleed screw | Screw | M8 | 1 | 6 | 0.6 | 4.3 | |
| Clutch pipe | Union bolt | M10 | 1 | 25 | 2.5 | 18 | |
| Middle drive pinion gear | Nut | M44 | 1 | 110 | 11.0 | 80 | - 6 |
| Middle driven pinion gear | Nut | M16 | 1 | 90 | 9.0 | 65 | -0 |
| Middle driven gear housing | Bolt | M8 | 3 | 30 | 3.0 | 22 | - |
| Shift cam segment | Screw | M6 | 1 | 12 | 1.2 | 8.7 | - 6 |
| Shift cam plate | Screw | M5 | 1 | 4 | 0.4 | 2.9 | -6 |
| Shift cam retainer | Screw | M6 | 3 | 7 | 0.7 | 5.1 | -6 |
| Shift shaft spring stopper | Bolt | M8 | 1 | 22 | 2.2 | 16 | |
| Stopper lever | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | -0 |
| Shift arm | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | - |
| Shift rod locknut | Nut | M6 | 1 | 10 | 1.0 | 7.2 | |
| Shift rod locknut | Nut | M6 | 1 | 10 | 1.0 | 7.2 | Left hand thread |
| Final gear case (rear arm) | Stud bolt | M10 | 4 | 18 | 1.8 | 13 | |
| Final gear case (bearing housing) | Stud bolt | M8 | 6 | 9 | 0.9 | 6.5 | |
| Coupling gear | Nut | M16 | 1 | 130 | 13.0 | 94 | |

SPEC U

| Port to be tightened | Port nomo | Thread | O'tu | Tight | ening to | Pomorko | | |
|-------------------------------|-----------|--------|------|-------|----------|---------|-----|--|
| Fait to be tightened | Fait name | size | Qiy | Nm | m∙kgf | ft∙lb | | |
| Bearing housing | Nut | M8 | 6 | 23 | 2.3 | 17 | | |
| Bearing housing | Bolt | M10 | 2 | 40 | 4.0 | 29 | | |
| Drain plug (final gear case) | Plug | M14 | 1 | 23 | 2.3 | 17 | | |
| Filler plug (final gear case) | Plug | M14 | 1 | 23 | 2.3 | 17 | | |
| Stator coil | Screw | M6 | 3 | 7 | 0.7 | 5.1 | - 1 | |
| Pickup coil | Screw | M6 | 4 | 7 | 0.7 | 5.1 | - 1 | |
| Starter motor | Bolt | M6 | 2 | 10 | 1.0 | 7.2 | | |
| Neutral switch | Screw | M5 | 3 | 4 | 0.4 | 2.9 | | |
| Oil level switch | Bolt | M6 | 2 | 10 | 1.0 | 7.2 | | |
| Thermo unit | | M10 | 1 | 15 | 1.5 | 11 | | |
| Thermo switch | | M16 | 1 | 15 | 1.5 | 11 | | |

Crankcase tightening sequence:





CHASSIS TIGHTENING TORQUES

| Part to be tightened | | Tight | Tightening torque | | Pomarks | |
|---|------|-------|-------------------|-------|----------|--|
| Fait to be lightened | size | Nm | m∙kgf | ft∙lb | Remarks | |
| Upper bracket and inner tube | M8 | 23 | 2.3 | 17 | | |
| Upper bracket and steering shaft | M22 | 110 | 11.0 | 80 | | |
| Handlebar holder (lower) and handlebar holder | MO | 20 | 2.0 | 11 | | |
| (upper) | IVIO | 20 | 2.0 | 14 | | |
| Ring nut (steering shaft) | M25 | 3 | 0.3 | 2.2 | See NOTE | |
| Brake hose joint and lower bracket | M6 | 7 | 0.7 | 5.1 | | |
| Front master cylinder cap (brake and clutch) | M4 | 2 | 0.2 | 1.4 | | |
| Handlebar holder (lower) | M10 | 40 | 4.0 | 29 | | |
| Front master cylinder (brake and clutch) | M6 | 9 | 0.9 | 6.5 | | |
| Union bolt (brake hose) | M10 | 30 | 3.0 | 22 | | |
| Clutch hose and clutch pipe | M10 | 19 | 1.9 | 13 | | |
| Engine mounting: | | | | | | |
| Mounting bolt (engine and front frame) | M10 | 42 | 4.2 | 30 | | |
| Mounting bolt (engine and rear frame) | M12 | 70 | 7.0 | 50 | | |
| Engine bracket and frame | M8 | 16 | 1.6 | 11 | | |
| Frame and down tube | M10 | 45 | 4.5 | 32 | | |
| Frame and rear cross bar | M8 | 23 | 2.3 | 17 | | |
| Swingarm pivot shaft (left) | M25 | 100 | 10.0 | 72 | | |
| Swingarm pivot shaft (right) | M25 | 7 | 0.7 | 5.1 | | |
| Swingarm pivot shaft locknut (right) | M25 | 100 | 10.0 | 72 | | |
| Rear shock absorber and frame | M8 | 20 | 2.0 | 14 | | |
| Rear shock absorber and swingarm | M10 | 35 | 3.5 | 25 | | |
| Rear shock absorber and final gear case | M10 | 30 | 3.0 | 22 | | |
| Swingarm and final gear case | M10 | 42 | 4.2 | 30 | | |
| Fuel sender and fuel tank | M6 | 7 | 0.7 | 5.1 | | |
| Side cover and frame | M6 | 7 | 0.7 | 5.1 | | |
| Sidestand bolt and nut | M10 | 40 | 4.0 | 29 | | |
| Left footrest bracket and frame | M8 | 26 | 2.6 | 19 | | |
| Left footrest bracket and rear frame pipe | M8 | 26 | 2.6 | 19 | | |
| Rear frame pipe and frame | M8 | 30 | 3.0 | 22 | | |
| Right footrest bracket and frame | M8 | 23 | 2.3 | 17 | | |
| Union bolt (rear brake hose) | M10 | 30 | 3.0 | 22 | | |
| Front fender brace | M6 | 9 | 0.9 | 6.5 | | |
| Front wheel axle | M14 | 58 | 5.8 | 42 | | |
| Front wheel axle pinch bolt | M8 | 20 | 2.0 | 14 | | |
| Rear wheel axle nut | M18 | 150 | 15.0 | 110 | | |
| Front brake caliper | M10 | 40 | 4.0 | 29 | | |
| Rear brake caliper | M10 | 40 | 4.0 | 29 | | |
| Brake disc and wheel | M8 | 23 | 2.3 | 17 | - 6 | |
| Caliper bleed screw | M8 | 6 | 0.6 | 4.3 | | |



NOTE: .

1.First, tighten the ring nut approximately 52 Nm (5.2 m • kg, 37 ft • lb) by using the torque wrench, then loosen the ring nut completely.

2.Retighten the ring nut to specification.



LUBRICATION POINTS AND LUBRICANT TYPES ENGINE

| Lubrication Point | Symbol |
|---|--------|
| Oil seal lips | |
| O-ring | |
| Bearing | - |
| Connecting rod bolt/nut | |
| Connecting rod small end and big end | |
| Crankshaft pin | |
| Crankshaft journal/big end | |
| Balancer shaft journal | |
| Piston surface | |
| Piston pin | |
| Camshaft cam lobe/journal | |
| Timing chain tensioner | |
| Valve stem (IN, EX) | |
| Valve stem end (IN, EX) | |
| Valve lifter | |
| Water pump impeller shaft | |
| Oil pump rotor (inner/outer), housing | |
| Oil strainer assembly | |
| Idle gear surface | |
| Starter idle gear | |
| Starter idle gear shaft | |
| Starter clutch (outer/roller) | |
| Push rod ball | |
| Pressure plate bearing | |
| Transmission gear (wheel/pinion) | |
| Shift cam | |
| Shift fork/guide bar | |
| Shift shaft assembly | |
| Shift pedal | |
| Shift lever joint | |
| Middle drive shaft (drive damper cam/driven damper cam) | |



CHASSIS

| Lubrication Point | Symbol |
|--|--------|
| Steering bearing (upper/lower) | |
| Steering bearing cover | |
| Steering lock | |
| Steering head pipe lower oil seal | |
| Front wheel oil seal (right/left) | |
| Rear wheel oil seal | |
| Clutch hub fitting area | |
| Rear brake pedal shaft | |
| Shift pedal | |
| Sidestand sliding surface | |
| Centerstand sliding surface | |
| Tube guide (throttle grip) inner surface | |
| Brake lever pivot bolt, contact surface | |
| Clutch lever pivot bolt, contact surface | |
| Swingarm pivot shaft | |
| Swingarm pivot bearing | |
| Swingarm pivot oil seal | |
| Rear shock absorber bearing (inner) | |

COOLING SYSTEM DIAGRAMS



COOLING SYSTEM DIAGRAMS

- ① Radiator cap
- ② Conduit
- ③ Radiator hose
- ④ Radiator
- (5) Thermostatic valve
- (6) Coolant drain cock
- ⑦ Water pump

- A To coolant reservoir tank
- B To thermostatic valve
- C To coolant drain cock



COOLING SYSTEM DIAGRAMS



- ① Radiator cap
- Conduit
- ③ Radiator hose
- ④ Radiator
- (5) Coolant drain cock
- (6) Thermostatic valve housing
- (7) Water pump

A To thermostatic valve B To coolant drain cock



2

OIL FLOW DIAGRAMS

- ① Camshaft (intake)
- ② Camshaft (exhaust)
- ③ Water pump impeller shaft
- 4 Water pump drive gear
- 5 Oil filter
- 6 Main gallery
- ⑦ Crankshaft

- (8) Oil strainer
- ③ Oil pump④ Main axle
- (1) Drive axle
- 1 1 2 2 3 С 4 ${f igodol}$ 5 ⓓ (10) 6 (9) (8) (7)

SPEC Ľ

OIL FLOW DIAGRAMS

Camshaft
 Main gallery
 Crankshaft
 Oil level switch





- Oil pump
 Oil strainer
- ③ Main axle
- ④ Drive axle
- ⁵ Middle driven pinion gear
- 6 Middle drive pinion gear





2

OIL FLOW DIAGRAMS

Crankshaft
 Oil pipe
 Oil filter





- (1) Front brake hose
 - ② Clutch hose
 - (2) Clutch nose
 - ③ Front flasher light lead (left)④ Speedometer cable
 - (4) Speedometer (5) Wire harness
 - 6 Speedometer light lead
 - (7) Front flasher light lead (right)

- A Insert the wire harness, speedometer light lead and front flasher light leads (left and right) through the hole in the housing at the back of the headlight.
- B Pass the clutch hose through the guide.





- 1) Main switch coupler
- ② Handlebar switch coupler
- ③ Fuel switch coupler
- ④ Ignition coil lead
- 5 Ground lead
- (6) Rear brake switch lead
- O Coolant reservoir tank breather hose
- (8) Battery breather hose
- (9) Fuel sender lead
- 1 Fuel sender coupler

- (1) Battery negative lead
- 12 Coolant breather hose
- (13) Conduit
- (4) Rear brake reservoir tank
- (5) Battery
- (6) Wire harness





- A Fasten the wire harness with a plastic locking tie.
- B To the conduit.
- C Pass the ground lead outside the coolant reservoir tank breather hose.
- D Pass the battery breather hose and coolant reservoir tank breather hose through the guide.
- E Pass the battery breather hose through the clamp.
- F Fasten the rear brake switch lead with a plastic locking tie.
- G Pass the wire harness through the clamp.



CABLE ROUTING SPEC

- 1 Clutch hose
- (2) Handlebar switch lead (left)
- ③ Clutch hose clump
- 4 Throttle cable holder
- 5 Throttle cables
- 6 Fuse box
- ⑦ Ignitor unit
- (8) Ignition coil
- (9) Radiator fan lead coupler
- 10 Horn lead

- (1) Speedometer cable
- (2) Front brake hose
- Bel pump control unitRelay unit
- (5) V-boost control unit
- (6) V-boost control unit lead
- (6) V-boost control unit lead





- A Pass the handlebar switch lead inside the clutch hose.
- $\underline{\mathbb{B}}$ Pass the meter lead outside the clutch hose.
- C Pass the clutch hose outside the throttle cable.
- $\ensuremath{\square}$ Fasten the clutch hose with a plastic locking tie.
- $\boxed{\mathbb{E}}$ Pass the horn lead through the clamp.
- $\underline{\mathbb{F}}$ Pass the speedometer cable through the guide.
- G Pass the front brake hose through the clamp.
- H Pass the front brake hose outside the speedometer cable.
- Pass the clutch hose under the throttle cable guide.
- $\ensuremath{{\rm J}}$ Pass the throttle cables through the guide.





- ① Starter relay
- 2 Main fuse
- ③ Ignition coil
- ④ Oil level switch lead
- (5) Neutral switch lead
- 6 Rectifier/regulator lead coupler
- ⑦ Ground lead coupler
- (8) Sidestand switch lead coupler
- ④ AC generator lead coupler
- 1 Clutch hose
- A Fasten the oil level switch lead, neutral switch lead, ground lead, sidestand switch lead, overflow hose and AC generator lead with a plastic band to the frame guide.

- B Fasten the oil level switch lead, neutral switch lead, ground lead, sidestand switch lead, overflow hose and AC generator lead with plastic band.
- C Pass the oil level switch lead, neutral switch lead, ground lead, and AC generator lead through the clamp.
- D Pass the clutch hose and overflow hose through the guide.
- E Fasten the oil level switch lead, neutral switch lead, ground lead, sidestand switch lead and AC generator lead with a plastic locking tie.
- $\ensuremath{\mathbb{F}}$ Pass the clutch hose through the guide.





- ① Coolant reservoir tank
- ② Spring
- ③ Filler cover
- ④ Drain hose
- (5) Overflow hose
- 6 Overflow valve
- ⑦ Fuel sender
- ⑧ Battery breather hose
- A Fasten the oil level switch lead, neutral switch lead, ground lead, sidestand switch lead, overflow hose and AC generator lead with a plastic band.
- B Fasten the oil level switch lead, neutral switch lead, ground lead, sidestand switch lead, overflow hose and AC generator lead with a plastic band.
- C Pass the clutch hose and overflow hose through the guide.
- D Fasten the overflow hose with a plastic clamp.
- $\ensuremath{\mathbb{E}}$ Pass the overflow hose through the guide.





A Pass the fuel pipe and overflow hose through the hose holder.

CABLE ROUTING

- ① Fuel pump
- ② Fuel pipe
- ③ Fuel filter bracket
- ④ Fuel filter
- $\overbrace{5}^{\smile}$ Over flow hose
- 6 Filler cover
- Filler cap
- 8 Battery band



2



- ① Diode
- ② Ignitor unit
- ③ Ignition coil lead coupler
- ④ Starter relay
- (5) Battery negative lead
- 6 Ignition coil
- ⑦ Ignition coil lead coupler
- (8) Starter relay lead coupler
- 9 Fuel filter
- 1 Rubber boot
- (1) Rear flasher light lead (left)

- 12 Pick up coil lead coupler
- (3) Ground lead coupler
- ⁽ⁱ⁾ Side stand switch lead coupler
- (5) Rectifier/regulator lead coupler
- (6) Oil level switch lead
- Neutral switch lead
- 18 Battery positive lead
- 19 Main fuse
- Starter motor lead
- 2 Fuel pump





- 2 Fuse box
- 23 Meter lead coupler
- Andlebar switch lead coupler

- $\begin{tabular}{|c|c|c|c|} \hline A \end{tabular}$ To the conduit.
- B Fasten the wire harness with a plastic locking tie.
- C Clamp the taillight lead and rear flasher light lead (right).
- D Clamp the rear flasher light lead (left).
- E To V-boost control unit.





EAS00036

PERIODIC CHECKS AND ADJUSTMENTS

INTRODUCTION

This chapter includes all information necessary to perform recommended checks and adjustments. If followed, these preventive maintenance procedures will ensure more reliable vehicle operation, a longer service life and reduce the need for costly overhaul work. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

PERIODIC MAINTENANCE CHART FOR THE EMISSION CONTROL SYSTEM

| | | | | INITIAL | ODOMETER READINGS | | | | | | |
|---|----|--|--|---------------------------------------|--|--|---|---|---|--|--|
| N | о. | ITEM ROUTINE | | 600 mi (1,000 km) or 1 month | 4,000 mi (7,000 km) or 6 months | 8,000 mi (13,000 km) or 12 months | 12,000 mi (19,000 km) or 18 months | 16,000 mi (25,000 km) or 24 months | 20,000 mi (31,000 km) or 30 months | | |
| 1 | * | Valve clearance | Check and adjust valve clearance when engine is cold. | Ev | very 30,00 | 0 mi (42,0 | 00 km) or | 42 month | 8 | | |
| 2 | | Spark plugs | • Check condition. • Adjust gap and clean. • Replace every 8,000 mi (13,000 km) or 12 months and thereafter every 8,000 mi (13,000 km) or 12 months.√Replace.√ | | Replace. | \checkmark | | | | | |
| 3 | * | Crankcase ventila- tion system | Check ventilation hose for cracks or damage.Replace if necessary. | | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark | | |
| 4 | * | Fuel line | Check fuel hoses for cracks or damage.Replace if necessary. | | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark | | |
| 5 | * | Fuel filter | • Replace initial 20,000 mi (31,000 km) or 30 months and thereafter every 20,000 mi (31,000 km) or 30 months. | | | | | | Replace. | | |
| 6 | * | Exhaust system | Check for leakage.Retighten if necessary.Replace gasket(s) if necessary. | | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark | | |
| 7 | * | Carburetor synchronization | Adjust synchronization of carburetors. | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark | | |
| 8 | * | Idle speed | Check and adjust engine idle speed. Adjust cable free play. | | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark | | |
| 9 | * | Evaporative emission control system (For California only) | Check control system for damage.Replace if necessary. | | | | \checkmark | | V | | |

* Since these items require special tools, data and technical skills, have a Yamaha dealer perform the service.



GENERAL MAINTENANCE AND LUBRICATION CHART

| | | | | | INITIAL | ODOMETER READI | | DINGS | DINGS | |
|----|----|--------------------------------------|---|---|--------------|----------------|----------------------------|--------------|---------------------------------------|--------------|
| N | о. | ITEM | ROUTINE | TYPE | 600 mi | 4,000 mi | 8,000 mi | 12,000 mi | 16,000 mi | 20,000 mi |
| | | | | | or | or | Or | Or | Or | or |
| 1 | | Engine oil | Replace (warm up engine before draining). | See page 2-2. | √ Timontin | √ | $\sqrt{12 \text{ months}}$ | √ Nonths | 1000000000000000000000000000000000000 | 30 months |
| 2 | | Oil filter | Replace. | - | \checkmark | | | | \checkmark | |
| 3 | * | Air filter | Clean with compressed air. Replace if necessary. | _ | | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark |
| 4 | * | Cooling system | Check hose for cracks or damage. Replace if neces- sary. | _ | | V | \checkmark | \checkmark | V | \checkmark |
| | | | Replace coolant every 24 months. | Ethylene glycol anti- freeze coolant | | | | | Replace. | |
| 5 | * | Brake system | Adjust free play. Replace pads if necessary. | _ | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark |
| 6 | * | Clutch | Check operation and fluid leakage. (See NOTE page 3-3.) Correct if neces- sary. | _ | V | V | V | \checkmark | V | V |
| 7 | | Final gear oil | Check oil lever and leakage. Replace every 16,000 mi (25,000 km) or 24 months. | SAE 80 API "GL-4" hypoid gear oil | Replace. | V | V | 1 | Replace. | V |
| 8 | | Control and meter cable | Apply chain lube thoroughly. | Yamaha chain and cable lube or SAE 10W-30 motor oil | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark |
| 9 | * | Swingarm pivot bearing | Check bearing assembly for looseness. Moderately repack every 16,000 mi (25,000 km). | Lithium-soap-based grease | | | \checkmark | | Repack. | |
| 10 | | Brake/clutch lever pivot shaft | Apply lithium-soap- based grease (all- purpose grease) lightly. | Lithium-soap-based grease (all-purpose grease) | | V | \checkmark | \checkmark | \checkmark | \checkmark |
| 11 | | Brake pedal and shift pedal shaft | Lubricate. Apply lithium-soap- based grease (all- purpose grease) lightly. | Lithium-soap-based grease (all-purpose grease) | | V | V | V | V | V |
| 12 | * | Center/sidestand pivots | Check operation and lubricate. Apply lithium-soap- based grease (all- purpose grease) lightly. | Lithium-soap-based grease (all-purpose grease) | | V | N | V | V | V |
| 13 | * | Front fork | Check operation and leakage. | - | | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark |



GENERAL MAINTENANCE AND LUBRICATION CHART



| | | | | | INITIAL | | ODOMETER READINGS | | | | |
|----|----|-------------------|---|------------------------------|---------------------------------------|--|--|---|---|---|--|
| N | о. | ITEM | ROUTINE | ТҮРЕ | 600 mi (1,000 km) or 1 month | 4,000 mi (7,000 km) or 6 months | 8,000 mi (13,000 km) or 12 months | 12,000 mi (19,000 km) or 18 months | 16,000 mi (25,000 km) or 24 months | 20,000 mi (31,000 km) or 30 months | |
| 14 | * | Steering bearings | Check bearing assembly for looseness. Moderately repack every 16,000 mi (25,000 km). | Lithium-soap-based grease | | \checkmark | V | \checkmark | Repack. | V | |
| 15 | * | Wheel bearings | Check bearings for smooth rotation. | - | | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark | |
| 16 | * | Battery | Check specific gravity and breather pipe for proper operation. | _ | | \checkmark | | | \checkmark | \checkmark | |
| 17 | * | Sidestand switch | Check and clean or replace if neces- sary. | _ | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark | |

* Since these items require special tools, data and technical skills, they should be serviced by a Yamaha dealer.

NOTE:

For odometer readings or time periods higher than 20,000 mi (31,000 km) or 30 months, follow the maintenance requirements listed in the maintenance chart under the 4,000 mi (7,000 km) or 6 month interval.

NOTE: _

- The air filter needs more frequent service if you are riding in unusually wet or dusty areas.
- Hydraulic brake and clutch systems
- After disassembling the master cylinder, caliper cylinder or clutch release cylinder, always replace the brake fluid.

Check the brake fluid level of the master cylinder and clutch release cylinder regularly and fill as required.

- Replace the oil seals on the inner parts of the master cylinder, caliper cylinder and clutch release cylinder every two years.
- Replace the brake and clutch hoses every four years or if cracked or damaged.

SEATS AND SIDE COVERS



SEATS AND SIDE COVERS



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------------|------|--|
| | Removing the seats and side covers | | Remove the parts in the order listed. |
| 1 | Rider seat | 1 | |
| 2 | Tool cover | 1 | |
| 3 | Tool band | 1 | |
| 4 | Tool kit | 1 | |
| 5 | Passenger seat | 1 | |
| 6 | Side covers (left and right) | 2 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |

3

TOP COVER AND COVERS



TOP COVER AND COVERS



| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------------------|------|--|
| | Removing the top cover and covers | | Remove the parts in the order listed. |
| 1 | Top cover | 1 | |
| 2 | Covers (left and right) | 2 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |
AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD

CHK

ADJ

10

AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD



| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------------|------|--|
| | Removing the air filter case and | | Remove the parts in the order listed. |
| | electrical components board | | |
| | Top cover and covers | | Refer to "TOP COVER AND COVERS". |
| 1 | Fuel pump control unit | 1 | Disconnect. |
| 2 | Relay unit | 1 | Disconnect. |
| 3 | Electrical components board | 1 | |
| 4 | Air vent hose holder | 2 | |
| 5 | Air filter case cover | 1 | |
| 6 | Air filter | 1 | |
| 7 | Air filter case | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |

3



ENGINE

ADJUSTING THE VALVE CLEARANCE

The following procedure applies to all of the valves.

NOTE: ____

- Valve clearance adjustment should be made on a cold engine, at room temperature.
- When the valve clearance is to be measured or adjusted, the piston must be at top dead center (TDC) on the compression stroke.
- 1. Remove:
- top cover
 covers (left and right) Refer to "AIR FILTER CASE AND ELEC-TRICAL COMPONENTS BOARD".
- 2. Remove:
- electrical components board ①
- 3. Disconnect:
- all electrical component leads
- 4. Remove:
- radiator side covers
- radiator bolt Refer to "COOLING SYSTEM" in chapter 5.

NOTE: _

It is not necessary to remove the radiator completely from the motorcycle.

- 5. Disconnect:
- spark plug caps
- 6. Remove:
- air baffle plate (rear) Refer to "ENGINE REMOVAL" in chapter 4.
- 7. Remove:
- cylinder head covers

NOTE: _

Be sure you do not lose the oil plugs 1 on the camshaft caps.



















- 8. Measure:
- valve clearance Out of specification \rightarrow Adjust.



- a. Turn the crankshaft counterclockwise.
- b. When piston #1 is at TDC on the compression stroke, align the TDC mark (a) with the stationary pointer (b).

NOTE: .

TDC on the compression stroke can be found when the camshaft lobes are turned away from each other.



- 1 TDC for No. 1 cylinder
- 2 TDC for No. 2 cylinder
- c. Measure the valve clearance with a thickness gauge ③.

NOTE: .

- If the valve clearance is incorrect, record the measured reading.
- Measure the valve clearance in the following sequence.

Valve clearance measuring sequence Cylinder #1 \rightarrow #3 \rightarrow #2 \rightarrow #4

A Front

- d. To measure the valve clearances of the other cylinders, starting with cylinder #1 at TDC, turn the crankshaft counterclockwise as specified in the following table.
- B Degrees that the crankshaft is turned counterclockwise
- C Cylinder
- D Combustion cycle

| Cylinder #3 | 180° |
|-------------|------|
| Cylinder #2 | 430° |
| Cylinder #4 | 610° |











- 9. Adjust:
- valve clearance
- a. Align the intake and exhaust valve lifter slots with each other.
- b. Install the tappet adjusting tool ① between the camshaft and the valve lifter.

| Tappet adjusting tool YM-33961 |
|-----------------------------------|
| |

NOTE:

Make sure the tappet adjusting tool touches only the valve lifter (2), not the valve pad (3).

- c. Slowly turn the tappet adjusting tool so that the valve pad can be removed.
- d. Remove the valve pad from the valve lifter with a small screwdriver and a pair of tweezers. Make a note of the position of each valve pad and valve pad number so they can be installed in the correct place.
- e. Select the proper valve pad from the following table.

| Valve pad rar | thickness ige | Available valve pads |
|------------------|------------------|----------------------|
| Nos. | 2.00 ~ | 25 thicknesses in |
| 200 ~ 320 | 3.20 mm | 0.05 mm increments |

NOTE:

- The thickness of each valve pad is marked in hundredths of millimeters on the side that touches the valve lifter (not the camshaft).
- Since valve pads of various sizes are originally installed, the valve pad number must be rounded in order to reach the closest equivalent to the original.



ADJUSTING THE VALVE CLEARANCE

INTAKE

| MEASURED | | | | | | | | | | IN | ISTA | LLED |) PA | D NL | JMBE | R | | | | | | | | | |
|-------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|------|------|------|--------|-------|-------|-------|-------|--------|-------|-------------|-------|---------|-------|
| CLEARANCE | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |
| 0.00 ~ 0.05 | | | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 |
| 0.06 ~ 0.10 | | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 |
| 0.11 ~ 0.15 | | | | | | | | | | S | TAN | DAR | D CL | EAR | ANC | E | | | | | | | | | |
| 0.16 ~ 0.20 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | |
| 0.21 ~ 0.25 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | |
| 0.26 ~ 0.30 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | |
| 0.31 ~ 0.35 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | |
| 0.36 ~ 0.40 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | |
| 0.41 ~ 0.45 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | |
| 0.46 ~ 0.50 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | |
| 0.51 ~ 0.55 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | |
| 0.56 ~ 0.60 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | | |
| 0.61 ~ 0.65 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | | | |
| 0.66 ~ 0.70 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | | | | |
| 0.71 ~ 0.75 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | | | | | |
| 0.76 ~ 0.80 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | | | | | | |
| 0.81 ~ 0.85 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | VAL | _VE | CLE | EAR | AN | CE (| cold | l): | | | |
| 0.86 ~ 0.90 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | (|) 11 | ~ 0 | 15 i | mm | (0, 0) | 04 - | źი | 006 | in) | |
| 0.91 ~ 0.95 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | - | | | | Eva | mnl | م· Ir | netal | hall | ie n | 2 he | 50 | | , | |
| 0.96 ~ 1.00 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | Mag | | | | | au 2 | .00 22 m | | | 0 in) |
| 1.01 ~ 1.05 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | л Г | vieas | sure | | | nce i | S U.2 | 23 11 | im (c | 0.00 | 9 11) |
| 1.06 ~ 1.10 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | | Rep | blace | e pa | d 25 | 50 W | /ith p | bad | 260 | | | |
| 1.11 ~ 1.15 | 300 | 305 | 310 | 315 | 320 | | | | | | | | | | F | Pad | num | nber | : (e) | kam | ple) | | | | |
| 1.16 ~ 1.20 | 305 | 310 | 315 | 320 | | | | | | | | | | | F | Pad | No. | 250 |) = 2 | 2.50 | mm | (0.0 |)98 | in) | |
| 1.21 ~ 1.25 | 310 | 315 | 320 | | | | | | | | | | | | F | Pad | No. | 260 |) = 2 | 2.60 | mm | (0.1 | 02 | in) | |
| 1.26 ~ 1.30 | 315 | 320 | | | | | | | | | | | | | Alw | avs | inst | all n | ad | with | nun | nher | . qov | , wn | |
| 1.31 ~ 1.35 | 320 | | - | | | | | | | | | | | | , | ~,0 | | ~ P | au | | | | 201 | | |

EXHAUST

| MEASURED | | | | | | | | | | IN | ISTA | LLE |) PA | D NL | JMBE | R | | | | | | | | | |
|-------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|-----|------|------|------|------------|-------|-------|-------|-------|--------|--------|---------|-------|-----|
| CLEARANCE | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 |
| 0.00 ~ 0.05 | | | | | | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 |
| 0.06 ~ 0.10 | | | | | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 |
| 0.11 ~ 0.15 | | | | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 |
| 0.16 ~ 0.20 | | | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 |
| 0.21 ~ 0.25 | | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 |
| 0.26 ~ 0.30 | | | | | | | | | | S | TAN | DAR | D CL | EAR | ANC | E | | | | | | | | | |
| 0.31 ~ 0.35 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | |
| 0.36 ~ 0.40 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | - |
| 0.41 ~ 0.45 | 215 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | |
| 0.46 ~ 0.50 | 220 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | - | | |
| 0.51 ~ 0.55 | 225 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | |
| 0.56 ~ 0.60 | 230 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | - | | | | |
| 0.61 ~ 0.65 | 235 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | - | | | | | |
| 0.66 ~ 0.70 | 240 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | - | | | | | | |
| 0.71 ~ 0.75 | 245 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | - | | | | | | | |
| 0.76 ~ 0.80 | 250 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | | | |
| 0.81 ~ 0.85 | 255 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | | | | |
| 0.86 ~ 0.90 | 260 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | | | | | |
| 0.91 ~ 0.95 | 265 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | - | | VAL | _VE | CLE | EAR | AN | CE (| colo | :(k | | |
| 0.96 ~ 1.00 | 270 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | C |).26 | ~ 0. | 30 n | nm (| 0.01 | 02 - | - 0.0 | 118 | in) |
| 1.01 ~ 1.05 | 275 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | Exa | mpl | e: Ir | nstal | ĺled | is pa | ad 2 | 250 | | , |
| 1.06 ~ 1.10 | 280 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | /ea/ | sure | d cl | ears | | | 1 32 | mm | h |
| 1.11 ~ 1.15 | 285 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | | | 12 in | | care | | , 13 (| J.02 | | • |
| 1.16 ~ 1.20 | 290 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | | <u>с (</u> | 0.0 | 1311 | " | - 0 | ••• | | <u></u> | | |
| 1.21 ~ 1.25 | 295 | 300 | 305 | 310 | 315 | 320 | | | | | | | | | | Rep | blace | e pa | d 25 | 50 W | lith p | bad | 255 | | |
| 1.26 ~ 1.30 | 300 | 305 | 310 | 315 | 320 | | | | | | | | | | | F | Pad | num | nber | : (e) | kam | ple) | | | |
| 1.31 ~ 1.35 | 305 | 310 | 315 | 320 | | | | | | | | | | | | F | Pad | No. | 250 |) = 2 | .50 | mm | (0.0 | 98 | in) |
| 1.36 ~ 1.40 | 310 | 315 | 320 | | | | | | | | | | | | | F | Pad | No. | 255 | 5 = 2 | .55 | mm | (0.1 | 100 | in) |
| 1.41 ~ 1.45 | 315 | 320 | | - | | | | | | | | | | | | Alw | avs | inst | all n | nad v | with | nun | nhei | doh 1 | wn |
| 1.46 ~ 1.50 | 320 | | | | | | | | | | | | | | | , | 4,0 | | an P | au | | | | 40 | |



ADJUSTING THE VALVE CLEARANCE



f. Round off the original valve pad number according to the following table.

| Last digit | Rounded value |
|------------|---------------|
| 0 or 2 | 0 |
| 5 | 5 |
| 8 | 10 |

EXAMPLE:

Original valve pad number = 248 (thickness = 2.48 mm)

Rounded value = 250

g. Locate the rounded number of the original valve pad and the measured valve clearance in the valve pad selection table. The point where the column and row intersect is the new valve pad number.

NOTE: .

The new valve pad number is only an approximation. The valve clearance must be measured again and the above steps should be repeated if the measurement is still incorrect.

- h. Install the new valve pad with the numbered side facing down.
- i. Remove the tappet adjusting tool.
- j. Measure the valve clearance again.
- k. If the valve clearance is still out of specification, repeat all of the valve clearance adjustment steps until the specified clearance is obtained.

10.Install:

all removed parts

NOTE:

For installation, reverse the removal procedure. Note the following points.

11.Install:

• cylinder head covers

| | X | 10 Nm (1.0 m · kg, 7.2 ft · lb) |
|---------------------------------|---|---------------------------------|
| spark plugs | X | 18 Nm (1.8 m · kg, 13 ft · lb) |



EASONDSO SYNCHRONIZING THE CARBURETORS

NOTE: .

Prior to synchronizing the carburetors, the valve clearance and the engine idling speed should be properly adjusted and the ignition timing should be checked.

1. Stand the motorcycle on a level surface.

NOTE: .

Place the motorcycle on a suitable stand.

- 2. Remove:
- carburetor joint covers (left and right)
- vacuum plugs (left and right)
 vacuum hose
- Refer to "CARBURETORS" in chapter 6.





- 3. Install:
- vacuum gauge attachment (into the bolt holes)
- vacuum gauge ①
 (onto the vacuum gauge attachments)
- inductive tachometer ②
 (onto the spark plug lead of cylinder #1)



- 4. Start the engine and let it warm up for several minutes.
- 5. Measure:
- engine idling speed Out of specification → Adjust. Refer to "ADJUSTING THE ENGINE IDLING SPEED".



Engine idling speed 950 ~ 1,050 r/min 1,050 ~ 1,150 r/min (for California)







- 6. Adjust:
- carburetor synchronization
- ****
- a. Synchronize carburetor #1 to carburetor #2 by turning the synchronizing screw ① in either direction until both gauges read the same.

NOTE: .

After each step, rev the engine two or three times, each time for less than a second, and check the synchronization again.

- b. Synchronize carburetor #4 to carburetor #3 by turning the synchronizing screw ② in either direction until both gauges read the same.
- c. Synchronize carburetor #2 to carburetor #3 by turning the synchronizing screw ③ in either direction until both gauges read the same.



Vacuum pressure at engine idling

speed 26.7 kPa (200 mm Hg, 7.88 in Hg) 33.3 kPa (250 mm Hg, 9.83 in Hg) (for California)

NOTE: _

The difference in vacuum pressure between two carburetors should not exceed 1.33 kPa (10 mm Hg, 0.4 in Hg).

- 7. Measure:
- engine idling speed
 Out of specification → Adjust.
- 8. Stop the engine and remove the measuring equipment.
- 9. Adjust:
- throttle cable free play Refer to "ADJUSTING THE THROTTLE CABLE FREE PLAY".

Throttle cable free play (at the flange of the throttle grip) 3 ~ 5 mm (0.12 ~ 0.20 in)

10.Install:

- vacuum hose
- vacuum plugs (left and right)
- carburetor joint covers (left and right) Refer to "CARBURETORS" in chapter 6.



EAS00053 ADJUSTING THE ENGINE IDLING SPEED

NOTE: _

Prior to adjusting the engine idling speed, the carburetor synchronization should be adjusted properly, the air filter element should be clean, and the engine should have adequate compression.

- 1. Start the engine and let it warm up for several minutes.
- 2. Attach:
- engine tachometer (onto the spark plug lead of cylinder #1)



Inductive tachometer YU-8036-A

- 3. Measure:
- engine idling speed Out of specification \rightarrow Adjust.

Engine idling speed



950 ~ 1,050 r/min 1,050 ~ 1,150 r/min (for California)



- 4. Adjust:
- engine idling speed
- *****
- a. Turn the throttle stop screw (1) in direction (a) or (b) until the specified engine idling speed is obtained.

| Direction ⓐ | Engine idling speed is increased. |
|---------------|-----------------------------------|
| Direction (b) | Engine idling speed is decreased. |

5. Adjust:

• throttle cable free play Refer to "ADJUSTING THE THROTTLE CABLE FREE PLAY".



Throttle cable free play (at the flange of the throttle grip) 3 ~ 5 mm (0.12 ~ 0.20 in)



ADJUSTING THE THROTTLE CABLE FREE PLAY

NOTE: _

Prior to adjusting the throttle cable free play, the engine idling speed and carburetor synchronization should be adjusted properly.

- 1. Check:
- throttle cable free play ⓐ Out of specification → Adjust.



Throttle cable free play (at the flange of the throttle grip) 3 ~ 5 mm (0.12 ~ 0.20 in)

- 2. Adjust:
- throttle cable free play

Carburetor side

- a. Loosen the locknut 1.
- b. Turn the adjusting nut ② in direction ③ or
 ⑤ until the specified throttle cable free play is obtained.

| Direction ⓐ | Throttle cable free play is increased. |
|---------------|--|
| Direction (b) | Throttle cable free play is decreased. |

c. Tighten the locknuts.

NOTE: _

If the specified throttle cable free play cannot be obtained on the carburetor side of the cable, use the adjusting nut on the handlebar side.

Handlebar side

- a. Loosen the locknut ③.
- b. Turn the adjusting nut ④ in direction ⓒ or
 ⓓ until the specified throttle cable free play is obtained.

| Direction © | Throttle cable free play is increased. |
|---------------|--|
| Direction (d) | Throttle cable free play is decreased. |







ADJUSTING THE THROTTLE CABLE FREE PLAY/ CHECKING THE SPARK PLUGS



c. Tighten the locknut.

A WARNING

After adjusting the throttle cable free play, start the engine and turn the handlebar to the right and to the left to ensure that this does not cause the engine idling speed to change.

EAS00050 CHECKING THE SPARK PLUGS

The following procedure applies to all of the spark plugs.

- 1. Disconnect:
- spark plug cap
- 2. Remove:
- spark plug

CAUTION:

Before removing the spark plugs, blow away any dirt accumulated in the spark plug wells with compressed air to prevent it from falling into the cylinders.

- 3. Check:
- spark plug type Incorrect \rightarrow Change.

Spark plug type (manufacturer) DPR8EA-9 (NGK) X24EPR-U9 (DENSO)

- 4. Check:
- electrodes (1)
 - Damage/wear \rightarrow Replace the spark plug.
- insulator (2) Abnormal color \rightarrow Replace the spark plug. Normal color is medium-to-light tan.
- 5. Clean:
- spark plug
- (with a spark plug cleaner or wire brush)
- 6. Measure:
- spark plug gap ⓐ (with a wire gauge)

Out of specification \rightarrow Regap.

Spark plug gap 0.8 ~ 0.9 mm (0.03 ~ 0.04 in)





7. Install:

• spark plug 🛛 🔌 18 Nm (1.8 m · kg, 13 ft · lb)

NOTE: _

Before installing the spark plug, clean the spark plug and gasket surface.

- 8. Connect:
- spark plug cap

CHECKING THE IGNITION TIMING

NOTE: _

Prior to checking the ignition timing, check the wiring connections of the entire ignition system. Make sure all connections are tight and free of corrosion.

- 1. Remove:
- timing plug (1)





- 2. Attach:
 - timing light ①
 - engine tachometer ②
 (onto the spark plug lead of cylinder #1)



Timing light YM-33277-A Inductive tachometer YU-8036-A

- 3. Check:
- ignition timing
- ****
- a. Start the engine, warm it up for several minutes, and then let it run at the specified engine idling speed.



Engine idling speed 950 ~ 1,050 r/min 1,050 ~ 1,150 r/min (for California)

CHECKING THE IGNITION TIMING/ MEASURING THE COMPRESSION PRESSURE





4. Install:timing plug

system.

NOTE:

MEASURING THE COMPRESSION PRESSURE

The ignition timing is not adjustable.

The following procedure applies to all of the cylinders.

b. Check that the stationary pointer (a) is within the firing range (b) on the generator rotor. Incorrect firing range \rightarrow Check the ignition

NOTE: _

Insufficient compression pressure will result in a loss of performance.

- 1. Measure:
- valve clearance Out of specification → Adjust. Refer to "ADJUSTING THE VALVE CLEARANCE".
- 2. Start the engine, warm it up for several minutes, and then turn it off.
- 3. Disconnect:
- spark plug cap
- 4. Remove:
- spark plug

CAUTION:

Before removing the spark plugs, use compressed air to blow away any dirt accumulated in the spark plug wells to prevent it from falling into the cylinders.



- 5. Install:
- compression gauge ①



6. Measure:

compression pressure

Out of specification \rightarrow Refer to steps (c) and (d).





| K | Compression pressure (at sea level) Minimum |
|---|---|
| | 1,200 KPa (12 kg/cm² 170 6 psi) |
| | Standard |
| | 1,400 kPa |
| | (14 kg/cm², 199.1 psi) |
| | Maximum |
| | 1,600 kPa |
| | (16 kg/cm², 227.6 psi) |

- a. Set the main switch to "ON".
- b. With the throttle wide open, crank the engine until the reading on the compression gauge stabilizes.

A WARNING

To prevent sparking, ground all spark plug leads before cranking the engine.

NOTE:

The difference in compression pressure between cylinders should not exceed 100 kPa (1 kg/cm², 14 psi).

c. If the compression pressure is above the maximum specification, check the cylinder head, valve surfaces and piston crown for carbon deposits.

Carbon deposits \rightarrow Eliminate.

 d. If the compression pressure is below the minimum specification, squirt a few drops of oil into the cylinder and measure again.
 Refer to the following table.

| Compression pressure (with oil applied into the cylinder) | | | |
|--|---|--|--|
| Reading | Diagnosis | | |
| Higher than without oil | Piston wear or damage \rightarrow Repair. | | |
| Same as without oil | Piston ring(s), valves, cylinder head gasket or pis- ton possibly defec- tive \rightarrow Repair. | | |

- 7. Install:
 - spark plug 🛛 🔌 18 Nm (1.8 m · kg, 13 ft · lb)
- 8. Connect:
- spark plug cap



CHECKING THE ENGINE OIL LEVEL

1. Stand the motorcycle on a level surface.

NOTE:

- Place the motorcycle on a suitable stand.
- Make sure the motorcycle is upright.
- 2. Start the engine, warm it up for several minutes, and then turn it off.
- 3. Check:
 - engine oil level

The engine oil level should be between the minimum level mark (a) and maximum level mark (b).

Below the minimum level mark \rightarrow Add the recommended engine oil to the proper level.



Recommended oil At 5 °C (40 °F) or higher A Yamalube 4 (20W40) or SAE 20W40 type SE motor oil At 15 °C (60 °F) or lower B Yamalube 4 (10W30) or SAE 10W30 type SE motor oil

CAUTION:

- Engine oil also lubricates the clutch and the wrong oil types or additives could cause clutch slippage. Therefore, do not add any chemical additives
- Do not allow foreign materials to enter the crankcase.

NOTE: .

- API Service "SE", "SF" and "SG" type or equivalent (e.g., "SF-SE", "SF-SE-CC", "SF-SE-SD").
- Before checking the engine oil level, wait a few minutes until the oil has settled.
- 3. Start the engine, warm it up for several minutes, and then turn it off.
- 4. Check the engine oil level again.

NOTE: .

Before checking the engine oil level, wait a few minutes until the oil has settled.







CHANGING THE ENGINE OIL











CHANGING THE ENGINE OIL

- 1. Start the engine, warm it up for several minutes, and then turn it off.
- 2. Place a container under the engine oil drain bolt.
- 3. Remove:
- engine oil filler cap
- engine oil drain bolt ② (along with the gasket)
- 4. Drain:
- engine oil (completely from the crankcase)

5. If the oil filter cartridge is also to be replaced, perform the following procedure.

a. Remove the oil filter cartridge ① with an oil filter wrench ②.

Oil filter wrench YU-38411

b. Lubricate the O-ring (3) of the new oil filter cartridge with a thin coat of engine oil.

CAUTION:

Make sure the O-ring 3 is positioned correctly in the groove of the oil filter cartridge.

c. Tighten the new oil filter cartridge to specification with an oil filter wrench.



Oil filter cartridge 17 Nm (1.7 m • kg, 12 ft • lb)

- 6. Check:
- engine oil drain bolt gasket Damage \rightarrow Replace.
- 7. Install:
- engine oil drain bolt

🔌 43 Nm (4.3 m · kg, 31 ft · lb)

CHANGING THE ENGINE OIL/ MEASURING THE ENGINE OIL PRESSURE



- 8. Fill:
- crankcase
 (with the specific

(with the specified amount of the recommended engine oil)



- 9. Install:
- engine oil filler cap
- 10.Start the engine, warm it up for several minutes, and then turn it off.
- 11.Check:
- engine
 - (for engine oil leaks)
- 12.Check:
- engine oil level Refer to "CHECKING THE ENGINE OIL LEVEL".

EAS00077

- MEASURING THE ENGINE OIL PRESSURE
- 1. Check:
- engine oil level Below the minimum level mark → Add the recommended engine oil to the proper level.
- 2. Start the engine, warm it up for several minutes, and then turn it off.

CAUTION

When the engine is cold, the engine oil will have a higher viscosity, causing the engine oil pressure to increase. Therefore, be sure to measure the engine oil pressure after warming up the engine.



MEASURING THE ENGINE OIL PRESSURE







- 3. Remove:
- main gallery bolt

A WARNING

The engine, muffler and engine oil are extremely hot.

- 4. Install:
- pressure gauge ①
- oil pressure adapter B 2



- 5. Measure:
- engine oil pressure (at the following conditions)



| Engine oil pressure | Possible causes |
|--------------------------|--|
| Below specifica- tion | Faulty oil pump Clogged oil filter Leaking oil passage Broken or damaged oil seal |
| Above specifica- tion | Leaking oil passage Faulty oil filter Oil viscosity too high |

6. Install:

• main gallery bolt

🔌 12 Nm (1.2 m · kg, 8.7 ft · lb)



EAS00083 CHECKING THE CLUTCH FLUID LEVEL

1. Stand the motorcycle on a level surface.

NOTE:

Place the motorcycle on a suitable stand.



- 2. Check:
- clutch fluid level

Below the minimum level mark $(1) \rightarrow Add$ the recommended clutch fluid to the proper level.

Recommended clutch fluid Brake fluid DOT 4



- Use only the designated clutch fluid. Other clutch fluids may cause the rubber seals to deteriorate, causing leakage and poor clutch performance.
- Refill with the same type of clutch fluid that is already in the system. Mixing clutch fluids may result in a harmful chemical reaction, leading to poor clutch performance.
- When refilling, be careful that water does not enter the clutch fluid reservoir. Water will significantly lower the boiling point of the clutch fluid and could cause vapor lock.

CAUTION:

Clutch fluid may damage painted surfaces or plastic parts. Therefore, always clean up any spilt clutch fluid immediately.

NOTE: _

In order to ensure a correct reading of the clutch fluid level, make sure the top of the reservoir is horizontal.



BLEEDING THE HYDRAULIC CLUTCH SYSTEM

A WARNING

Bleed the hydraulic clutch system whenever:

- the system was disassembled,
- a clutch hose was loosened or removed,
- the clutch fluid level is very low,
- clutch operation is faulty.

NOTE: .

- Be careful not to spill any clutch fluid or allow the clutch fluid reservoir to overflow.
- When bleeding the hydraulic clutch system, make sure there is always enough clutch fluid before applying the clutch lever. Ignoring this precaution could allow air to enter the hydraulic clutch system, considerably lengthening the bleeding procedure.
- If bleeding is difficult, it may be necessary to let the clutch fluid settle for a few hours. Repeat the bleeding procedure when the tiny bubbles in the hose have disappeared.



- 1. Bleed:
- hydraulic clutch system
- ****
- a. Add the recommended clutch fluid to the proper level.
- b. Install the clutch fluid reservoir diaphragm.
- c. Connect a clear plastic hose ① tightly to the bleed screw ②.
- d. Place the other end of the hose into a container.
- e. Slowly squeeze the clutch lever several times.
- f. Fully squeeze the clutch lever without releasing it.
- g. Loosen the bleed screw. This will release the tension and cause the clutch lever to contact the handlebar grip.
- h. Tighten the bleed screw and then release the clutch lever.

BLEEDING THE HYDRAULIC CLUTCH SYSTEM/ CLEANING THE AIR FILTER ELEMENT



- i. Repeat steps (e) to (h) until all of the air bubbles have disappeared from the clutch fluid in the plastic hose.
- j. Tighten the bleed screw to specification.



Bleed screw 6 Nm (0.6 m • kg, 4.3 ft • lb)

k. Add the recommended clutch fluid to the proper level.
 Refer to "CHECKING THE CLUTCH FLUID LEVEL".

A WARNING

After bleeding the hydraulic clutch system, check the clutch operation.







CLEANING THE AIR FILTER ELEMENT

- 1. Remove:
- top cover
- 2. Remove:
- air filter case cover 1
- air filter element
- 3. Clean:
- air filter element Apply compressed air to the outer surface of the air filter element.
- 4. Check:
- air filter element
 Damage → Replace.
- 5. Install:
- air filter element
- air filter case cover

CAUTION:

Never operate the engine without the air filter element installed. Unfiltered air will cause rapid wear of engine parts and may damage the engine. Operating the engine without the air filter element will also affect the carburetor tuning, leading to poor engine performance and possible overheating.



NOTE: _

When installing the air filter element into the air filter case cover, make sure their sealing surfaces are aligned to prevent any air leaks.

- 6. Install:
- top cover

EAS00095

CHECKING THE CARBURETOR JOINTS

The following procedure applies to all of the carburetor joints and intake manifolds.

- 1. Remove:
- carburetor joint covers



- 2. Check:
- carburetor joint ① Cracks/damage → Replace. Refer to "CARBURETORS" in chapter 6.
- 3. Install:
- carburetor joint covers

CHECKING THE VACUUM HOSES

The following procedure applies to all of the fuel and vacuum hoses.

- 1. Remove:
- covers (left and right) Refer to "AIR FILTER CASE AND ELEC-TRICAL COMPONENTS BOARD".



- 2. Check:
- vacuum hose (1) Cracks/damage \rightarrow Replace. Loose connection \rightarrow Connect properly.
- 3. Install:
- covers (left and right) Refer to "AIR FILTER CASE AND ELEC-TRICAL COMPONENTS BOARD".

(1)

(2)



CHECKING THE FUEL HOSES AND FUEL FILTER

The following procedure applies to all of the fuel hoses.

- 1. Remove:
- rider seat Refer to "SEATS AND SIDE COVERS".
- 2. Check:
- fuel hose (1) Cracks/damage \rightarrow Replace.
- fuel filter (2) Contaminants/damage \rightarrow Replace.

NOTE:

- Drain and flush the fuel tank if abrasive damage to any components of the fuel line is evident.
- The arrow mark on the fuel filter must point towards the fuel pump ③ as shown.
- 3. Install:
 - rider seat Refer to "SEATS AND SIDE COVERS".



1

CHECKING THE CRANKCASE BREATHER HOSE

- 1. Check:
- crankcase breather hose ①
 Cracks/damage → Replace.
 Loose connection → Connect properly.

CAUTION:

Make sure the crankcase breather hose is routed correctly.



CHECKING THE EXHAUST SYSTEM/ CHECKING THE COOLANT LEVEL





CHECKING THE EXHAUST SYSTEM

The following procedure applies to all of the exhaust pipes, mufflers and gaskets.

- 1. Check:
- exhaust pipe ①
- muffler (2) Cracks/damage \rightarrow Replace.
- gasket (3) Exhaust gas leaks \rightarrow Replace.
- 2. Check:
- tightening torque



EAS00102

CHECKING THE COOLANT LEVEL

1. Stand the motorcycle on a level surface.

NOTE: _

- Place the motorcycle on a suitable stand.
- Make sure the motorcycle is upright.
- 2. Remove:
- top cover
- 3. Check:
- coolant level

The coolant level should be between the maximum level mark (a) and minimum level mark (b).

Below the minimum level mark \rightarrow Add the recommended coolant to the proper level.

CAUTION:

- Adding water instead of coolant lowers the antifreeze content of the coolant. If water is used instead of coolant check, and if necessary, correct the antifreeze concentration of the coolant.
- Use only distilled water. However, if distilled water is not available soft water may be used.



CHECKING THE COOLANT LEVEL/CHECKING THE COOLING SYSTEM/CHANGING THE COOLANT



- 4. Start the engine, warm it up for several minutes, and then turn it off.
- 5. Check:
- coolant level

NOTE: _

Before checking the coolant level, wait a few minutes until it settles.

- 6. Install:
- top cover







CHECKING THE COOLING SYSTEM

- 1. Check:
- \bullet radiator (1)
- radiator inlet hose ②
- radiator outlet hose ③
 Cracks/damage → Replace.
 Refer to "COOLING SYSTEM" in chapter 5.
- 2. Install:
- top cover

EAS00105

CHANGING THE COOLANT

- 1. Turn the coolant drain cock ① to the "ON" position ②.
- 2. Disconnect:
- coolant reservoir hose ①
- 3. Drain:
- coolant (from the coolant reservoir)
- 4. Remove:
- radiator cap 2

A WARNING

A hot radiator is under pressure. Therefore, do not remove the radiator cap when the engine is hot. Scalding hot fluid and steam may be blown out, which could cause serious injury. When the engine has cooled, open the radiator cap as follows:



Place a thick rag or a towel over the radiator cap and slowly turn the radiator cap counterclockwise toward the detent to allow any residual pressure to escape. When the hissing sound has stopped, press down on the radiator cap and turn it counterclockwise to remove.

The following procedure applies to all of the coolant drain bolts and copper washers.

- 5. Remove:
- cover
- coolant drain plug (engine) ①
- coolant drain bolt (water pump) ②
- 6. Drain:
- coolant (from the engine and radiator)
- 7. Install:
- coolant drain plug (engine)
- cover
- coolant drain bolt (water pump)

🔌 43 Nm (4.3 m · kg, 31 ft · lb)

- 8. Connect:
- coolant reservoir hose

- 9. Fill:
- cooling system

(with the specified amount of the recommended coolant)

Recommended antifreeze High-quality ethylene glycol antifreeze containing corrosion inhibitors for aluminum engines Mixing ratio 1:1 (antifreeze:water) Quantity Total amount 3.05 L (2.68 Imp qt, 3.22 US qt) Coolant reservoir capacity 0.3 L (0.26 Imp qt, 0.21 US qt) From minimum to maximum level mark 0.2 L (0.18 Imp qt, 0.21 US qt)









Handling notes for coolant

Coolant is potentially harmful and should be handled with special care.

A WARNING

- If coolant splashes in your eyes, thoroughly wash them with water and consult a doctor.
- If coolant splashes on your clothes, quickly wash it away with water and then with soap and water.
- If coolant is swallowed, induce vomiting and get immediate medical attention.

CAUTION:

- Adding water instead of coolant lowers the antifreeze content of the coolant. If water is used instead of coolant check, and if necessary, correct the antifreeze concentration of the coolant.
- Use only distilled water. However, if distilled water is not available, soft water may be used.
- If coolant comes into contact with painted surfaces, immediately wash them with water.
- Do not mix different types of antifreeze.





- 10.Turn the coolant drain cock ① to the "OFF" position ②.
- 11.Install:
- · radiator cap
- 12.Fill:
- coolant reservoir (with the recommended coolant to the maximum level mark (a))
- 13.Install:
- coolant reservoir cap
- 14.Start the engine, warm it up for several minutes, and then stop it.
- 15.Check:
- coolant level Refer to "CHECKING THE COOLANT LEVEL".

NOTE:

Before checking the coolant level, wait a few minutes until the coolant has settled.









EAS00108 CHASSIS

ADJUSTING THE FRONT BRAKE

- 1. Check:
- brake lever free play (a) Out of specification \rightarrow Adjust.



2 ~ 5 mm (0.08 ~ 0.20 in)

- 2. Adjust:
- brake lever free play

- a. Loosen the locknut (1).
- b. Turn the adjusting bolt (2) in direction (a) or (b) until the specified brake lever free play is obtained.

| Direction ⓐ | Brake lever free play is increased. |
|---------------|-------------------------------------|
| Direction (b) | Brake lever free play is decreased. |

c. Tighten the locknut.

A soft or spongy feeling in the brake lever can indicate the presence of air in the brake system. Before the vehicle is operated, the air must be removed by bleeding the brake system. Air in the brake system will considerably reduce braking performance and could result in loss of control and possibly an accident. Therefore, check and, if necessary, bleed the brake system.

CAUTION:

After adjusting the brake lever free play, make sure there is no brake drag.

.....











ADJUSTING THE REAR BRAKE

1. Check:

 brake pedal position (distance ⓐ from the top of the rider footrest to the top of the brake pedal) Out of specification → Adjust.



Brake pedal position (below the top of the rider footrest) 20 mm (0.79 in)

- 2. Adjust:
- brake pedal position
- ****
- a. Loosen the locknut ①.
- b. Turn the adjusting bolt ② in direction ③ or
 ⑤ until the specified brake pedal position is obtained.

| Direction (a) | Brake pedal is raised. |
|---------------|-------------------------|
| Direction (b) | Brake pedal is lowered. |

A WARNING

After adjusting the brake pedal position, check that the end \bigcirc of the adjusting bolt is visible through the hole \bigcirc .

c. Tighten the locknut 1 to specification.



Locknut 16 Nm (1.6 m • kg, 11 ft • lb)

A WARNING

A soft or spongy feeling in the brake pedal can indicate the presence of air in the brake system. Before the vehicle is operated, the air must be removed by bleeding the brake system. Air in the brake system will considerably reduce braking performance and could result in loss of control and possibly an accident. Therefore, check and, if necessary, bleed the brake system.

CAUTION:

After adjusting the brake pedal position, make sure there is no brake drag.



ADJUSTING THE REAR BRAKE/ CHECKING THE BRAKE FLUID LEVEL



- 3. Adjust:
- · rear brake light switch Refer to "ADJUSTING THE REAR BRAKE LIGHT SWITCH". EAS00115

CHECKING THE BRAKE FLUID LEVEL

1. Stand the motorcycle on a level surface.

NOTE:

- Place the motorcycle on a suitable stand.
- Make sure the motorcycle is upright.
- 2. Check:
 - brake fluid level Below the minimum level mark (a) \rightarrow Add the recommended brake fluid to the proper level.



Recommended brake fluid

A Front brake

B Rear brake

A WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

CAUTION

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

NOTE: __

In order to ensure a correct reading of the brake fluid level, make sure the top of the brake fluid reservoir is horizontal.









CHECKING THE BRAKE PADS

The following procedure applies to all of the brake pads.

- 1. Operate the brake.
- 2. Check:
- front brake pad
- rear brake pad

Wear indicators (1) almost touch the brake disc \rightarrow Replace the brake pads as a set. Refer to "REPLACING THE FRONT BRAKE PADS" and "REPLACING THE REAR BRAKE PADS" in chapter 7.



ADJUSTING THE REAR BRAKE LIGHT SWITCH

NOTE: _

The rear brake light switch is operated by movement of the brake pedal. The rear brake light switch is properly adjusted when the brake light comes on just before the braking effect starts.

- 1. Check:
- rear brake light operation timing Incorrect → Adjust.
- 2. Adjust:
- rear brake light operation timing
- ****
- a. Hold the main body ① of the rear brake light switch so that it does not rotate and turn the adjusting nut ② in direction ③ or ⑤ until the rear brake light comes on at the proper time.

| Direction ⓐ | Brake sooner | light | comes | on |
|---------------|-----------------|-------|-------|----|
| Direction (b) | Brake later. | light | comes | on |









CHECKING THE BRAKE HOSES

The following procedure applies to all of the brake hoses and brake hose clamps.

1. Check:

- brake hose ①
 Cracks/damage/wear
 - Cracks/damage/wear \rightarrow Replace.
- 2. Check:
- brake hose clamp
 Loose → Tighten the clamp bolt.
- 3. Hold the motorcycle upright and apply the brake several times.
- 4. Check:
- brake hose

Activate the brake several times.

Brake fluid leakage \rightarrow Replace the damaged hose.

Refer to "FRONT AND REAR BRAKES" in chapter 7.

BLEEDING THE HYDRAULIC BRAKE SYSTEM

Bleed the hydraulic brake system whenever:

- the system is disassembled,
- a brake hose is loosened, disconnected or replaced,
- the brake fluid level is very low,
- brake operation is faulty.

NOTE: _

- Be careful not to spill any brake fluid or allow the brake master cylinder reservoir or brake fluid reservoir to overflow.
- When bleeding the hydraulic brake system, make sure there is always enough brake fluid before applying the brake. Ignoring this precaution could allow air to enter the hydraulic brake system, considerably lengthening the bleeding procedure.
- If bleeding is difficult, it may be necessary to let the brake fluid settle for a few hours. Repeat the bleeding procedure when the tiny bubbles in the hose have disappeared.







- 1. Bleed:
- hydraulic brake system
- ****
- a. Fill the brake fluid reservoir to the proper level with the recommended brake fluid.
- b. Install the diaphragm (brake master cylinder reservoir or brake fluid reservoir).
- c. Connect a clear plastic hose ① tightly to the bleed screw ②.
- A Front
- B Rear
- d. Place the other end of the hose into a container.
- e. Slowly apply the brake several times.
- f. Fully squeeze the brake lever or fully depress the brake pedal and hold it in position.
- g. Loosen the bleed screw.

NOTE: .

Loosening the bleed screw will release the pressure and cause the brake lever to contact the throttle grip or the brake pedal to fully extend.

- h. Tighten the bleed screw and then release the brake lever or brake pedal.
- i. Repeat steps (e) to (h) until all of the air bubbles have disappeared from the brake fluid in the plastic hose.
- j. Tighten the bleed screw to specification.



Bleed screw 6 Nm (0.6 m • kg, 4.3 ft • lb)

k. Fill the brake fluid reservoir to the proper level with the recommended brake fluid. Refer to "CHECKING THE BRAKE FLUID LEVEL".

A WARNING

After bleeding the hydraulic brake system, check the brake operation.

.......

ADJUSTING THE SHIFT PEDAL/ CHECKING THE FINAL DRIVE OIL LEVEL





ADJUSTING THE SHIFT PEDAL

NOTE: .

The shift pedal position is determined by the installed shift rod length (a).

- 1. Check:
- installed shift rod length ⓐ Incorrect → Adjust.



Installed shift rod length 30 ~ 34 mm (1.18 ~ 1.34 in)

- 2. Adjust:
- installed shift rod length (a)

- a. Loosen both locknuts ①.
- b. Turn the adjusting bolt ② in direction ⑤ or
 ⓒ to obtain the correct shift pedal position.

| Direction (b) | Installed shift rod length increases. |
|---------------|---------------------------------------|
| Direction © | Installed shift rod length decreases. |

- c. Tighten both locknuts.
- d. Make sure the installed shift rod length is within specification.

EAS00144

CHECKING THE FINAL DRIVE OIL LEVEL

1. Stand the motorcycle on a level surface.

NOTE: .

- Place the motorcycle on a suitable stand.
- Make sure the motorcycle is upright.

CHECKING THE FINAL DRIVE OIL LEVEL/ CHANGING THE FINAL DRIVE OIL



- 2. Remove:
 - final drive housing oil filler bolt (1)
- 3. Check:
- final drive oil level
 The final drive oil level should be to the bottom brim ② of the filler hole.
 Below the top brim → Add the recom-

Below the top brim \rightarrow Add the recommended final drive oil to the proper level.



Recommended oil SAE 80 hypoid gear oil graded "GL-4" multi-purpose SAE 80W90 hypoid gear oil

- 4. Install:
- final drive housing oil filler bolt







CHANGING THE FINAL DRIVE OIL

- 1. Place a container under the final drive housing.
- 2. Remove:
- final drive housing oil filler bolt
- final drive housing oil drain bolt ①
 Completely drain the final drive housing of its oil.
- 3. Check:
- final drive housing oil drain bolt gasket Damage \rightarrow Replace.
- 4. Install:
- final drive housing oil drain bolt
 23 Nm (2.3 m · kg, 17 ft · lb)
- 5. Fill:
- final drive housing (with the specified amount of the recommended final drive oil)

Quantity 0.2 L (0

0.2 L (0.18 Imp qt, 0.21 US qt)

Refer to "CHECKING THE FINAL DRIVE OIL LEVEL".



CHECKING AND ADJUSTING THE STEERING HEAD

1. Stand the motorcycle on a level surface.

A WARNING

Securely support the motorcycle so that there is no danger of it falling over.

NOTE:

Place the motorcycle on a suitable stand so that the front wheel is elevated.

- 2. Check:
- steering head Grasp the bottom of the front fork legs and gently rock the front fork. Binding/looseness → Adjust the steering head.
 Remove:
 - . Remove.
- headlight body bracket bolt
- flasher light bracket
- handlebar holder assembly
- 4. Loosen:
- upper bracket pinch bolts ①
- 5. Remove:
- steering stem nut 2
- washer
- upper bracket ③
- 6. Adjust:
- steering head

- a. Remove the lock washer ①, the upper ring nut ②, and the rubber washer ③.
- b. Loosen the lower ring nut ④ and then tighten it to specification with a ring nut wrench ⑤.

NOTE:

Set the torque wrench at a right angle to the ring nut wrench.








CHECKING AND ADJUSTING THE STEERING HEAD



c. Loosen the lower ring nut completely, then tighten it to specification.

A WARNING

Do not overtighten the lower ring nut.



Lower ring nut (final tightening torque) 3.0 Nm (0.3 m • kg, 22 ft • lb)

d. Check the steering head for looseness or binding by turning the front fork all the way in both directions. If any binding is felt, remove the lower bracket and check the upper and lower bearings.

Refer to "STEERING HEAD" and "HAN-DLEBAR" in chapter 7.



- e. Install the rubber washer ③.
- f. Install the upper ring nut 2.
- g. Finger tighten the upper ring nut ②, then align the slots of both ring nuts. If necessary, hold the lower ring nut and tighten the upper ring nut until their slots are aligned.
- h. Install the lock washer ①.

NOTE: _

Make sure the lock washer tabs sit correctly in the ring nut slots.

- 7. Install:
- upper bracket
- washer
- steering stem nut

🔌 110 Nm (11.0 m · kg, 80 ft · lb)

- 8. Tighten:
- upper bracket pinch bolt

🔌 20 Nm (2.0 m · kg, 14 ft · lb)

- 9. Install:
- handlebar holder assembly
- flasher light bracket
- headlight body bracket bolt

🔌 40 Nm (4.0 m · kg, 29 ft · lb)

CHECKING THE FRONT FORK/ ADJUSTING THE FRONT FORK LEGS



CHECKING THE FRONT FORK

1. Stand the motorcycle on a level surface.

Securely support the motorcycle so that there is no danger of it falling over.

- 2. Check:
- inner tube Damage/scratches \rightarrow Replace.
- oil seal

3. Hold the motorcycle upright and apply the front brake.



- 4. Check:
- front fork operation

Push down hard on the handlebars several times and check if the front fork rebounds smoothly.

Rough movement \rightarrow Repair. Refer to "FRONT FORK" in chapter 7.

ADJUSTING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

- Always adjust both front fork legs evenly. Uneven adjustment can result in poor handling and loss of stability.
- Securely support the motorcycle so that there is no danger of it falling over.

Spring preload

1. Place the motorcycle on a suitable stand so that the front wheel is elevated.

NOTE: _

When checking and adjusting the air pressure, there should be no weight on the front end of the motorcycle.

- 2. Remove:
- · front fork air valve cap

ADJUSTING THE FRONT FORK LEGS/ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLIES





- 3. Regulate:
- air pressure

a. Check the front fork leg air pressure with an air pressure gauge ①.

| Supplying air | Spring pr increased (is harder). | eload is suspension |
|---------------|---|------------------------|
| Releasing air | Spring pr decreased (is softer). | eload is suspension |

Air pressure Standard 40 kPa (0.4 kg/cm², 5.8 psi) Maximum 100 kPa (1.0 kg/cm², 14.2 psi)

The difference in air pressure between the left and right front fork legs should not exceed 10 kPa (0.1 kg/cm², 0.1 bar).

CAUTION:

Exceeding the maximum air pressure may damage the oil seal.

4. Install:

• front fork air valve cap

ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLIES

The following procedure applies to both of the rear shock absorber assemblies.

- Securely support the motorcycle so that there is no danger of it falling over.
- Always adjust both rear shock absorber assemblies evenly. Uneven adjustment can result in poor handling and loss of stability.



ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLIES





Spring preload

CAUTION:

Never go beyond the maximum or minimum adjustment positions.

- 1. Adjust:
- · spring preload

- a. Insert a screwdriver into the hole ① in the spring seat.
- b. Turn the spring seat ② in direction ③ or ⑤.

| Direction (a) | Spring preload is increased (suspension is harder). |
|---------------|---|
| Direction (b) | Spring preload is decreased (suspension is softer). |

Adjusting positions Minimum: 1 Standard: 1 Maximum: 5

Rebound damping

CAUTION

Never go beyond the maximum or minimum adjustment positions.

- 1. Adjust:
- rebound damping
- ****
- a. Turn the adjusting knob ① in direction ⓐ or ⑤.

| | Rebound damping | is |
|---------------|-----------------------|----|
| Direction (a) | increased (suspension | is |
| | harder). | |
| | Rebound damping | is |
| Direction (b) | decreased (suspension | is |
| | softer). | |

Adjusting positions Minimum: 1 Standard: 1 Maximum: 4







CHECKING THE TIRES

The following procedure applies to both of the tires.

1. Measure:

• tire pressure

Out of specification \rightarrow Regulate.

- The tire pressure should only be checked and regulated when the tire temperature equals the ambient air temperature.
- The tire pressure and the suspension must be adjusted according to the total weight (including cargo, rider, passenger and accessories) and the anticipated riding speed.
- Operation of an overloaded motorcycle could cause tire damage, an accident or an injury.

NEVER OVERLOAD THE MOTORCYCLE.

| Basic weight (with oil and a full fuel tank) | 283 kg (624 lb) 284 kg (626 lb) (for California) | | |
|---|--|--|--|
| Maximum load* | 216 kg (476 lb) 215 kg (474 lb) (for California) | | |
| Cold tire pressure | Front | Rear | |
| Up to 90 kg load* | 225 kPa (2.25 kgf/cm², 33 psi) | 225 kPa (2.25 kgf/cm², 33 psi) | |
| 90 kg – maxi- mum load* | 225 kPa (2.25 kgf/cm², 33 psi) | 250 kPa (2.5 kgf/cm², 36 psi) | |
| High-speed riding | 225 kPa (2.25 kgf/cm ² , 33 psi) | 250 kPa (2.5 kgf/cm ² , 36 psi) | |

* total of cargo, rider, passenger and accessories

A WARNING

It is dangerous to ride with a worn-out tire. When the tire tread reaches the wear limit, replace the tire immediately.











- 2. Check:
- tire surfaces Damage/wear \rightarrow Replace the tire.



Minimum tire tread depth 1.0 mm (0.04 in)

① Tire tread depth

② Sidewall

③ Wear indicator

- Do not use a tubeless tire on a wheel designed only for tube tires to avoid tire failure and personal injury from sudden deflation.
- When using tube tires, be sure to install the correct tube.
- Always replace a new tube tire and a new tube as a set.
- To avoid pinching the tube, make sure the wheel rim band and tube are centered in the wheel groove.
- Patching a punctured tube is not recommended. If it is absolutely necessary to do so, use great care and replace the tube as soon as possible with a good quality replacement.

A Tire

B Wheel

| Tube wheel | Tube tire only |
|----------------|--------------------------|
| Tubeless wheel | Tube or tubeless tire |

 After extensive tests, the tires listed below have been approved by Yamaha Motor Co., Ltd. for this model. The front and rear tires should always be by the same manufacturer and of the same design. No guarantee concerning handling characteristics can be given if a tire combination other than one approved by Yamaha is used on this motorcycle.

CHECKING THE TIRES/ CHECKING THE WHEELS



Front tire

| Manufacturer | Model | Size |
|--------------|--------|---------------------|
| BRIDGESTON | G525AW | 110/90-18 (61 V) |
| DUNLOP | F20 | 110/90-18 (61 V) |

Rear tire

| Manufacturer | Model | Size |
|--------------|--------|------------------------|
| BRIDGESTON | G526BW | 150/90- 15MC (74 V) |
| DUNLOP | K525 | 150/90- 15MC (74 V) |

A WARNING

- New tires have a relatively low grip on the road surface until they have been slightly worn. Therefore, approximately 100 km should be traveled at normal speed before any high-speed riding is done.
- After a tire has been repaired or replaced, be sure to tighten the tire air valve stem nut ① and locknut ② to specification.

NOTE: _

For tires with a direction of rotation mark ③:

- Install the tire with the mark pointing in the direction of wheel rotation.
- Align the mark ④ with the valve installation point.

Tire air valve stem Vlave stem nut 1.6 Nm (0.16 m • kg, 11 ft • lb) Valve stem locknut 1.6 Nm (0.16 m • kg, 11 ft • lb)

CHECKING THE WHEELS

The following procedure applies to both of the wheels.

- 1. Check:
- wheel
 - Damage/out-of-round \rightarrow Replace.

A WARNING

Never attempt to make any repairs to the wheel.





CHECKING THE WHEELS/ CHECKING AND LUBRICATING THE CABLES/ LUBRICATING THE LEVERS AND PEDALS



NOTE: _

After a tire or wheel has been changed or replaced, always balance the wheel.

CHECKING AND LUBRICATING THE CABLES

The following procedure applies to all of the cable sheaths and cables.

A WARNING

Damaged cable sheaths may cause the cable to corrode and interfere with its movement. Replace damaged cable sheaths and cables as soon as possible.

- 1. Check:
- cable sheath
 Damage → Replace.
- 2. Check:
- cable operation Rough movement \rightarrow Lubricate.

Recommended lubricant Engine oil or a suitable cable lubricant

NOTE: _

Hold the cable end upright and pour a few drops of lubricant into the cable sheath or use a suitable lubricating device.

LUBRICATING THE LEVERS AND PEDALS

Lubricate the pivoting point and metal-to-metal moving parts of the levers and pedals.

Recommended lubricant Lithium soap base grease

LUBRICATING THE SIDESTAND/ LUBRICATING THE CENTERSTAND/ LUBRICATING THE REAR SUSPENSION



LUBRICATING THE SIDESTAND

Lubricate the pivoting point and metal-to-metal moving parts of the sidestand.



LUBRICATING THE CENTERSTAND

Lubricate the pivoting point and metal-to-metal moving parts of the centerstand.



Recommended lubricant Lithium soap base grease



LUBRICATING THE REAR SUSPENSION

Lubricate the pivoting point and metal-to-metal moving parts of the rear suspension.



Recommended lubricant Molybdenum disulfide grease



ELECTRICAL SYSTEM CHECKING THE BATTERY

A WARNING

Batteries generate explosive hydrogen gas and contain electrolyte which is made of poisonous and highly caustic sulfuric acid. Therefore, always follow these preventive measures:

- Wear protective eye gear when handling or working near batteries.
- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks or open flames (e.g., welding equipment, lighted cigarettes).
- DO NOT SMOKE when charging or handling batteries.
- KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.
- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.

FIRST AID IN CASE OF BODILY CONTACT: EXTERNAL

- Skin Wash with water.
- Eyes Flush with water for 15 minutes and get immediate medical attention.

INTERNAL

- Drink large quantities of water or milk followed with milk of magnesia, beaten egg or vegetable oil. Get immediate medical attention.
- 1. Remove:
- rider seat
 - Refer to "SEATS AND SIDE COVERS".
- 2. Disconnect:
- battery leads (from the battery terminals)

CAUTION:

First, disconnect the negative battery lead ①, and then the positive lead ②.

- 3. Remove:
- battery



CHECKING THE BATTERY





- 4. Check:
- electrolyte level

The electrolyte level should be between the minimum level mark ① and the maximum level mark ②.

Below the minimum level mark \rightarrow Add distilled water to the proper level.

CAUTION

Add only distilled water. Tap water contains minerals which are harmful to the battery.

- 5. Check:
- specific gravity

Less than $1.280 \rightarrow$ Recharge the battery.



Specific gravity 1.280 at 20 °C (68 °F)

- 6. Charge:
- battery

Battery charging amperage and time 1.4 amps/10 hrs

Do not quick charge a battery.

CAUTION:

- Loosen the battery sealing caps.
- Make sure the battery breather hose and battery vent are free of obstructions.
- To ensure maximum performance, always charge a new battery before using it.
- Do not use a high-rate battery charger. They force a high-amperage current into the battery quickly and can cause battery overheating and battery plate damage.
- If it is impossible to regulate the charging current on the battery charger, be careful not to overcharge the battery.
- When charging a battery, be sure to remove it from the motorcycle. (If charging has to be done with the battery mounted on the motorcycle, disconnect the negative lead from the battery terminal.)



CHECKING THE BATTERY



- To reduce the chance of sparks, do not plug in the battery charger until the battery charger leads are connected to the battery.
- Before removing the battery charger lead clips from the battery terminals, be sure to turn off the battery charger.
- Make sure the battery charger lead clips are in full contact with the battery terminal and that they are not shorted. A corroded battery charger lead clip may generate heat in the contact area and a weak clip spring may cause sparks.
- If the battery becomes hot to the touch at any time during the charging process, disconnect the battery charger and let the battery cool before reconnecting it. Hot batteries can explode!

NOTE: _

Replace the battery whenever:

- battery voltage does not rise to specification or bubbles fail to rise during charging,
- sulphation of one or more battery cells occurs (as indicated by the battery plates turning white or material accumulating in the bottom of the battery cell),
- specific gravity readings after a long, slow charge indicate that one battery cell's charge is lower than the rest,
- warpage or buckling of the battery plates or insulators is evident.
- 7. Check:
- battery breather hose and battery vent Obstruction → Clean.
 Damage → Replace.
- 8. Connect:
- battery breather hose ①
- 9. Install:
- battery
- 10.Connect:
- battery breather hose ①





CAUTION:

- When checking the battery, make sure the battery breather hose is properly installed and routed correctly. If the battery breather hose is positioned so as to allow electrolyte or hydrogen gas from the battery to contact the frame, the motorcycle and its finish may be damaged.
- Make sure the battery breather hose is properly routed away from the drive chain and from below the swingarm.

11.Check:

battery terminals
 Dirt → Clean with a wire brush.
 Loose connection → Connect properly.





- 12.Connect:
- battery leads (to the battery terminals)

CAUTION:

First, connect the positive battery lead (1), and then the negative lead (2).

- 13.Lubricate:
- battery terminals



Recommended lubricant Dielectric grease

14.Install:

 rider seat Refer to "SEATS AND SIDE COVERS".



CHECKING THE FUSES

The following procedure applies to all of the fuses.

CAUTION:

To avoid a short circuit, always set the main switch to "OFF" when checking or replacing a fuse.

- 1. Remove:
- rider seat Refer to "SEATS AND SIDE COVERS".
- 2. Check:
- continuity

a. Connect the pocket tester to the fuse and check the continuity.

NOTE:

Set the pocket tester selector to " $\Omega \times 1$ ".



Pocket tester YU-03112

b. If the pocket tester indicates " ∞ ", replace the fuse.

- 3. Replace:
- blown fuse
- ****
- a. Set the main switch to "OFF".
- b. Install a new fuse of the correct amperage.
- c. Set on the switches to verify if the electrical circuit is operational.
- d. If the fuse immediately blows again, check the electrical circuit.

CHECKING THE FUSES/ REPLACING THE HEADLIGHT BULB







| Items | Amperage rating | Q'ty |
|----------------------------|--------------------|------|
| Main fuse | 30 A | 1 |
| Headlight fuse | 15 A | 1 |
| Signaling system fuse | 10 A | 1 |
| Ignition fuse | 10 A | 1 |
| Radiator fan motor fuse | 10 A | 1 |
| Reserve fuse | 30 A | 1 |
| Reserve fuse | 15 A | 1 |
| Reserve fuse | 10 A | 1 |

A WARNING

Never use a fuse with an amperage rating other than that specified. Improvising or using a fuse with the wrong amperage rating may cause extensive damage to the electrical system, cause the lighting and ignition systems to malfunction and could possibly cause a fire.

- 4. Install:
- rider seat Refer to "SEATS AND SIDE COVERS".



REPLACING THE HEADLIGHT BULB

- 1. Remove:
- screw (1)
- headlight lens unit 2

REPLACING THE HEADLIGHT BULB







- 2. Disconnect:
- headlight coupler (1)
- 3. Remove:
- headlight bulb holder cover ②

- 4. Detach:
- headlight bulb holder ①
- 5. Remove:
- headlight bulb (2)

A WARNING

Since the headlight bulb gets extremely hot, keep flammable products and your hands away from the bulb until it has cooled down.

- 6. Install:
- headlight bulb
 Secure the new headlight bulb with the headlight bulb holder.

CAUTION:

Avoid touching the glass part of the headlight bulb to keep it free from oil, otherwise the transparency of the glass, the life of the bulb and the luminous flux will be adversely affected. If the headlight bulb gets soiled, thoroughly clean it with a cloth moistened with alcohol or lacquer thinner.

- 7. Attach:
- headlight bulb holder
- 8. Install:
- headlight bulb holder cover
- 9. Connect:
- headlight coupler
- 10.Install:
- headlight lens unit
- screws



ADJUSTING THE HEADLIGHT BEAM



ADJUSTING THE HEADLIGHT BEAM

- 1. Adjust:
- headlight beam (vertically)

a. Turn the adjusting screw ① in direction ⓐ or ⓑ.

| Direction ⓐ | Headlight raised. | beam | is |
|---------------|--------------------|---------|------|
| Direction (b) | Headlight ered. | beam is | low- |





- 2. Adjust:
- headlight beam (horizontally)
- *****
- a. Turn the adjusting screw in direction or b.

| Direction ⓐ | Headlight beam to the right. | moves |
|---------------|------------------------------|-------|
| Direction (b) | Headlight beam to the left. | moves |



ENGINE

ENGINE REMOVAL EXHAUST PIPES, MUFFLER AND AIR BAFFLE PLATES



| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------------|------|--|
| | Removing the exhaust pipes, muf- | | Remove the parts in the order listed. |
| | fler and air baffle plates | | |
| | Carburetors | | Refer to "REMOVING THE CARBURE- |
| | | | TOR" in chapter 6. |
| | Radiator | | Refer to "REMOVING THE RADIATOR" |
| | | | in chapter 5. |
| | Middle gear case cover | | Refer to "SHIFT SHAFT". |
| 1 | Air baffle plate (front) | 1 | |
| 2 | Plate cover | 2 | |
| 3 | Air baffle plate (rear) | 1 | |
| 4 | Front exhaust pipes | 2 | |
| 5 | Muffler | 1 | |
| 6 | Rear exhaust pipes | 2 | |
| 7 | Gaskets | 11 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |



BRAKE PEDAL, FOOTREST (RIGHT), MASTER CYLINDER AND GROUND LEAD

ENGINE REMOVAL



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------------|------|--|
| | Removing the brake pedal, footrest | | Remove the parts in the order listed. |
| | (right), master cylinder and ground | | |
| | lead | | |
| 1 | Brake pedal | 1 | |
| 2 | Footrest (right) | 1 | |
| 3 | Rear brake hose | 1 | Disconnect. |
| 4 | Brake fluid reservoir hose | 1 | Disconnect. |
| 5 | Brake master cylinder | 1 | |
| 6 | Rear brake switch | 1 | |
| 7 | Ground lead | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |



LEADS, CABLES AND HOSES



ENGINE REMOVAL

| Order | Job/Part | Q'ty | Remarks |
|-------|--------------------------------|------|--|
| | Removing the leads, cables and | | Remove the parts in the order listed. |
| | hoses | | |
| 1 | Spark plug leads | 4 | Disconnect. |
| 2 | Vacuum hose | 1 | Disconnect. |
| 3 | Horn lead | 2 | Disconnect. |
| 4 | Starter lead (starter motor) | 1 | Disconnect. |
| 5 | Plastic locking tie | 1 | |
| 6 | Plastic band | 2 | |
| 7 | Starter lead (starter relay) | 1 | Disconnect. |
| 8 | Pickup coil coupler | 1 | Disconnect. |
| 9 | Neutral switch lead | 1 | Disconnect. |
| 10 | Oil level switch lead | 1 | Disconnect. |
| 11 | Rectifier/regulator coupler | 1 | Disconnect. |
| 12 | V-boost control cable | 1 | Disconnect. |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |



ENGINE REMOVAL

ENGINE MOUNTING BOLTS



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------|------|--|
| | Removing the engine | | Remove the parts in the order listed. |
| | | | NOTE: |
| | | | Place a suitable stand under the frame |
| | | | and engine. |
| | | | |
| | | | |
| | | | Securely support the motorcycle so |
| | | | there is no danger of it falling over. |
| | | | |
| 1 | Bolts (front-lower) | 2 | |
| 2 | Bolts (engine bracket) | 4 | |
| 3 | Engine bracket | 1 | |
| 4 | Nuts (front-upper) | 2 | |
| 5 | Bolts (rear) | 2 | |
| 6 | Bolts (down tube) | 4 | |



ENGINE REMOVAL



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------|------|---|
| 7 | Down tube (right side) | 1 | |
| 8 | Bolts (engine stay) | 2 | |
| 9 | Engine stay | 1 | |
| 10 | Engine assembly | 1 | NOTE: |
| | | | Remove the engine assembly from the right side of the motorcycle. |
| | | | For installation, reverse the removal pro- |

ENGINE REMOVAL









EAS00192 INSTALLING THE ENGINE

- 1. Install:
- engine stay ①
- bolt (engine stay) ②
 - 16 Nm (1.6 m · kg, 11 ft · lb)
- down tube (right) ③
 bolt (down tube) ④
 - 45 Nm (4.5 m · kg, 32 ft · lb)
- bolt (rear) (5) 🔀 70 Nm (7.0 m · kg, 50 ft · lb)
- nut (front-upper) 6
 - 🔌 42 Nm (4.2 m · kg, 30 ft · lb)
- engine bracket ⑦
- bolt (engine bracket) (8)
 - 🔌 16 Nm (1.6 m · kg, 11 ft · lb)
- bolt (front-lower) (9)
 ¥ 42 Nm (4.2 m · kg, 30 ft · lb)

NOTE: .

Do not fully tighten the bolts.

- 2. Install:
- shift pedal link (1)
 - 🔌 10 Nm (1.0 m · kg, 7.2 ft · lb)

NOTE:

- Align the punch mark (a) in the shift shaft with the slot (b) in the shift pedal link.
- Align the bottom edge of the shift pedal with the mark on the frame-to-swingarm bracket.



CAMSHAFTS

CYLINDER HEAD COVERS

000



| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|--|
| | Removing the cylinder head covers | | Remove the parts in the order listed. |
| | | | Stand the motorcycle on a level surface. |
| | | | |
| | | | Securely support the motorcycle so there is no danger of it falling over. |
| | Top cover and covers | | Refer to "TOP COVER AND COVERS" in chapter 3. |
| | Air filter case and electrical components board | | Refer to "AIR FILTER CASE AND ELEC- TRICAL COMPONENTS BOARD" in chapter 3. |
| | Carburetors | | Refer to "REMOVING THE CARBURE- TOR" in chapter 6. |
| | Coolant | | Drain. Refer to "CHANGING THE COOLANT" in chapter 3. |





| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------------|------|--|
| 1 | Spark plug cap | 4 | Disconnect. |
| 2 | Coolant hoses (to cylinder head) | 2 | Disconnect. |
| 3 | Spark plugs | 4 | |
| 4 | Cylinder head covers bolts | 16 | |
| 5 | Cylinder head covers | 2 | |
| 6 | Cylinder head covers gaskets | 2 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |

ENG

CAMSHAFTS

EAS00196



| Order | Job/Part | Q'ty | Remarks |
|-------|--------------------------|------|--|
| | Removing the camshafts | | Remove the parts in the order listed. |
| | Cylinder head covers | | Refer to "CYLINDER HEAD COVERS". |
| 1 | Crankcase cover plate | 1 | |
| 2 | Timing plug | 1 | |
| 3 | Tensioners cap bolts | 2 | |
| 4 | Timing chain tensioners | 2 | |
| 5 | Gaskets | 2 | |
| 6 | Timing chain guides | 4 | Refer to "Rear cylinder". |
| 7 | Camshaft sprockets bolts | 8 | |
| 8 | Camshaft caps | 16 | |
| 9 | Camshafts | 4 | |
| 10 | Camshaft sprockets | 4 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |







REMOVING THE CAMSHAFTS

- 1. Remove:
- timing mark accessing screw (1)
- crankshaft end cover 2
- 2. Align:
- "T1" mark on the flywheel (with the stationary pointer on the crankcase cover)

•••••

- a. Turn the crankshaft counterclockwise.
- b. When piston #1 is at TDC on the compression stroke, align the "T1" mark (a) with the stationary pointer (b).

NOTE: _

TDC on the compression stroke can be found when the camshaft lobes are turned away from each other.

- 3. Remove:
- timing chain guide (top side)





- 4. Loosen:
- camshaft sprocket bolts ①

- 5. Loosen:
- cap bolt ①
- 6. Remove:
- timing chain tensioner 2
- gasket





- 7. Remove:
- timing chain guide (exhaust side)
- camshaft caps (1)

dowel pins

NOTE: _

For reference during installation, put identification marks on each camshaft cap.

CAUTION:

To prevent damage to the cylinder head, camshafts or camshaft caps, loosen the camshaft cap bolts in stages and in a crisscross pattern, working from the outside in.







- 8. Remove:
- camshafts

NOTE: _

To prevent the timing chain from falling into the crankcase, fasten it with a wire (1).

- 9. Remove:
- camshaft sprockets
- EAS00204

CHECKING THE CAMSHAFTS

- 1. Check:
- camshaft lobes Blue discoloration/pitting/scratches \rightarrow Replace the camshaft.
- 2. Measure:
- camshaft lobe dimensions (a) and (b) Out of specification \rightarrow Replace the camshaft.





- 3. Measure:
- camshaft runout Out of specification \rightarrow Replace.



Camshaft runout limit 0.03 mm (0.0012 in)

- 4. Measure:
- camshaft-journal-to-camshaft-cap clearance

Out of specification \rightarrow Measure the camshaft journal diameter.

Camshaft-journal-to-camshaftcap clearance 0.020 ~ 0.054 mm (0.0008 ~ 0.0021 in)

- a. Install the camshaft into the cylinder head (without the dowel pins and camshaft caps).
- b. Position a strip of Plastigauge[®] ① onto the camshaft journal as shown.
- c. Install the dowel pins and camshaft caps.

NOTE: .

- Tighten the camshaft cap bolts in stages and in a crisscross pattern, working from the inner caps out.
- Do not turn the camshaft when measuring the camshaft journal-to-camshaft cap clearance with the Plastigauge[®].



Camshaft cap bolt 10 Nm (1.0 m • kg, 7.2 ft • lb)

d. Remove the camshaft caps and then measure the width of the Plastigauge[®] ①.

.....

- 5. Measure:
 - camshaft journal diameter ⓐ
 - Out of specification \rightarrow Replace the camshaft.

Within specification \rightarrow Replace the cylinder head and the camshaft caps as a set.



Camshaft journal diameter 24.967 ~ 24.980 mm (0.9830 ~ 0.9835 in)











CHECKING THE TIMING CHAIN, CAMSHAFT SPROCKETS, AND TIMING CHAIN GUIDES

The following procedure applies to all of the camshaft sprockets and timing chain guides.

- 1. Check:
- timing chain
 Damage/stiffness → Replace the timing chain and camshaft sprockets as a set.
- 2. Check:
- camshaft sprocket

More than 1/4 tooth wear (a) \rightarrow Replace the camshaft sprockets and the timing chain as a set.

- (a) 1/4 tooth
- b Correct
- ① Timing chain roller
- ② Camshaft sprocket
- 3. Check:
- timing chain guide (exhaust side)
- timing chain guide (top side)
 Damage/wear → Replace the defective part(s).



CHECKING THE TIMING CHAIN TENSIONER

- 1. Check:
- timing chain tensioner
 Cracks/damage → Replace.
- one-way cam operation Rough movement → Replace the timing chain tensioner housing.
- 2. Check:
- cap bolt
- copper washer
- spring
- one-way cam
- gasket
- timing chain tensioner rod Damage/wear → Replace the defective part(s).





EAS00218 INSTALLING THE CAMSHAFTS

1. Align:

• "T1" marks on the flywheel (with the stationary pointer on the crankcase cover)

- a. Turn the crankshaft counterclockwise.
- b. When piston #1 is at TDC on the compression stroke, align the "T1" marks ① on the generator rotor with the stationary pointer ②.

CAUTION:

Do not turn the crankshaft when installing the camshaft to avoid damage or improper valve timing.

NOTE:

First, install the rear cylinder camshafts, camshaft sprockets, timing chain, and timing chain tensioner. Then, install the front cylinder camshafts and related parts.

4

Rear cylinder

- 1. Install:
- intake camshaft
- exhaust camshaft

CAUTION:

Do not turn the crankshaft when installing the camshafts to avoid damage or improper valve timing.

a. Install the camshaft sprockets onto the camshafts.

Refer to the camshaft sprocket installation steps below.

NOTE: .

Make sure the "REAR" marks 3 on the camshaft sprockets face away from the "IN" 4 and "EX" marks 5 on the camshafts.











b. First, install the exhaust camshaft, and then the intake camshaft.

NOTE: .

• Be sure to install the camshafts in the correct place as shown.

"IN" mark = intake camshaft

- "EX" mark = exhaust camshaft
- Make sure the timing marks (6) (o: small hole) in the camshaft face up.
- Be sure to keep the timing chain as tight as possible on the exhaust side.
- Remove the wire from the timing chain.

CAUTION:

Do not turn the camshaft, as damage could occur to the pistons and valves.

c. Install intake and exhaust camshaft caps #1, #3, and finally #4.

NOTE:

At this point, do not install intake camshaft cap #2, exhaust camshaft cap #2, and the timing chain guide (top side).

d. Align the mark (a) on the camshaft with the mark (b) camshaft cap.

NOTE:

Cylinder #1 is at TDC when the small hole in the camshaft is aligned with the camshaft cap mark.

- e. Lubricate the camshaft cap bolts with engine oil.
- f. Tighten the camshaft cap bolts.

NOTE:

- The camshaft caps are numbered from right to left.
- First, tighten intake and exhaust camshaft cap bolts #3, #1, and finally #4.
- Tighten the camshaft cap bolts in stages and in a crisscross pattern, working from the inner caps out.



CAUTION:

The camshaft cap bolts must be tightened evenly or damage to the cylinder head, camshaft caps, and camshafts will result.



Camshaft cap bolt 10 Nm (1.0 m • kg, 7.2 ft • lb)

g. Lubricate the camshaft bearing surfaces, camshaft lobes, and camshaft journals with engine oil.

- 2. Install:
- intake camshaft sprocket
- exhaust camshaft sprocket (onto the camshafts)

CAUTIONS

Do not turn the crankshaft when installing the camshaft sprockets to avoid damage or improper valve.

- 4
- Install the timing chain onto the intake camshaft sprocket.
- b. Install the intake camshaft sprocket with the "REAR" mark facing out, and then finger tighten the camshaft sprocket bolts.

NOTE:

Align the "IN" mark ① hole in the intake camshaft sprocket with the thread hole in the camshaft.

- c. Turn the intake camshaft so that the camshaft timing mark ② (o: small hole) is aligned with the camshaft cap mark ③.
- d. To remove the timing chain slack, force the intake camshaft counterclockwise.
- e. Install the timing chain onto the exhaust camshaft sprocket.
- f. Install the exhaust camshaft sprocket with the "REAR" mark facing out, and then finger tighten the camshaft sprocket bolts.

NOTE:

Align the "EX" mark hole in the exhaust camshaft sprocket with the thread hole in the camshaft.





- g. Turn the exhaust camshaft so that the mark(o: small hole) on the camshaft is aligned with the mark on the camshaft cap.
- h. To remove the timing chain slack, force the exhaust camshaft clockwise.
- i. Insert your finger into the timing chain tensioner hole and push the timing chain guide (intake side) in.
- j. When pushing the timing chain guide (intake side), make sure the camshaft cap marks and camshaft timing marks stay aligned.
- k. If the camshaft cap marks and camshaft timing marks are not aligned, change the meshing position of the camshaft sprockets and timing chain.



- 3. Install:
- timing chain tensioner
- *****
- a. Remove the cap bolt ①, washer ② and spring ③.
- Release the timing chain tensioner one-way cam ④.
- c. Install the timing chain tensioner and gasket(5) onto the cylinder block.

A WARNING

Always use a new gasket.



Timing chain tensioner bolt 12 Nm (1.2 m • kg, 18.7 ft • lb)

d. Install the spring ③, washer ②, and cap bolt ①.



20 Nm (2.0 m • kg, 14 ft • lb)

4. Turn:

- crankshaft
 (approved turns approved to real turns)
 - (several turns counterclockwise)







5. Check:

• TDC mark (a)

Make sure the TDC mark on the generator rotor is aligned with the stationary pointer b.

• camshaft timing punch mark © (o: small hole)

Make sure the punch marks in the camshafts are aligned with the marks 0 on the camshaft caps.

Out of alignment \rightarrow Adjust.

Refer to the camshaft installation steps above.

- 6. Tighten:
- camshaft sprocket bolts

🔌 24 Nm (2.4 m · kg, 17 ft · lb)

CAUTION:

Be sure to tighten the camshaft sprocket bolts to the specified torque to avoid the possibility of the bolts coming loose and damaging the engine.

- 7. Install:
- camshaft caps "I-2" ①
- camshaft caps "E-2" (2)
- timing chain guide (top side) ③

🔌 10 Nm (1.0 m · kg, 7.2 ft · lb)

- timing chain guide (exhaust side) ④
- 8. Lubricate:
- timing chain
- camshaft sprockets
- camshafts
- valve pads

Recommended lubricant Engine oil

Front cylinder

NOTE: _

When installing the front cylinder camshafts, repeat the rear cylinder camshaft installation procedure. However, note the following points.







- 1. Install:
- exhaust camshaft
- intake camshaft

- a. From the "T1" marks, turn the crankshaft counterclockwise 430° (i.e., 360° plus an additional 70°).
- b. When piston #2 is at TDC on the compression stroke, align the "T2" mark (a) with the stationary pointer (b).
- c. Install the camshaft sprockets onto the camshafts.

Refer to the camshaft sprocket installation steps below.

NOTE: .

Make sure the "FRONT" marks ① on the camshaft sprockets face away from the "IN" ② and "EX" marks ③ on the camshafts.

d. Turn the camshafts by hand so that the camshaft timing marks (o: big hole) face up.

- 2. Install:
- intake camshaft sprocket
- exhaust camshaft sprocket (onto the camshafts)

- a. Align the "T2" mark on the generator rotor with the stationary pointer.
- b. Install the camshaft sprocket with the "FRONT" mark facing out, and then finger tighten the camshaft sprocket bolts.
- c. Turn the intake and exhaust camshafts and align the camshaft timing marks (o: big hole) with the camshaft cap marks.

- 3. Measure:
- valve clearance Out of specification → Adjust. Refer to "ADJUSTING THE VALVE CLEARANCE" in chapter 3.


CAMSHAFTS

- 4. Install:
- timing mark accessing screw (1)
 crankshaft end cover (2)

🔌 7 Nm (0.7 m · kg, 5.1 ft · lb)





CYLINDER HEADS

CYLINDER HEADS



| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------|------|--|
| | Removing the cylinder head | | Remove the parts in the order listed. |
| | Engine assembly | | Refer to "ENGINE REMOVAL". |
| | Cylinder head covers | | Refer to "CYLINDER HEAD COVERS". |
| | Camshafts | | Refer to "CAMSHAFTS". |
| 1 | Intake manifold | 2 | |
| 2 | Lock pins | 2 | |
| 3 | Water jacket joints | 2 | |
| 4 | Oil delivery pipes | 2 | |
| 5 | Cylinder heads | 2 | |
| 6 | Timing chain dampers | 2 | |
| 7 | Gaskets (cylinder heads) | 2 | |
| 8 | Dowel pins | 4 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |





REMOVING THE CYLINDER HEADS

- 1. Remove:
- cylinder head nuts

NOTE:

- Loosen the nuts in the proper sequence as shown.
- Loosen each nut 1/2 of a turn at a time. After all of the nuts are fully loosened, remove them.



CHECKING THE V-BOOST

- 1. Check:
- V-boost body Dirt → Clean.
 Wash the V-boost body in a petroleum based solvent.
- butterfly valves ①
 Damage/wear → Replace the V-boost assembly.

ADJUSTING THE BUTTERFLY SHAFT LEVER-TO-ADJUSTING BOLT CLEARANCE

NOTE: _

This adjustment should only be made when replacing the following part(s).

- servomotor
- control cable
- control cable joint
- carburetor joint
- 1. Set the main switch to "ON".



CYLINDER HEADS

- 2. Measure:
- butterfly shaft lever-to-adjusting bolt clearance ⓐ

Out of specification \rightarrow Adjust.





Butterfly shaft lever-to-adjusting bolt clearance 0.2 ~ 0.4 mm (0.008 ~ 0.016 in)

- ① Butterfly shaft lever
- ② Adjusting bolt
- 3. Adjust:
- butterfly shaft lever-to-adjusting bolt clearance

NOTE: _____

Do not loosen the locknut ③ at this stage of adjustment.

- a. Loosen the lock bolt ④.
- b. Set the main switch to "ON".

NOTE:

By performing these steps the proper tension of the control cable 5 can be obtained with the spring 6 located in the control cable joint 7.

c. Tighten the lock bolt to the specified torque.



Lock bolt 3.5 Nm (0.35 m • kg, 2.5 ft • lb)

- d. Measure the clearance again.
- e. If the butterfly shaft lever-to-adjusting bolt clearance is still out of specification, perform the following steps.
- f. Loosen the locknut ③.
- g. Turn the adjusting bolt ② clockwise or counterclockwise until the specified clearance is obtained.
- h. Tighten the locknut ③.

NOTE: .

Apply locking agent (LOCTITE®) to the lock-nut.



SYNCHRONIZING THE V-BOOST

CYLINDER HEADS

NOTE:

Before synchronizing the V-boost, the butterfly shaft lever-to-adjusting bolt clearance should be adjusted properly.

- 1. Measure:
- butterfly shaft lever-to-adjusting bolt clearance (a)

Out of specification \rightarrow Adjust.

Butterfly shaft lever-to-adjusting bolt clearance 0.3 ~ 0.5 mm (0.012 ~ 0.020 in)

- ① Butterfly shaft lever
- ② Adjusting bolt
- 2. Adjust:
- butterfly shaft lever-to-adjusting bolt clearance

- a. Loosen the locknut ③.
- b. Turn the adjusting bolt ② clockwise or counterclockwise until the specified clearance is obtained.
- c. Tighten the locknut.

NOTE: _

Apply locking agent (LOCTITE®) to the lock-nut.



CHECKING THE CYLINDER HEADS

The following procedure applies to all of the cylinder heads.

- 1. Eliminate:
- combustion chamber carbon deposits (with a rounded scraper)

NOTE: _

Do not use a sharp instrument to avoid damaging or scratching:

- spark plug bore threads
- valve seats





- 2. Check:
- cylinder head
 Damage/scratches → Replace.
- cylinder head water jacket ①
 Mineral deposits/rust → Eliminate.
- 3. Measure:
- cylinder head warpage Out of specification → Resurface the cylinder head.



Maximum cylinder head warpage 0.03 mm (0.0012 in)

- a. Place a straightedge ① and a thickness gauge ② across the cylinder head.
- b. Measure the warpage.
- c. If the limit is exceeded, resurface the cylinder head as follows.

CYLINDER HEADS



d. Place a 400 ~ 600 grit wet sandpaper on the surface plate and resurface the cylinder head using a figure-eight sanding pattern.

NOTE: _

To ensure an even surface, rotate the cylinder head several times.

INSTALLING THE CYLINDER HEAD

- 1. Install:
- timing chain dampers ①
- 2. Install:
- dowel pins ②
- gasket ③ New

NOTE: _

The "HEAD" mark (a) on the gasket must face up.

- 3. Install:
- cylinder head ①

NOTE: _

Pass the timing chain ② through the timing chain cavity.

- 4. Tighten:
- cylinder head nuts

🔌 43 Nm (4.3 m · kg, 31 ft · lb)

NOTE:

- Lubricate the cylinder head nuts with engine oil.
- Tighten the cylinder head nuts in the proper tightening sequence as shown and torque them in two stages.
- 5. Install:
- exhaust camshaft
- intake camshaft Refer to "INSTALLING THE CAMSHAFTS".







VALVES AND VALVE SPRINGS



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------|------|--|
| | Removing the valves and valve | | Remove the parts in the order listed. |
| | springs | | |
| | Engine assembly | | Refer to "ENGINE REMOVAL". |
| | Camshafts | | Refer to "CAMSHAFTS". |
| I | Cylinder heads | | Refer to "CYLINDER HEADS". |
| 1 | Valve pads | 16 | |
| 2 | Valve lifters | 16 | |
| 3 | Valve cotters | 32 | |
| 4 | Spring retainer | 16 | |
| 5 | Outer valve springs | 16 | |
| 6 | Inner valve springs | 16 | |
| 7 | Valves (intake/exhaust) | 8/8 | |
| 8 | Spring seat | 16 | |
| 9 | Oil seal | 16 | |
| 10 | Valve guide | 16 | |
| I | | | For installation, reverse the removal pro- |
| l | | | cedure. |



REMOVING THE VALVES

The following procedure applies to all of the valves and related components.

NOTE:

Before removing the internal parts of the cylinder head (e.g., valves, valve springs, valve seats), make sure the valves properly seal.

- 1. Remove:
- valve pad ①
- valve lifter 2

NOTE: _

Make a note of the position of each valve lifter (2) and valve pad (1) so that they can be reinstalled in their original place.

- 2. Check:
- valve (for leakage) Leakage at the valve seat → Check the valve face, valve seat, and valve seat width. Refer to "CHECKING THE VALVE SEATS".

- a. Pour a clean solvent (a) into the intake and exhaust ports.
- b. Check that the valves properly seal. There should be no leakage at the valve seat (1).



- 3. Remove:
- valve cotters ①

NOTE:

Remove the valve cotters by compressing the valve springs with the valve spring compressor (2) and attachment (3).







VALVES AND VALVE SPRINGS





- 4. Remove:
- spring retainer (1)
- inner valve springs ②
- \bullet outer valve springs 3
- valve ④
- spring seat (5)
- \bullet oil seal 6

NOTE: _

Identify the position of each part very carefully so that it can be reinstalled in its original place.



CHECKING THE VALVES AND VALVE GUIDES

The following procedure applies to all of the valves and valve guides.

- 1. Measure:
- valve-stem-to-valve-guide clearance

Valve-stem-to-valve-guide clearance = Valve guide inside diameter (a) – Valve stem diameter (b)

Out of specification \rightarrow Replace the valve guide.













- 2. Replace:
- valve guide
- NOTE: _____

To ease valve guide removal and installation, and to maintain the correct fit, heat the cylinder head to 100°C in an oven.

- a. Remove the valve guide with the valve guide remover ①.
- b. Install the new valve guide with the valve guide installer (2) and valve guide remover (1).
- c. After installing the valve guide, bore the valve guide with the valve guide reamer ③ to obtain the proper valve-stem-to-valve-guide clearance.

NOTE:

After replacing the valve guide, reface the valve seat.



- 3. Eliminate:
- carbon deposits
 (from the value face and value acc

(from the valve face and valve seat)

- 4. Check:
- valve face Pitting/wear → Grind the valve face.
 valve stem end

Mushroom shape or diameter larger than the body of the valve stem \rightarrow Replace the valve.

- 5. Measure:
- valve margin thickness ⓐ
 Out of specification → Replace the valve.

Valve margin thickness 1.1 ~ 1.5 mm (0.043 ~ 0.059 in) <Limit>: 0.7 mm (0.03 in)





6. Measure:

 valve stem runout Out of specification → Replace the valve.

NOTE:

- When installing a new valve, always replace the valve guide.
- If the valve is removed or replaced, always replace the oil seal.

Valve stem runout 0.01 mm (0.0004 in)

EAS00240

CHECKING THE VALVE SEATS

The following procedure applies to all of the valves and valve seats.

- 1. Eliminate:
- carbon deposits (from the valve face and valve seat)
- 2. Check:
- valve seat Pitting/wear \rightarrow Replace the cylinder head.
- 3. Measure:
- valve seat width (a)

Out of specification \rightarrow Replace the cylinder head.

Valve seat width Intake 0.9 ~ 1.1 mm (0.035 ~ 0.043 in) Exhaust 0.9 ~ 1.1 mm (0.035 ~ 0.043 in)

- a. Apply Mechanic's blueing dye (Dykem) (b) onto the valve face.
- b. Install the valve into the cylinder head.
- c. Press the valve through the valve guide and onto the valve seat to make a clear impression.
- d. Measure the valve seat width.







NOTE: _

Where the valve seat and valve face contacted one another, the blueing will have been removed.









- 4. Lap:
- valve face
- valve seat

NOTE: ____

After replacing the cylinder head or replacing the valve and valve guide, the valve seat and valve face should be lapped.

a. Apply a coarse lapping compound (a) to the valve face.

CAUTION:

Do not let the lapping compound enter the gap between the valve stem and the valve guide.

- b. Apply molybdenum disulfide oil onto the valve stem.
- c. Install the valve into the cylinder head.
- d. Turn the valve until the valve face and valve seat are evenly polished, then clean off all of the lapping compound.

NOTE: _

For the best lapping results, lightly tap the valve seat while rotating the valve back and forth between your hands.

- e. Apply a fine lapping compound to the valve face and repeat the above steps.
- f. After every lapping procedure, be sure to clean off all of the lapping compound from the valve face and valve seat.











- g. Apply Mechanic's blueing dye (Dykem) (b) onto the valve face.
- h. Install the valve into the cylinder head.
- i. Press the valve through the valve guide and onto the valve seat to make a clear impression.
- j. Measure the valve seat width © again. If the valve seat width is out of specification, reface and lap the valve seat.

CHECKING THE VALVE SPRINGS

The following procedure applies to all of the valve springs.

- 1. Measure:
- valve spring free length ⓐ
 Out of specification → Replace the valve spring.



Valve spring free length limit (intake and exhaust) Inner valve spring 37.45 mm (1.47 in) Outer valve spring 38.90 mm (1.53 in)

- 2. Measure:
- compressed valve spring force Out of specification → Replace the valve spring.

(b) Installed length

Compressed valve spring force (installed) Intake and exhaust inner valve spring 6.29 ~ 7.39 kg at 31.8 mm (13.9 ~ 16.3 lb at 1.25 in) Intake and exhaust outer valve spring 13.3 ~ 15.7 kg at 33.8 mm (29.3 ~ 34.6 lb at 1.33 in)









- 3. Measure:
- valve spring tilt ⓐ
 Out of specification → Replace the valve spring.



EAS00242

CHECKING THE VALVE LIFTERS

The following procedure applies to all of the valve lifters.

1. Check:

• valve lifter

 $\label{eq:def-Damage} \begin{array}{l} \mbox{Damage/scratches} \rightarrow \mbox{Replace the valve lifters and cylinder head.} \end{array}$

EAS00250 INSTALLING THE VALVES

The following procedure applies to all of the valves and related components.

- 1. Deburr:
- valve stem end (with an oil stone)
- 2. Lubricate:
- valve stem
- oil seal

(with the recommended lubricant)



3. Install:

- valve ①
- spring seat ②
- oil seal ③
- outer valve springs ④
- inner valve springs (5)
- spring retainer 6
- (into the cylinder head)

NOTE:

Install the valve springs with the larger pitch (a) facing up.

(b) Smaller pitch





- 4. Install:
- valve cotters (1)

NOTE: _

Install the valve cotters by compressing the valve springs with the valve spring compressor (2) and attachment (3).







5. To secure the valve cotters onto the valve stem, lightly tap the valve tip with a soft-face hammer.

CAUTION:

Hitting the valve tip with excessive force could damage the valve.

- 6. Lubricate:
- valve lifter ① (with the recommended lubricant)
- valve pad ②



- 7. Install:
- valve lifter
- valve pad

NOTE: _

- The valve lifter must move smoothly when rotated with a finger.
- Each valve lifter and valve pad must be reinstalled in its original position.

CLUTCH CRANKCASE COVER (RIGHT SIDE)





| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------------|------|---|
| | Removing the crankcase (right side) | | Remove the parts in the order listed. |
| | | | Stand the motorcycle on a level surface. |
| | | | |
| | | | Securely support the motorcycle so there is no danger of it falling over. |
| | Engine oil | | Refer to "CHANGING THE ENGINE OIL" in chapter 3. |
| | Brake pedal and footrest (right) | | Refer to "ENGINE REMOVAL". |
| 1 | Crankcase cover (right side) | 1 | |
| 2 | Gasket | 1 | |
| 3 | Dowel pins | 2 | |
| | | | For installation, reverse the removal pro- cedure. |

4

CLUTCH ASSEMBLY



ENG

0

CLUTCH

| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------|------|---------------------------------------|
| | Removing the clutch | | Remove the parts in the order listed. |
| 1 | Clutch spring plate retainer | 1 | |
| 2 | Clutch spring plate | 1 | |
| 3 | Clutch spring plate seat | 1 | |
| 4 | Pressure plate | 1 | |
| 5 | Short clutch push rod | 1 | |
| 6 | O-ring | 1 | |
| 7 | Ball | 1 | |
| 8 | Friction plates | 7 | |
| 9 | Clutch plates | 6 | |
| 10 | Lock washer | 1 | |
| 11 | Clutch boss | 1 | |
| 12 | Wire circlip | 1 | |

CLUTCH ENG

Ó



| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------|------|--|
| 13 | Clutch plate | 1 | |
| 14 | Friction plate | 1 | |
| 15 | Clutch damper spring | 1 | |
| 16 | Clutch damper spring seat | 1 | |
| 17 | Thrust washer | 1 | |
| 18 | Clutch housing | 1 | |
| 19 | Long clutch push rod | 1 | |
| 20 | Circlip | 1 | |
| 21 | Oil pump drive gear | 1 | |
| 22 | Dowel pins | 2 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |





REMOVING THE CLUTCH

- 1. Straighten the lock washer tab.
- 2. Loosen:
- clutch boss nut ①

NOTE: .

While holding the clutch boss 0 with the universal clutch holder 0, loosen the clutch boss nut.

Clutch holding tool YM-91042



- 3. Remove:
- clutch boss nut ①
- lock washer (2)
- clutch boss assembly ③
- thrust washer ④
- clutch housing (5)

NOTE:

There is a built-in damper between the clutch boss and the clutch plate. It is not necessary to remove the wire circlip and disassemble the built-in damper unless there is serious clutch chattering.



CHECKING THE FRICTION PLATES

The following procedure applies to all of the friction plates.

- 1. Check:
- friction plate Damage/wear → Replace the friction plates as a set.
- 2. Measure:
- friction plate thickness
 Out of specification → Replace the friction plates as a set.



NOTE: _

Measure the friction plate at four places.



Friction plate thickness 2.9 ~ 3.1 mm (0.114 ~ 0.122 in) <Limit>: 2.8 mm (0.110 in)

1 I1411901

EAS00281 **CHECKING THE CLUTCH PLATES**

The following procedure applies to all of the clutch plates.

- 1. Check:
- clutch plate Damage \rightarrow Replace the clutch plates as a set.
- 2. Measure:
- clutch plate warpage (with a surface plate and thickness gauge 1)

Out of specification \rightarrow Replace the clutch plates as a set.



Clutch plate warpage limit 0.2 mm (0.008 in)





EAS00283

CHECKING THE CLUTCH SPRING PLATE

- 1. Check:
- clutch spring plate ① Damage \rightarrow Replace.
- 2. Measure:
- clutch spring free height (a) Out of specification \rightarrow Replace the clutch spring plate.



Clutch spring free height 7 mm (0.28 in) <Limit>: 6.5 mm (0.26 in)

- 3. Check:
- clutch spring plate seat ② Damage \rightarrow Replace.





CHECKING THE CLUTCH HOUSING

1. Check:

 clutch housing dogs
 Damage/pitting/wear → Deburr the clutch housing dogs or replace the clutch housing.

NOTE:

Pitting on the clutch housing dogs will cause erratic clutch operation.

- 2. Check:
- bearing

Damage/wear \rightarrow Replace the bearing and clutch housing.



CHECKING THE CLUTCH BOSS

- 1. Check:
- clutch boss splines
 Damage/pitting/wear → Replace the clutch boss.

NOTE: ____

Pitting on the clutch boss splines will cause erratic clutch operation.



CHECKING THE PRESSURE PLATE

- 1. Check:
- pressure plate (1) Cracks/damage \rightarrow Replace.
- bearing ②
 Damage/wear → Replace.





CHECKING THE CLUTCH PUSH RODS

- 1. Check:
- O-ring ①
- \bullet short clutch push rod 2
- long clutch push rod ③
- ball ④
 Cracks/damage/wear → Replace the defective part(s).
- 2. Measure:
- long clutch push rod bending limit
 Out of specification → Replace the long
 clutch push rod.



Long clutch push rod bending limit 0.5 mm (0.26 in)

CHECKING THE PRIMARY DRIVE

- 1. Check:
- primary drive gear
- primary driven gear
 - $\label{eq:def-Damage} \begin{array}{l} \mbox{Damage/wear} \to \mbox{Replace the primary drive} \\ \mbox{and primary driven gears as a set.} \end{array}$

Excessive noise during operation \rightarrow Replace the primary drive and primary driven gears as a set.

- 2. Check:
- primary-drive-gear-to-primary-driven-gear free play
 Free play
 Free play

Free play exists \rightarrow Replace the primary drive and primary driven gears as a set.



EAS00296 INSTALLING THE CLUTCH

- 1. Install:
- \bullet clutch housing ()
- thrust washer 2







- 2. Install:
- clutch boss assembly (1)

NOTE:

- If the wire circlip (2) has been removed, carefully install a new one as shown.
- Install the clutch spring plate ③ with the "OUTSIDE" mark facing out.
- 3. Install:
- clutch boss ①
- lock washer New
- clutch boss nut 2

🔌 70 Nm (7.0 m · kg, 50 ft · lb)

NOTE: _

While holding the clutch boss with the universal clutch holder 3, tighten the clutch boss nut.



Clutch holding tool YM-91042

4. Bend the lock washer tab along a flat side of the nut.



- 5. Lubricate:
 - long clutch push rod ①
 - ball (2)
 - short clutch push rod ③
 (with the recommended lubricant)

Recommended lubricant Lithium soap base grease

- 6. Install:
- long clutch push rod
- ball
- short clutch push rod (along with the O-ring ④)

NOTE: _

Insert the rounded end of the long clutch push rod into the clutch boss first.



- 7. Lubricate:
- friction plates

clutch plates

(with the recommended lubricant)

Recommended lubricant Engine oil









- 8. Install:
- friction plates
- clutch plates

NOTE: _

- First, install a friction plate and then alternate between a clutch plate and a friction plate.
- Align the two embossed mark (a) on the clutch housing with the two semicircular slots
 (b) in the friction plates.
- 9. Install:
- pressure plate ①

NOTE: _

Align the punch mark (a) on the pressure plate with the punch mark (b) on the clutch boss.

10.Install:

- clutch spring plate seat ①
- clutch spring plate 2
- clutch spring plate retainer ③
- \bullet clutch spring bolts 4

🔌 8 Nm (0.8 m · kg, 5.8 ft · lb)

NOTE:

Tighten the clutch spring bolts in stages and in a crisscross pattern.

- 11.Install:
- clutch cover ①

🔌 10 Nm (1.0 m · kg, 7.2 ft · lb)

NOTE: _

Tighten the clutch cover bolts in stages and in a crisscross pattern.



SHIFT SHAFT GENERATOR ROTOR COVER



055

| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------------|------|--|
| | Removing the generator rotor cover | | Remove the parts in the order listed. |
| | Engine oil | | Refer to "CHANGING THE ENGINE OIL" |
| | | | in chapter 3. |
| 1 | Shift pedal | 1 | |
| 2 | Middle gear case cover | 1 | NOTE: |
| | | | Loosen the bolts in stages and in a criss- |
| | | | cross pattern. |
| | | | |
| 3 | Gasket | 1 | |
| 4 | Dowel pins | 2 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |



SHIFT SHAFT AND STOPPER LEVER



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------------|------|--|
| | Removing the shift shaft and stop- | | Remove the parts in the order listed. |
| | per lever | | |
| | Clutch assembly | | Refer to "CLUTCH". |
| 1 | Shift shaft assembly | 1 | |
| 2 | Circlip | 1 | |
| 3 | Washer | 1 | |
| 4 | Torsion spring | 1 | |
| 5 | Stopper lever | 1 | |
| 6 | Return spring | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |









CHECKING THE SHIFT SHAFT

- 1. Check:
- shift shaft ①
- shift lever ②
 Bends/damage/wear → Replace.
- shift lever spring ③
 Damage/wear → Replace.

CHECKING THE STOPPER LEVER

- 1. Check:
- stopper lever ①
 Bends/damage → Replace.
 Roller turns roughly → Replace the stopper lever.

EAS00336

INSTALLING THE SHIFT SHAFT

- 1. Install:
- stopper lever spring ①
- stopper lever (2)

🔌 10 Nm (1.0 m · kg, 7.2 ft · lb)

NOTE: _

- Hook the ends of the stopper lever spring onto the stopper lever and the crankcase boss.
- Mesh the stopper lever with the shift drum segment assembly.



- 2. Install:
- shift lever spring ①
- washer ②
- circlip ③ New





- 3. Install:
- shift shaft 1

NOTE: _

- Lubricate the oil seal lips with lithium soap base grease.
- Hook the end of the shift shaft spring onto the shift shaft spring stopper ②.
- 4. Install:
- clutch
- clutch cover Refer to "INSTALLING THE CLUTCH".



- 5. Install:
- dowel pins
- gasket New
- middle gear cover ①
- shift pedal ②

A WARNING

Always use a new copper washer on the lower bolt.

NOTE:

Tighten the middle gear cover bolts in stages and in a crisscross pattern.



GENERATOR STATOR COIL ASSEMBLY





| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------------------|------|---------------------------------------|
| | Removing the stator coil assembly | | Remove the parts in the order listed. |
| | Engine oil | | Refer to "CHANGING THE ENGINE OIL" |
| | | | in chapter 3. |
| | Muffler and exhaust pipes | | Refer to "ENGINE REMOVAL". |
| | Thermostat assembly | | Refer to "THERMOSTAT ASSEMBLY |
| | | | AND CONDUIT" in chapter 5. |
| | Middle gear case cover | | Refer to "SHIFT SHAFT". |
| 1 | Generator cover | 1 | |
| 2 | Gasket | 1 | |
| 3 | Dowel pins | 2 | |
| 4 | Pickup coil lead and stator coil lead | 1/1 | Remove from the cable clamp. |
| 5 | Cable holder | 1 | |
| 6 | Pickup coil | 1 | |

ENG

Ó



| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------|------|--|
| 7 | Plate (stator coil) | 1 | |
| 8 | Stator coil assembly | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |





| Order | Job/Part | Q'ty | Remarks |
|-------|--------------------------------|------|--|
| | Removing the generator rotor | | Remove the parts in the order listed. |
| 1 | Starter clutch idle gear shaft | 2 | |
| 2 | Starter clutch idle gear | 3 | |
| 3 | Generator rotor | 1 | |
| 4 | Woodruff key | 1 | |
| 5 | Starter clutch gear | 1 | |
| 6 | Starter motor lead | 1 | Disconnect. |
| 7 | Starter motor | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |





REMOVING THE GENERATOR

- 1. Remove:
- generator rotor bolt ①

washer

NOTE: .

- While holding the generator rotor ② with the sheave holder ③, loosen the generator rotor bolt.
- Do not allow the sheave holder to touch the projection on the generator rotor.

Sheave holder YU-01701



- 2. Remove:
- generator rotor ①

 (with the flywheel puller set ② and adapter ③)
- woodruff key

CAUTION:

To protect the end of the crankshaft, place an appropriate sized socket between the flywheel puller set's center bolt and the crankshaft.

NOTE: _

Make sure the flywheel puller is centered over the generator rotor.

Flywheel puller YU-33270 Attachment YM-33282









CHECKING THE STARTER CLUTCH

1. Check:

- starter clutch rollers ①
 Damage/wear → Replace.
- starter clutch spring cap ②
- starter clutch spring ③
- 2. Check:
- starter clutch idle gear
- starter clutch gear ②
 Burrs/chips/roughness/wear → Replace the defective part(s).
- 3. Check:
- starter clutch gear's contacting surfaces
 Damage/pitting/wear → Replace the starter
 clutch gear.
- 4. Check:
- starter clutch operation
- ****
- a. Install the starter clutch gear ① onto the starter clutch ② and hold the starter clutch.
- b. When turning the starter clutch gear clockwise, the starter clutch and the starter clutch gear should engage, otherwise the starter clutch is faulty and must be replaced.
- c. When turning the starter clutch drive gear counterclockwise, it should turn freely, otherwise the starter clutch is faulty and must be replaced.

- 5. Check:
- starter clutch shafts Bends/damage/wear \rightarrow Replace.





EAS00354 INSTALLING THE GENERATOR

- 1. Install:
- starter clutch gear ①
- woodruff key 2
- generator rotor ③
- pin ④
- washer (5)
- generator rotor bolt (6)

NOTE: _

- Clean the tapered portion of the crankshaft and the generator rotor hub.
- When installing the generator rotor, make sure the woodruff key is properly seated in the keyway of the crankshaft.



- 2. Tighten:
- generator rotor bolt ①

🔌 130 Nm (13.0 m · kg, 94 ft · lb)

NOTE:

- While holding the generator rotor ② with the sheave holder ③, tighten the generator rotor bolt.
- Do not allow the sheave holder to touch the projection on the generator rotor.

Sheave holder YU-01701

OIL PAN AND OIL PUMP



OIL PAN AND OIL PUMP





| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------------------|------|---------------------------------------|
| | Removing the oil pan and oil pump | | Remove the parts in the order listed. |
| | Engine oil | | Drain. |
| | | | Refer to "CHANGING THE ENGINE OIL" |
| | | | in chapter 3. |
| | Muffler and exhaust pipes | | Refer to "ENGINE REMOVAL". |
| | Clutch assembly | | Refer to "CLUTCH". |
| 1 | Circlip | 1 | |
| 2 | Oil pump drive gear | 1 | |
| 3 | Oil pan | 1 | |
| 4 | Dowel pins | 2 | |
| 5 | Gasket | 1 | |
| 6 | Oil level switch | 1 | |
| 7 | Oil pump assembly | 1 | |
| 8 | Dowel pins | 2 | |
| 9 | Oil pump pipe | 1 | |


OIL PAN AND OIL PUMP



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------|------|--|
| 10 | Bracket tabs | 2 | Straighten. |
| 11 | Oil pipe | 1 | |
| 12 | Oil gallery pipe | 1 | |
| 13 | Oil filter | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |

OIL PAN AND OIL PUMP



OIL PUMP



| Order | Job/Part | Q'ty | Remarks |
|----------------|-------------------------------|------|---------------------------------------|
| | Disassembling the oil pump | | Remove the parts in the order listed. |
| | Engine oil | | Drain. |
| | | | Refer to "CHANGING THE ENGINE OIL" |
| | | | in chapter 3. |
| | Oil pan and oil pump assembly | | Refer to "OIL PAN AND OIL PUMP". |
| 1 | Oil strainer | 1 | |
| 2 | Oil strainer housing | 1 | |
| 3 | Gasket | 1 | |
| 4 | Circlip | 1 | |
| 5 | Oil pump driven gear | 1 | |
| 6 | Oil pump gear housing | 1 | |
| \overline{O} | Spring | 1 | |
| 8 | Relief valve | 1 | |
| 9 | Inner rotor 1 | 1 | |
| 10 | Outer rotor 1 | 1 | |

OIL PAN AND OIL PUMP





| Order | Job/Part | Q'ty | Remarks |
|-------|--------------------------|------|---------------------------------------|
| (1) | Pin | 1 | |
| (12) | Dowel pins | 2 | |
| 13 | Oil pump housing cover 1 | 1 | |
| (14) | Inner rotor 2 | 1 | |
| 15 | Outer rotor 2 | 1 | |
| 16 | Pin | 1 | |
| 17 | Oil pump shaft | 1 | |
| 18 | Oil pump housing cover 2 | 1 | |
| (19) | Dowel pin | 1 | |
| 20 | Oil pump housing | 1 | |
| | | | For assembly, reverse the disassembly |
| | | | procedure. |





REMOVING THE OIL PAN

- 1. Remove:
- oil level switch ①
- oil pan 2
- gasket
- dowel pins

NOTE: _

Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.





CHECKING THE OIL PUMP

1. Check:

- oil pump drive gear ①
- oil pump driven gear ②
- oil pump gear housing ③
- oil pump housing cover 1 ④
- oil pump housing cover 2 (5) Cracks/damage/wear → Replace the defective part(s).
- 2. Measure:
- inner-rotor-to-outer-rotor-tip clearance (a)
- outer-rotor-to-oil-pump-housing clearance (b) Out of specification \rightarrow Replace the oil pump.
- ① Inner rotor
- ② Outer rotor
- ③ Oil pump housing



• oil pump operation

3. Check:









CHECKING THE RELIEF VALVE

- 1. Check:
- relief valve ①
- spring (2) Damage/wear \rightarrow Replace the defective part(s).

Rough movement \rightarrow Repeat steps (1) and

(2) or replace the defective part(s).

CHECKING THE OIL DELIVERY PIPE

- 1. Check:
- oil gallery pipe ①
- oil pipe ②
- oil pump pipe ③
- Damage \rightarrow Replace.

Obstruction \rightarrow Wash and blow out with compressed air.





CHECKING THE OIL STRAINER

- 1. Check:
- oil strainer ①
- oil strainer housing ②
 Damage → Replace.
 Contaminants → Clean with engine oil.





ASSEMBLING THE OIL PUMP

- 1. Lubricate:
- inner rotor 1
- outer rotor 1
- inner rotor 2
- outer rotor 2
- oil pump shaft (with the recommended lubricant)

Recommended lubricant Engine oil

- 2. Install:
- oil pump housing ①
- dowel pin ②
- oil pump housing cover 2 ③
- oil pump shaft ④
- pin (5)
- outer rotor 2 6
- inner rotor 2 ⑦
- oil pump housing cover 1 (8)
- oil pump housing cover 1 screw (9)

🔌 7 Nm (0.7 m · kg, 5.1 ft · lb)

- oil pump housing cover 1 bolt 1
 - 🔌 10 Nm (1.0 m · kg, 7.2 ft · lb)
- dowel pins ①
- pin 1
- outer rotor 2 13
- inner rotor 2 (14)
- relief valve 15
- spring 16
- oil pump gear housing 🕜

🔌 7 Nm (0.7 m · kg, 5.1 ft · lb)

- oil pump driven gear (18)
- circlip 19





NOTE: .

- When installing the inner rotor, align the pin in the oil pump shaft with the groove in the inner rotor.
- The arrow (a) on the gear housing faces toward the front of the engine.

3. Check:

 oil pump operation Refer to "CHECKING THE OIL PUMP".





INSTALLING THE OIL STRAINER

- 1. Install:
- oil strainer housing ①
 - 🔌 7 Nm (0.7 m · kg, 5.1 ft · lb)
- oil strainer cover 2

NOTE: _

The arrow (a) on the oil strainer cover must point towards the rear of the engine.

EAS00380 INSTALLING THE OIL PAN

- 1. Install:
- dowel pins
 - asket Now
- gasket <u>New</u>
- oil pan () 🔌 10 Nm (1.0 m · kg, 7.2 ft · lb)
- oil level switch ②
 - 🔌 10 Nm (1.0 m · kg, 7.2 ft · lb)
- engine oil drain bolt
 43 Nm (4.3 m · kg, 31 ft · lb)

NOTE:

- Tighten the oil pan bolts in stages and in a crisscross pattern.
- Lubricate the oil level switch O-ring with engine oil.



CRANKCASE



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------|------|---------------------------------------|
| | Separating the crankcase | | Remove the parts in the order listed. |
| | Engine assembly | | Refer to "ENGINE REMOVAL". |
| | Cylinder head | | Refer to "CYLINDER HEAD COVERS". |
| | Water pump | | Refer to "WATER PUMP" in chapter 5. |
| | Clutch assembly | | Refer to "CLUTCH ASSEMBLY". |
| | Shift shaft, stopper lever | | Refer to "SHIFT SHAFT AND STOPPER |
| | | | LEVER". |
| | Clutch release cylinder | | Refer to "DISASSEMBLING THE |
| | | | CLUTCH RELEASE CYLINDER" in chap- |
| | | | ter 7. |
| | Generator | | Refer to "GENERATOR". |
| | Oil pan and oil pump assembly | | Refer to "OIL PAN AND OIL PUMP". |
| | Connecting rods and pistons | | Refer to "CONNECTING RODS AND |
| | | | PISTONS". |

ENG

Ó



| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------------|------|--|
| 1 | Retainer (main axle bearing) | 1 | |
| 2 | Retainers (middle gear bearing) | 2 | |
| 3 | Middle driven gear assembly | 1 | |
| 4 | Shims | 2/4 | |
| 5 | Crankcase (upper) | 1 | Refer to "SEPARATING THE CRANK- |
| 6 | Crankcase (lower) | 1 | CASE". |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |





| Order | Job/Part | Q'ty | Remarks |
|----------------|-------------------------------|------|---------------------------------------|
| | Disassembling the crankcase | | Remove the parts in the order listed. |
| | Engine assembly | | Refer to "ENGINE REMOVAL". |
| | Crankcase separation | | Refer to "CRANKCASE". |
| | Crankshaft | | Refer to "CRANKSHAFT". |
| | Transmission | | Refer to "TRANSMISSION". |
| 1 | Crankcase breather cover | 1 | |
| 2 | Crankcase breather spacer | 1 | |
| 3 | Rubber gaskets | 2 | |
| 4 | Oil pipe | 1 | |
| 5 | Drain plugs (cylinders) | 4 | |
| 6 | Oil pipe | 1 | |
| \overline{O} | Bracket (timing chain damper) | 1 | |
| 8 | Circlip | 1 | |
| 9 | Oil pump drive shaft | 1 | |
| 10 | Idler gear (oil pump) | 1 | |
| | | | For assembly, reverse the disassembly |
| | | | procedure. |









SEPARATING THE CRANKCASE

CRANKCASE

1. Remove:

• crankcase bolts

NOTE: .

- Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.
- Loosen the bolts in decreasing numerical order (refer to the numbers in the illustration).
- The numbers embossed on the crankcase indicate the crankcase tightening sequence.
- * With a washer
- 2. Place the engine upside down.
- 3. Separate:
- A Upper crankcase
- B Lower crankcase

NOTE: _

While pulling up on the timing chains separate the upper crankcase from the lower crankcase.

CAUTION:

Tap on one side of the crankcase with a soft-face hammer. Tap only on reinforced portions of the crankcase, not on the crankcase mating surfaces. Work slowly and carefully and make sure the crankcase halves separate evenly.

- 4. Remove:
- dowel pins
- O-ring
- 5. Remove:
- crankshaft journal lower bearing (from the lower crankcase)

NOTE: .

Identify the position of each crankshaft journal lower bearing so that it can be reinstalled in its original place.



ASSEMBLING THE CRANKCASE

- 1. Lubricate:
- crankshaft journal bearings (with the recommended lubricant)



- 2. Apply:
- sealant

(onto the crankcase mating surfaces)

Quick Gasket[®] ACC-1100-15-01

NOTE:

Do not allow any sealant to come into contact with the oil gallery or crankshaft journal bearings. Do not apply sealant to within 2 ~ 3 mm of the crankshaft journal bearings.





- 3. Install:
- upper crankcase ① (onto the lower crankcase ②)

CAUTION:

Before tightening the crankcase bolts, make sure the transmission gears shift correctly when the shift drum assembly is turned by hand.

- 4. Install:
- final drive assembly Refer to "MIDDLE GEAR".

NOTE: .

The arrow on the final drive assembly must point towards the upper crankcase.





- 5. Install:
- middle driven shaft bearing housing bolts 🔌 30 Nm (3.0 m ⋅ kg, 22 ft ⋅ lb)

NOTE: .

The bolt with the washer goes in the lower right hole (a) of the middle driven shaft bearing housing.

- 6. Tighten:
- · upper crankcase bolts
- lower crankcase bolts

A WARNING

Always use new copper washers.

NOTE: .

- Tighten the bolts in the tightening sequence cast on the crankcase.
- Install copper washers on bolts (2) and (3).
- Install the cable holder on bolts 22 and 32.
- Install the washers on bolts (2) and (4) ~ (8).

A Lower crankcase

B Upper crankcase (M10 bolt) (M8 bolt) (M6 bolt)

| X | 40 Nm (4.0 m · kg, 29 ft · lb) |
|---|---------------------------------|
| X | 24 Nm (2.4 m · kg, 17 ft · lb) |
| X | 12 Nm (1.2 m · kg, 8.7 ft · lb) |



28^{°°}

26

32 (29)

33

0

TÞ. C

35

ĭ

(30)

(31) - (34)

<u>\</u> -27

(a) А

 \bigcirc

đ.

(23)

(24)

25





- 7. Install:
- middle driven shaft bearing housing retainers ①
 125 Nm (2.5 m · kg, 18 ft · lb)
- main axle bearing retainer 2

🔌 7 Nm (0.7 m · kg, 5.1 ft · lb)

A WARNING

Always use new screws.

NOTE: _

Apply LOCTITE[®] to the middle gear and main bearing retainer screws.

CAUTIONE

After tightening the middle driven shaft bearing housing retainer screws, be sure to stake them with a center punch.







CRANKSHAFT



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------|------|--|
| | Removing the crankshaft | | Remove the parts in the order listed. |
| | Engine assembly | | Refer to "ENGINE REMOVAL". |
| | Crankcase separation | | Refer to "CRANKCASE". |
| 1 | Crankshaft | 1 | |
| 2 | Timing chains | 2 | |
| 3 | Main journal bearings | 8 | |
| 4 | Balancer shaft | 1 | |
| 5 | Main journal bearings | 4 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |



EAS00387 **REMOVING THE CRANKSHAFT** ASSEMBLY

- 1. Remove:
- crankshaft assembly
- crankshaft journal upper bearings (from the upper crankcase)

NOTE:

Identify the position of each crankshaft journal upper bearing so that it can be reinstalled in its original place.



EAS00396

- **CHECKING THE CRANKSHAFT**
- 1. Measure:
- crankshaft runout Out of specification \rightarrow Replace the crankshaft.



- 2. Check:
- crankshaft journal surfaces
- crankshaft pin surfaces
- bearing surfaces Scratches/wear \rightarrow Replace the crankshaft.
- 3. Measure:
- crankshaft-journal-to-crankshaft-journalbearing clearance

Out of specification \rightarrow Replace the crankshaft journal bearings.



Crankshaft-journal-to-crankshaftjournal-bearing clearance 0.040 ~ 0.058 mm (0.0016 ~ 0.0023 in)

..... CAUTION:

Do not interchange the crankshaft journal bearings. To obtain the correct crankshaftjournal-to-crankshaft-journal-bearing clearance and prevent engine damage, the crankshaft journal bearings must be installed in their original positions.









- b. Place the upper crankcase upside down on a bench.
- c. Install the crankshaft journal upper bearings and the crankshaft into the upper crankcase.

NOTE: .

Align the projections (a) of the crankshaft journal upper bearings with the notches (b) in the upper crankcase.

d. Put a piece of Plastigauge[®] ① on each crankshaft journal.

NOTE: _

Do not put the Plastigauge[®] over the oil hole in the crankshaft journal.

 Install the crankshaft journal lower bearings into the lower crankcase and assemble the crankcase halves.

NOTE:

- Align the projections of the crankshaft journal lower bearings with the notches in the lower crankcase.
- Do not move the crankshaft until the clearance measurement has been completed.
- f. Tighten the bolts to specification in the tightening sequence cast on the crankcase.



Crankcase bolt 40 Nm (4.0 m • kg, 29 ft • lb)

* With a washer

NOTE: _

Lubricate the bolt threads with engine oil.

- g. Remove the lower crankcase and the crankshaft journal lower bearings.
- h. Measure the compressed Plastigauge[®] width ② on each crankshaft journal. If the crankshaft-journal-to-crankshaft-journal-bearing clearance is out of specification, select replacement crankshaft journal bearings.















- 4. Select:
- crankshaft journal bearings (J1 ~ J4)

NOTE:

- The numbers A stamped into the crankshaft web and the numbers ① stamped into the lower crankcase are used to determine the replacement crankshaft journal bearing sizes.
- " $J_1 \sim J_4$ " refer to the bearings shown in the crankshaft illustration.
- If " $J_1 \sim J_4$ " are the same, use the same size for all of the bearings.

For example, if the crankcase " J_1 " and crankshaft web " J_1 " numbers are "6" and "2" respectively, then the bearing size for " J_1 " is:

Bearing size of J₁:

" J_1 " (crankcase) – " J_1 " (crankshaft web) 6 – 2 = 4 (green)

| BEARING COLOR CODE | | |
|--------------------|--------|--|
| 1 | blue | |
| 2 | black | |
| 3 | brown | |
| 4 | green | |
| 5 | yellow | |
| 6 | pink | |
| 7 | red | |

NOTE: _

If the size is the same for all " J_1 to J_4 ", one digit for that size is indicated. (crankcase side only)



CHECKING THE BALANCER SHAFT

- 1. Measure:
- balancer shaft-journal-to-balancer shaftjournal-bearing clearance
 Out of specification → Replace the balancer

shaft journal bearings.



CAUTION:

Do not interchange the balancer shaft journal bearings. To obtain the correct balancer shaft-journal-to-balancer shaft-journalbearing clearance and prevent engine damage, the balancer shaft journal bearings must be installed in their original positions.

- a. Clean the balancer shaft journal bearings, balancer shaft journals, and bearing portions of the crankcase.
- b. Place the upper crankcase upside down on a bench.
- c. Install the balancer shaft journal upper bearings and the balancer shaft into the upper crankcase.

NOTE:

Align the projections (a) of the balancer shaft journal upper bearings with the notches (b) in the upper crankcase.

d. Put a piece of Plastigauge[®] ① on each balancer shaft journal.

NOTE: .

Do not put the Plastigauge[®] over the oil hole in the balancer shaft journal.

e. Install the balancer shaft journal lower bearings into the lower crankcase and assemble the crankcase halves.







NOTE: _

- Align the projections of the balancer shaft journal lower bearings with the notches in the lower crankcase.
- Do not move the crankshaft until the clearance measurement has been completed.
- f. Tighten the bolts to specification in the tightening sequence cast on the crankcase.



Crankcase bolt 24 Nm (2.4 m • kg, 17 ft • lb)

NOTE: _

Lubricate the bolt threads with engine oil.

- g. Remove the lower crankcase and the balancer shaft journal lower bearings.
- h. Measure the compressed Plastigauge[®] width ② on each balancer shaft journal. If the balancer shaft-journal-to-balancer shaft-journal-bearing clearance is out of specification, select replacement balancer shaft journal bearings.

- 2. Select:
- balancer shaft journal bearings (J₅ ~ J₆)

NOTE: _

- The numbers A stamped into the balancer shaft web and the numbers 1 stamped into the lower crankcase are used to determine the replacement balancer shaft journal bearing sizes.
- "J5 ~ J6" refer to the bearings shown in the balancer shaft illustration.
- If " $J_5 \sim J_6$ " are the same, use the same size for all of the bearings.

For example, if the crankcase " J_5 " and balancer shaft web " J_5 " numbers are "6" and "2" respectively, then the bearing size for " J_5 " is:













Bearing size of J₁:

CRANKSHAFT

"J₅" (crankcase) – "J₅" (balancer shaft web)

6 – 2 = 4 (green)

| BEARING COLOR CODE | | |
|--------------------|--------|--|
| 1 | blue | |
| 2 | black | |
| 3 | brown | |
| 4 | green | |
| 5 | yellow | |
| 6 | pink | |
| 7 | red | |

NOTE:

If the size is the same for all "J $_5$ and J $_6$ ", one digit for that size is indicated. (crankcase side only)



EAS00407 INSTALLING THE CRANKSHAFT

- 1. Install:
- crankshaft journal upper bearings (into the upper crankcase)

NOTE: .

- Align the projections (a) on the crankshaft journal upper bearings with the notches (b) in the upper crankcase.
- Be sure to install each crankshaft journal upper bearing in its original place.





- 2. Install:
- timing chain ①
 (onto the crankshaft sprocket)
- crankshaft assembly (2)

NOTE: _

- Pass the timing chain through the timing chain cavity.
- To prevent the timing chain from falling into the crankcase, fasten it with a wire.



EAS00410 INSTALLING THE BALANCER SHAFT

- 1. Install:
- balancer shaft

NOTE: ____

Align the punch mark (a) in the balancer shaft drive gear with the punch mark (b) in the balancer shaft driven gear.



CONNECTING RODS AND PISTONS



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------------|------|--|
| | Removing the connecting rod and | | Remove the parts in the order listed. |
| | piston | | |
| | Engine assembly | | Refer to "ENGINE REMOVAL". |
| | Cylinder heads | | Refer to "CYLINDER HEAD COVERS". |
| | Oil pan and oil pump assembly | | Refer to "OIL PAN AND OIL PUMP". |
| 1 | Nuts (connecting rod caps) | 8 | |
| 2 | Connecting rod caps and plain bear- | 4/8 | |
| | ings | | |
| 3 | Connecting rods with pistons | 4 | |
| 4 | Piston pin clips | 8 | |
| 5 | Piston pins | 4 | |
| 6 | Pistons | 4 | |
| 7 | Piston rings | 12 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |



REMOVING THE CONNECTING RODS AND PISTONS

The following procedure applies to all of the connecting rods and pistons.

1. Remove:

- connecting rod
- big end bearings

NOTE: _

Identify the position of each big end bearing so that it can be reinstalled in its original place.

- 2. Remove:
- piston pin clips ①
- piston pin (2)
- piston ③

CAUTION:

Do not use a hammer to drive the piston pin out.

NOTE: .

- For reference during installation, put identification marks on the piston crown.
- Before removing the piston pin, deburr the piston pin clip's groove and the piston's pin bore area. If both areas are deburred and the piston pin is still difficult to remove, remove it with the piston pin puller ④.

Piston pin puller set YU-01304



- 3. Remove:
- top ring
- 2nd ring
- oil ring

NOTE:

When removing a piston ring, open the end gap with your fingers and lift the other side of the ring over the piston crown.













CHECKING THE CYLINDERS AND PISTONS

- 1. Check:
- piston wall

 cylinder wall Vertical scratches → Rebore or replace the cylinder, and replace the piston and piston rings as a set.

- 2. Measure:
- piston-to-cylinder clearance

- a. Measure cylinder bore "C" with the cylinder bore gauge.
- (a) 40 mm from the top of the cylinder

NOTE: _

Measure cylinder bore "C" by taking side-toside and front-to-back measurements of the cylinder. Then, find the average of the measurements.



- b. If out of specification, rebore or replace the cylinder, and replace the piston and piston rings as a set.
- c. Measure piston skirt diameter "P" with the micrometer.
- 6.2 mm (0.24 in) from the bottom edge of the piston

| | Piston size "P" |
|------------|--|
| Standard | 75.905 ~ 75.955 mm (2.9884 ~ 2.9903 in) |
| Oversize 1 | 76.25 mm (3.0021 in) |
| Oversize 2 | 76.50 mm (3.0118 in) |

CONNECTING RODS AND PISTONS



- d. If out of specification, replace the piston and piston rings as a set.
- e. Calculate the piston-to-cylinder clearance with the following formula.

Piston-to-cylinder clearance = Cylinder bore "C" – Piston skirt diameter "P"



Piston-to-cylinder clearance 0.055 ~ 0.075 mm (0.0022 ~ 0.0030 in) <Limit>: 0.15 mm (0.0059 in)

f. If out of specification, rebore or replace the cylinder, and replace the piston and piston rings as a set.



CHECKING THE PISTON RINGS

- 1. Measure:
- piston ring side clearance
 Out of specification → Replace the piston and piston rings as a set.

NOTE: .

Before measuring the piston ring side clearance, eliminate any carbon deposits from the piston ring grooves and piston rings.



- 2. Install:
- piston ring (into the cylinder)

NOTE:

Level the piston ring into the cylinder with the piston crown.

(a) 20 mm (0.79 in)





- 3. Measure:
- piston ring end gap Out of specification → Replace the piston ring.

NOTE:

The oil ring expander spacer's end gap cannot be measured. If the oil ring rail's gap is excessive, replace all three piston rings.



Piston ring oversize

• Top and 2nd piston rings The size of the top and 2nd oversize piston rings is stamped on the top of each ring.

| Oversize 1 | 0.25 mm (0.0098 in) |
|------------|------------------------|
| Oversize 2 | 0.50 mm (0.0197 in) |

• Oil ring

The expander spacer of the oil ring is colorcoded for size identification.

| Size | Mark |
|------------|------|
| Oversize 1 | 25 |
| Oversize 2 | 50 |

EAS00266 CHECKING THE PISTON PINS

The following procedure applies to all of the piston pins.

- 1. Check:
- piston pin

Blue discoloration/grooves \rightarrow Replace the piston pin and then check the lubrication system.

CONNECTING RODS AND PISTONS







- 2. Measure:
- piston pin outside diameter ⓐ
 Out of specification → Replace the piston pin.



Piston pin outside diameter 18.991 ~ 19.000 mm (0.7477 ~ 0.7480 in)

- 3. Calculate:
- piston-pin-to-piston clearance
 Out of specification → Replace the piston pin.

Piston-pin-to-piston clearance = Piston pin bore size ⓑ – Piston pin outside diameter ⓐ



Piston-pin-to-piston clearance 0.004 ~ 0.024 mm (0.00016 ~ 0.00094 in) <Limit>: 0.072 mm (0.0028 in)

- 4. Measure:
- crankshaft-pin-to-big-end-bearing clearance

Out of specification \rightarrow Replace the big end bearings.



Crankshaft-pin-to-big-end-bearing clearance 0.021 ~ 0.039 mm (0.0008 ~ 0.0015 in)

The following procedure applies to all of the connecting rods.

CAUTION:

Do not interchange the big end bearings and connecting rods. To obtain the correct crankshaft-pin-to-big-end-bearing clearance and prevent engine damage, the big end bearings must be installed in their original positions.

- a. Clean the big end bearings, crankshaft pins, and the inside of the connecting rod halves.
- b. Install the big end upper bearing into the connecting rod and the big end lower bearing into the connecting rod cap.







NOTE: _

Align the projections (a) on the big end bearings with the notches (b) in the connecting rod and connecting rod cap.

- c. Put a piece of Plastigauge[®] on the crankshaft pin.
- d. Assemble the connecting rod halves.

NOTE: _

- Do not move the connecting rod or crankshaft until the clearance measurement has been completed.
- Lubricate the bolts threads and nut seats with molybdenum disulfide grease.
- Make sure the "Y" mark ① on the connecting rod faces towards the left side of the crank-shaft.
- Make sure the characters ② on both the connecting rod and connecting rod cap are aligned.
- e. Tighten the connecting rod nuts. Refer to "INSTALLING THE PISTONS AND CYLINDERS".



Connecting rod nut 36 Nm (3.6 m • kg, 25 ft • lb)

f. Remove the connecting rod and big end bearings.

Refer to "REMOVING THE CONNECTING RODS AND PISTONS".



g. Measure the compressed Plastigauge[®] width ① on the crankshaft pin. If the crankshaft-pin-to-big-end-bearing clearance is out of specification, select replacement big end bearings.











- 6. Select:
- big end bearings (P1 ~ P2)

NOTE:

- The numbers A stamped into the crankshaft web and the numbers ① on the connecting rods are used to determine the replacement big end bearing sizes.
- "P1" ~ "P2" refer to the bearings shown in the crankshaft illustration.

For example, if the connecting rod "P1" and the crankshaft web "P1" numbers are "4" and "1" respectively, then the bearing size for "P1" is:

| Bearing size of P1: | | | | |
|---------------------|------|---|---------------|---------|
| "P1" (connecting | rod) | _ | " P 1" | (crank- |
| shaft web) | | | | |
| 4 – 1 = 3 (brown) | | | | |

| BEARING COLOR CODE | | |
|--------------------|--------|--|
| 1 | blue | |
| 2 | black | |
| 3 | brown | |
| 4 | green | |
| 5 | yellow | |
| 6 | pink | |

EAS00270

INSTALLING THE PISTONS AND CYLINDERS

The following procedure applies to all of the pistons and cylinders.

- 1. Install:
- top ring
- 2nd ring
- oil ring

NOTE: .

- Be sure to install the piston rings so that the manufacturer's marks or numbers are located on the upper side of the rings.
- Lubricate the piston and piston rings liberally with engine oil.

CONNECTING RODS AND PISTONS











- 2. Position:
- top ring
- 2nd ring
- oil ring

Offset the piston ring end gaps as shown.

- (a) Top ring end
- (b) Lower oil ring end
- © Upper oil ring end
- (d) 2nd ring end
- 3. Install:
- piston ①
- piston pin ②
- piston pin clip ③ New

NOTE:

- Apply engine oil onto the piston pin.
- Be sure that the piston is positioned correctly, as shown in the illustration.
- (4) "Y" mark
- ⑤ "EX" exhaust side
- 6 "IN" exhaust side
- ⑦ Projection

- 4. Install:
- big end bearings ①

NOTE: _

- Align the projections (a) on the big end bearings with the notches (b) in the connecting rods and connecting rod caps.
- Be sure to reinstall each big end bearing in its original place.
- 5. Lubricate:
- piston
- piston rings
- cylinder
 - (with the recommended lubricant)

Recommended lubricant Engine oil

CONNECTING RODS AND PISTONS









- 6. Attach:
- piston ring compressors 1

Piston ring compressor YM-8037

7. Install:

• connecting rod and piston assembly

NOTE: .

- The stamped "Y" mark ② on the No. 2 and No. 4 connecting rods should face towards the right side of the crankcase.
- The stamped "Y" mark ② on the No. 1 and No. 3 connecting rods should face towards the left side of the crankcase.
- A Top view
- ③ Front
- (4) "Y" mark facing direction
- 5 Piston exhaust mark
- 6 Piston intake mark
- 8. Align:
- bolt heads (1)
 - (with the connecting rod caps)
- 9. Tighten:
- connecting rod nuts

🔌 36 Nm (3.6 m · kg, 25 ft · lb)

CAUTION

- When tightening the connecting rod nuts, be sure to use an F-type torque wrench.
- Without pausing, tighten the connecting rod nuts to the specified torque. Apply continuous torque between 3.0 and 3.6 m kg (22 and 25 ft lb). Once you reach 3.0 m kg (22 ft lb) DO NOT STOP TIGHTENING until the specified torque is reached. If the tightening is interrupted between 3.0 and 3.6 m kg (22 and 25 ft lb), loosen the connecting rod nut to less than 3.0 m kg (22 ft lb) and start again.



TRANSMISSION



| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------|------|--|
| | Removing the transmission | | Remove the parts in the order listed. |
| | Crankcase separation | | Refer to "CRANKCASE". |
| 1 | Drive axle assembly | 1 | |
| 2 | Main axle assembly | 1 | |
| 3 | Push rod bearing | 1 | |
| 4 | Oil seal | 1 | |
| 5 | Bearing stoppers | 2 | |
| 6 | Shift fork guide bars | 2 | |
| 7 | Shift forks | 3 | |
| 8 | Neutral switch | 1 | |
| 9 | Shift drum retainer | 1 | |
| 10 | Shift drum | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |





| Order | Job/Part | Q'ty | Remarks |
|----------------|-----------------------------------|------|---------------------------------------|
| | Disassembling the transmission | | Remove the parts in the order listed. |
| | Middle drive pinion gear assembly | | Refer to "MIDDLE GEAR". |
| 1 | Bearing | 1 | |
| 2 | Shim | 1 | |
| 3 | 1st wheel gear | 1 | |
| 4 | 4th wheel gear | 1 | |
| 5 | Circlip | 1 | |
| 6 | Washer | 1 | |
| \overline{O} | 3rd wheel gear | 1 | |
| 8 | Drive axle | 1 | |
| 9 | Plug | 1 | |
| 10 | 2nd wheel gear | 1 | |
| 1 | Washer | 1 | |
| 12 | Circlip | 1 | |





| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------|------|--|
| 13 | 5th wheel gear | 1 | |
| 14) | Bearing | 1 | |
| 15 | Circlip | 1 | |
| 16 | Bearing | 1 | |
| 17 | Main axle | 1 | |
| 18 | 4th pinion gear | 1 | |
| (19) | Washer | 1 | |
| 20 | Circlip | 1 | |
| 21 | 2nd, 3rd pinion gear | 1 | |
| 2 | 5th pinion gear | 1 | |
| 23 | Washer | 1 | |
| 24 | Circlip | 1 | |
| 25 | Bearing | 1 | |
| | | | For assembly, reverse the disassembly procedure. |











EAS00421 **CHECKING THE SHIFT FORKS**

The following procedure applies to all of the shift forks.

- 1. Check:
- shift fork cam follower ①
- shift fork pawl 2 Bends/damage/scoring/wear \rightarrow Replace the shift fork.
- 2. Check:
- shift fork guide bar Roll the shift fork guide bar on a flat surface. Bends \rightarrow Replace.

Do not attempt to straighten a bent shift fork guide bar.

- 3. Check:
- shift fork movement (along the shift fork guide bar) Rough movement \rightarrow Replace the shift forks and shift fork guide bar as a set.

EAS00422

CHECKING THE SHIFT DRUM ASSEMBLY

- 1. Check:
- shift drum grooves Damage/scratches/wear \rightarrow Replace the shift drum assembly.
- shift drum segment ① Damage/wear \rightarrow Replace the shift drum assembly.
- shift drum bearing 2 Damage/pitting \rightarrow Replace the shift drum assembly.
ENG







CHECKING THE TRANSMISSION

TRANSMISSION

1. Measure:

 main axle runout (with a centering device and dial gauge ①) Out of specification → Replace the main axle.



Main axle runout limit 0.08 mm (0.003 in)

2. Measure:

• drive axle runout

(with a centering device and dial gauge (1)) Out of specification \rightarrow Replace the drive axle.

Drive axle runout limit 0.08 mm (0.003 in)

- 3. Check:
- transmission gears Blue discoloration/pitting/wear → Replace the defective gear(s).
- transmission gear dogs Cracks/damage/rounded edges → Replace the defective gear(s).
- 4. Check:
- transmission gear engagement (each pinion gear to its respective wheel gear)

Incorrect \rightarrow Reassemble the transmission axle assemblies.

- 5. Check:
- transmission gear movement Rough movement → Replace the defective part(s).
- 6. Check:
- circlips Bends/damage/looseness \rightarrow Replace.

TRANSMISSION





EAS00430 INSTALLING THE TRANSMISSION

- 1. Install:
- shift drum assembly (1)
- shift drum retainer 2

🔌 7 Nm (0.7 m · kg, 5.1 ft · lb)

NOTE:

- Apply LOCTITE[®] #648 to the shift drum retainer screws.
- Turn the shift drum assembly to the neutral position.



- 2. Lubricate:
- neutral switch (with the recommended lubricant)



Recommended lubricant Lithium soap base grease

- 3. Install:
- neutral switch ①

🔌 3.5 Nm (0.35 m · kg, 25 ft · lb)

Always use a new O-ring.



- 4. Install:
- shift fork "C" ①
- shift fork "L" (2)
- shift fork "R" 3
- \bullet shift fork guide bars (4)

NOTE: _

The embossed marks on the shift forks should face towards the right side of the engine and be in the following sequence: "R", "C", "L".





- 5. Install:
- bearing stoppers 1

TRANSMISSION

NOTE: _

Insert the bearing stoppers completely into the grooves in the lower crankcase.

- 6. Lubricate:
- oil seal lips

(with a thin coat of the recommended lubricant)

Recommended lubricant Lithium soap base grease





- 7. Install:
- push rod bearing ①
- oil seal 2

A WARNING

Always use a new O-ring.

NOTE: _

- Insert the bearing pin into the hole in the crankcase.
- Position the oil seal against the push rod bearing.
- 8. Install:
- main axle assembly ①
- drive axle assembly ②

Always use new circlips.

NOTE: _

Position the bearing pins ③ as shown.

- 9. Check:
- transmission
 - Rough movement \rightarrow Repair.

NOTE: .

Oil each gear, shaft, and bearing thoroughly.

MIDDLE GEAR



MIDDLE GEAR



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------------|------|---------------------------------------|
| | Removing the middle gear | | Remove the parts in the order listed. |
| | Crankcase separation | | Refer to "CRANKCASE". |
| | Drive axle assembly | | Refer to "TRANSMISSION". |
| 1 | Nut | 1 | |
| 2 | Washer | 1 | |
| 3 | Universal joint (yoke) | 1 | |
| 4 | Dust seal | 1 | |
| 5 | Middle driven shaft bearing housing | 1 | |
| 6 | Shims | 2 | |
| 7 | O-ring | 1 | |
| 8 | Bearing | 1 | |
| 9 | Collapsible collar | 1 | |
| 10 | Spacer | 1 | |
| 11 | Bearing | 1 | |



MIDDLE GEAR



| Order | Job/Part | Q'ty | Remarks |
|-------|--------------------------|------|--|
| 12 | Middle driven shaft | 1 | |
| 13 | Retainer | 1 | |
| 14 | Thrust washer | 1 | |
| 15 | Middle drive pinion gear | 1 | |
| 16 | Damper cam | 1 | |
| 17 | Damper spring | 1 | |
| 18 | Spring seat | 1 | |
| 19 | Bearing | 1 | |
| 20 | Nut | 1 | |
| 21 | Bearing | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |





DISASSEMBLING THE MIDDLE DRIVE SHAFT ASSEMBLY

- 1. Remove:
- spring retainers

NOTE:

While holding the spring with the middle drive gear holder ①, compress the spring with the damper spring compressor ②, and then remove the spring retainers.



- 2. Remove:
- middle drive shaft nut
- bearing
- shim(s)

- a. Wrap the end of the middle drive shaft in a folded rag ①.
- b. Secure the middle drive shaft in a vice.
- c. Attach the middle drive shaft nut wrench as shown.



d. Remove the middle drive shaft nut, bearing, and shim(s).

DISASSEMBLING THE MIDDLE DRIVEN SHAFT ASSEMBLY

NOTE: _

The following procedure should only be performed if the middle drive gear or middle driven shaft bearing(s) has to be replaced.







1

1. Remove:

• universal joint

a. Remove the circlips 1.

MIDDLE GEAR

- b. Place the universal joint in a press.
- c. With a pipe of the proper diameter positioned beneath the universal joint driven yoke as shown, press the bearing into the pipe.

NOTE: _

It may be necessary to lightly tap the universal joint driven yoke with a center punch.

- d. Repeat the above steps to remove the opposite side's bearing.
- e. Separate the universal joint yokes.

- 2. Loosen:
- middle driven shaft nut

NOTE: _

While holding the universal joint driven yoke with the universal joint holder ①, loosen the middle driven shaft nut.



Universal joint holder YM-04062



CHECKING THE MIDDLE DRIVE SHAFT ASSEMBLY

- 1. Check:
- damper cam surface Scratches/wear → Replace the damper cam.
- 2. Check:
- spring Cracks/damage \rightarrow Replace.



CHECKING THE MIDDLE DRIVEN SHAFT ASSEMBLY

- 1. Check:
- middle driven gear Galling/pitting/wear → Replace the middle driven shaft assembly.
- 2. Check:
- bearings
 Damage/pitting → Replace the middle drive shaft bearing housing assembly.
- 3. Check:
- O-ring
- oil seal

Damage \rightarrow Replace the defective part(s).

- 4. Check:
- universal joint movement Rough movement → Replace the universal joint.

ASSEMBLING THE MIDDLE DRIVE SHAFT ASSEMBLY

- 1. Tighten:
- middle drive shaft nut

🔌 110 Nm (11.0 m · kg, 80 ft · lb)

NOTE:

- Apply LOCTITE[®] #620 or #201 to the middle drive pinion gear nut.
- Lock the threads on the middle drive shaft nut by staking them with a center punch ①.
- 2. Install:
- spring retainers

NOTE: _

While holding the spring with the middle drive gear holder ②, compress the spring with the damper spring compressor ①, and then install the spring retainers.



Middle gear backlash tool 90890-04080 Damper spring compressor YM-33286





MIDDLE GEAR

252 04



- 3. Measure:
- drive axle assembly length ⓐ
 Out of specification → Add shim ①.

| (9.9924 ~ 10.0145 in) | | |
|--|--------------------|--|
| Length (a) Shim thickness | | |
| 252.66 ~ 253.00 mm (9.9472 ~ 9.9606 in) | 1.3 mm (0.0512 in) | |
| 253.01 ~ 253.40 mm (9.9610 ~ 9.9764 in) | 0.9 mm (0.0354 in) | |
| 253.41 ~ 253.80 mm (9.9768 ~ 9.9921 in) | 0.5 mm (0.0197 in) | |

Drive axle assembly length

254 27

ASSEMBLING THE MIDDLE DRIVEN SHAFT ASSEMBLY

NOTE:

The following points are critical when assembling the middle gears:

- The collapsible collar must be replaced whenever the middle driven shaft assembly is removed from the middle driven shaft bearing housing.
- When performing this procedure for the first time, be sure to have at least one extra collapsible collar on hand.
- If there is insufficient preload on the bearings, the middle driven shaft can move slightly, allowing oil to leak past the seal. In addition to torquing the middle driven shaft nut to specification, you must also check the spinning torque (bearing preload).
- 1. Install:
- bearing outer race (into the middle driven shaft bearing housing)

A WARNING

Do not press the bearing outer race. During installation, always press the bearing inner race carefully.



- 2. Tighten:
- middle driven shaft nut

 \searrow 90 Nm (9.0 m · kg, 65 ft · lb)While holding the universal joint driven yokewith the universal joint holder, tighten themiddle driven shaft nut.

Universal joint holder YM-04062

CAUTION:

Tighten the middle driven shaft nut in small increments, checking the torque it takes to keep the middle driven gear turning in the middle driven shaft bearing housing - not the torque it takes to start it turning.

- 3. Measure:
- middle driven gear spinning torque (with the beam-type torque wrench)



Under specification \rightarrow Repeat steps (2) and (3).

CAUTION:

- Never exceed the standard spinning torque.
- If the spinning torque is not high enough, tighten the middle driven shaft nut slightly and check the spinning torque again. Repeat these steps until the proper spinning torque is obtained.
- If the spinning torque specification is exceeded, remove the middle driven shaft assembly, install a new collapsible collar, and repeat steps (1) ~ (3).







- 4. Install:
- universal joint driven yoke/cross joint (into the universal joint drive yoke)

CAUTION:

MIDDLE GEAR

Do not hammer the universal joint drive yoke or the collapsible collar may be distorted. This will result in a change in the standard spinning torque, requiring replacement of the collapsible collar and reassembly of the middle driven shaft assembly.



- 5. Install:
- bearings

(onto the universal joint driven yoke/cross joint)

CAUTION:

The needles can easily fall out of their races, so check each bearing carefully. Slide the universal joint driven yoke assembly back and forth on the bearings. If a needle is out of place, the yoke will not go all the way onto the bearings.

6. Press each bearing into the universal joint driven yoke assembly with a socket of the proper size.

NOTE:

The bearings must be inserted far enough into the universal joint driven yoke assembly so that circlips can be installed.

EAS00446 INSTALLING THE MIDDLE GEAR

1. Install:

- shim(s) ①
- middle driven shaft housing ②

NOTE:

Finger tighten the middle driven shaft housing bolts.



MIDDLE GEAR

- 2. Tighten:
- crankcase bolts
- middle driven shaft housing bolts

 30 Nm (3.0 m · kg, 22 ft · lb)

NOTE:

Before tightening the bolts:

- Adjust the middle gear backlash. Refer to "ADJUSTING THE MIDDLE GEAR BACKLASH".
- 2. Check that the middle driven gear turns smoothly.
- 3. Make sure the arrow on the middle driven shaft bearing housing points towards the upper crankcase.



- 3. Install:
- bearing retainers (1)

🔌 25 Nm (2.5 m · kg, 18 ft · lb)

NOTE: .

Apply LOCTITE[®] to the middle gear bearing retainer screws.

A WARNING

Always use new screws.

CAUTION:

After tightening the bearing retainer screws, stake them with a center punch.



ADJUSTING THE MIDDLE GEAR BACKLASH

- 1. Install:
- middle gear backlash tool (1)

Middle gear backlash tool 90890-04080

MIDDLE GEAR



- 2. Loosen:
- middle driven shaft bearing housing bolts
- 3. Remove:
- shim(s)
- 4. Tighten:
- middle driven shaft bearing housing bolts

CAUTION:

Do not overtighten the middle driven shaft bearing housing bolts or you may obtain too little middle gear backlash, and damage the middle gears and collapsible collar. If the bolts are overtightened, replace the collapsible collar. Then, repeat all of the previous steps until the crankcase-to-middledriven-shaft-bearing-housing clearance is within specification.



NOTE: .

- Tighten the middle driven shaft bearing housing bolts carefully, one thread turn at a time only. Push in the middle driven shaft bearing housing and then tighten the bolts to specification.
- Clearance between the crankcase and the middle driven shaft bearing housing should be approximately 2 mm, when measured with a thickness gauge 2.
- 5. Position:
- dial gauge ③

(onto the outside edge of the universal joint)



Dial gauge YU-03097

NOTE:

Be sure that the gauge is positioned over the centerline of the yoke bearing hole.



- 6. Turn:
- universal joint drive yoke

NOTE: _

While carefully tightening the middle driven shaft bearing housing bolts in stages and in a crisscross pattern, turn the universal joint drive yoke back and forth until the dial gauge reads $0.05 \sim 0.12$ mm.

- 7. Measure:
- crankcase-to-middle-driven-shaft-bearinghousing clearance (with a thickness gauge)



- 8. Select:
- shim(s) (1)
- ****
- a. Shims can only be selected in 0.05 mm increments, therefore round off to the hundredth's digit of the calculated thickness and select the appropriate shim(s) with the following chart.
- b. For example, the clearance between the crankcase and the middle driven shaft bearing housing is 0.46 mm. Therefore, the chart instructs you to round off the 6 to 5. Thus, you should use one 0.15 mm and one 0.30 shim.

| Hundredth | Rounded value |
|------------|---------------|
| 0, 1, 2 | 0 |
| 3, 4, 5, 6 | 5 |
| 7, 8, 9 | 10 |

Shims are supplied in the following thicknesses.

| - Contraction of the second se | Middle driven pinion gear shim | | | |
|--|--------------------------------|----------------------------------|--|--|
| Thickness (mm) | | 0.10 0.15 0.30 0.40 0.50 0.60 | | |
| | | | | |





- 9. Loosen:
- middle driven shaft bearing housing bolts 10.Install:
- shim(s)
- 11.Tighten:
- middle driven shaft bearing housing bolts
 30 Nm (3.0 m · kg, 22 ft · lb)

NOTE:

Before tightening the middle driven shaft bearing housing bolts, make sure the arrow on the middle driven shaft bearing housing points towards the upper crankcase.

12.Measure:

• middle gear backlash



ALIGNING THE MIDDLE GEAR

NOTE: .

Aligning the middle gear is necessary when any of the following parts are replaced:

- Crankcase
- Middle driven shaft
- Middle driven shaft bearing housing
- ① Drive pinion gear
- ② Driven pinion gear
- 3 Drive pinion gear shim
- ④ Driven pinion gear shim
- 1. Select:
- drive pinion gear shim
- ****
- a. Position the drive pinion gear with the appropriate shim(s) ③. Calculate the respective thicknesses from the information marked on the crankcase.



b. To find drive pinion gear shim thickness "T", use the following formula:

Drive pinion gear shim thickness $\mathbf{T} = \mathbf{A} - \mathbf{B}$

Where:

A = 54.5 + (constant number)B = 53 + (a/100)



a = a numeral stamped on the left-side of the upper crankcase, divided by 100. If the left-side of the upper crankcase is stamped "96": B = 53 + (96/100)

- = 53 + 0.96
- = 53.96 noroforo.

Therefore:
$$T = A - B$$

$$-515-53$$

= 0.54

Therefore, the calculate drive pinion gear shim thickness is 0.54.

MIDDLE GEAR



Since the shims are only available in 0.10- or 0.15-mm increments, round off the hundredths' digit.

| Hundredth's digit | Rounded value |
|-------------------|---------------|
| 0, 1, 2 | 0 |
| 3, 4, 5, 6 | 5 |
| 7, 8, 9 | 10 |

In the example above, the calculated drive pinion gear shim thickness is 0.54 mm. The chart instructs you to round off to 0.55 mm. Thus, 0.15 mm and 0.4 mm should be used as indicated in the following chart.

| Drive pinion | Drive pinion gear shim | | |
|----------------|------------------------|--|--|
| Thickness (mm) | 0.15 0.30 0.40 0.50 | | |
| | | | |

4

COOL



COOLING SYSTEM

RADIATOR AND RADIATOR HOSES



| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------|------|--|
| | Removing the radiator | | Remove the parts in the order listed. |
| | Top cover and covers | | Refer to "TOP COVER AND COVERS" in |
| | | | chapter 3. |
| | Coolant | | Drain. |
| | | | Refer to "CHANGING THE COOLANT" in |
| | | | chapter 3. |
| 1 | Radiator fan motor coupler | 1 | Disconnect. |
| 2 | Radiator hose clamps | 3 | Loosen. |
| 3 | Radiator side panels | 2 | |
| 4 | Radiator | 1 | |
| 5 | Fan motor | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | ocuure. |





| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------------------|------|--|
| | Removing the radiator hoses | | Remove the parts in the order listed. |
| 1 | Radiator inlet hose | 1 | |
| 2 | Coolant drain cock assembly hose | 1 | |
| 3 | Radiator outlet hose | 1 | |
| 4 | Thermostat assembly breather hose | 1 | |
| 5 | Conduit breather hose | 1 | |
| 6 | Conduit inlet hoses | 2 | |
| 7 | Coolant breather hose | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |

5

RADIATOR AND RADIATOR HOSES







CHECKING THE RADIATOR

1. Check:

• radiator fins Obstruction \rightarrow Clean. Apply compressed air to the rear of the radiator. Damage \rightarrow Repair or replace.

NOTE:

Straighten any flattened fins with a thin, flathead screwdriver.

- 2. Check:
- radiator hoses
- radiator pipes
 Cracks/damage → Replace.
- 3. Check:
- radiator fan
- Damage \rightarrow Replace.

Malfunction \rightarrow Check and repair.

Refer to "COOLING SYSTEM" in chapter 8.

EAS00456 INSTALLING THE RADIATOR

- 1. Install:
- radiator hoses

NOTE: _

Align the hose match marks ① with the match marks ② on the conduit.

- 2. Fill:
- cooling system

(with the specified amount of the recommended coolant) Refer to "CHANGING THE COOLANT" in

chapter 3.

- 3. Check:
- cooling system
 Leaks → Repair or replace any faulty part.
- 4. Measure:
- radiator cap opening pressure Below the specified pressure → Replace the radiator cap.

Refer to "CHECKING THE RADIATOR CAP".



THERMOSTAT ASSEMBLY AND CONDUIT



| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------------|------|---------------------------------------|
| | Removing the thermostat assembly | | Remove the parts in the order listed. |
| | Top cover and covers | | Refer to "TOP COVER AND COVERS" in |
| | | | chapter 3. |
| | Coolant | | Drain. |
| | | | Refer to "CHANGING THE COOLANT" in |
| | | | chapter 3. |
| | Radiator assembly and hoses | | Refer to "RADIATOR AND RADIATOR |
| | | | HOSES". |
| 1 | Coolant drain cock assembly | 1 | |
| 2 | O-ring | 1 | |
| 3 | Thermostat assembly | 1 | |
| 4 | Water pump inlet pipe | 1 | |
| 5 | O-ring | 2 | |
| 6 | Coolant drain cock | 1 | |
| 7 | Stopper ball | 1 | |





| Order | Job/Part | Q'ty | Remarks |
|-------|----------|------|--|
| 8 | Spring | 1 | |
| 9 | O-ring | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |





| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------|------|---------------------------------------|
| | Disassembling the thermostat | | Remove the parts in the order listed. |
| | assembly | | |
| 1 | Thermostat housing cover | 1 | |
| 2 | O-ring | 1 | |
| 3 | Thermostat | 1 | |
| 4 | Thermostat housing | 1 | |
| | | | For assembly, reverse the disassembly |
| | | | procedure. |





| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------|------|--|
| | Removing the conduit assembly | | Remove the parts in the order listed. |
| 1 | Thermo switch coupler | 1 | Disconnect. |
| 2 | Temperature sender lead | 1 | Disconnect. |
| 3 | Ground lead | 1 | Disconnect. |
| 4 | Conduit | 1 | |
| 5 | Temperature sender | 1 | |
| 6 | Thermo switch | 1 | |
| 7 | O-ring | 1 | |
| 8 | Conduit board | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |









EAS00463 CHECKING THE THERMOSTAT

- 1. Check:
- thermostat (1) Does not open at 80 ~ 84 °C (178.0 ~ 183.2 °F) \rightarrow Replace.

- a. Suspend the thermostat in a container filled with water.
- b. Slowly heat the water.
- c. Place a thermometer in the water.
- d. While stirring the water, observe the thermostat and thermometer's indicated temperature.

- 1 Thermometer
- ② Water
- ③ Thermostat
- ④ Container
- A Fully closed
- B Fully open

NOTE: _

If the accuracy of the thermostat is in doubt, replace it. A faulty thermostat could cause serious overheating or overcooling.

- 2. Check:
- thermostat housing cover
- thermostat housing Cracks/damage → Replace.
- 3. Check:
- thermostat housing cover O-ring
- thermostat housing inlet pipe O-ring
- water pump inlet pipe Damage → Replace.

THERMOSTAT ASSEMBLY AND CONDUIT





CHECKING THE RADIATOR CAP

1. Measure:

 radiator cap opening pressure Below the specified pressure → Replace the radiator cap.



a. Install the radiator cap tester ① and adapter
② to the radiator cap ③.



b. Apply the specified pressure for ten seconds and make sure there is no drop in pressure.







ASSEMBLING THE THERMOSTAT ASSEMBLY

- 1. Install:
- thermostat housing ①
- thermostat 2
- O-ring ③ New
- thermostat housing cover ④

NOTE:

- Install the thermostat with its breather hole (a) facing up.
- Align the projection (b) on the thermostat with the slot (c) on the thermostat housing.
- 2. Install:
- thermo switch (1)

🔌 15 Nm (1.5 m · kg, 11 ft · lb)

temperature sender ②

🔌 15 Nm (1.5 m · kg, 11 ft · lb)

CAUTION:

Use extreme care when handling the thermo switch and temperature sender. Replace any part that was dropped or subjected to a strong impact.



INSTALLING THE THERMOSTAT ASSEMBLY

1. Fill:

- cooling system (with the specified amount of the recommended coolant) Refer to "CHANGING THE COOLANT" in chapter 3.
- 2. Check:
- cooling system
 Leaks → Repair or replace any faulty part.
- 3. Measure:
- radiator cap opening pressure Below the specified pressure → Replace the radiator cap.

Refer to "CHECKING THE RADIATOR CAP".

WATER PUMP



COOL

WATER PUMP

| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------|------|---|
| | Removing the water pump | | Remove the parts in the order listed. |
| | | | NOTE: |
| | | | It is not necessary to remove the water pump unless the coolant level is extremely low or the coolant contains engine oil. |
| | Coolant | | Refer to "CHANGING THE COOLANT" in chapter 3. |
| | Engine oil | | Refer to "CHANGING THE ENGINE OIL" in chapter 3. |
| 1 | Water pump cover | 1 | |
| 2 | O-ring | 1 | |
| 3 | Water pump housing | 1 | |
| 4 | Water pump inlet pipe | 1 | |

5 - 11



WATER PUMP



| Order | Job/Part | Q'ty | Remarks |
|-------|------------|------|--|
| 5 | O-ring | 1 | |
| 6 | Gasket | 1 | |
| 7 | Dowel pins | 2 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |

WATER PUMP



| Order | Job/Part | Q'ty | Remarks |
|----------------|------------------------------|------|---------------------------------------|
| | Disassembling the water pump | | Remove the parts in the order listed. |
| 1 | Circlip | 1 | |
| 2 | Driven gear | 1 | |
| 3 | Gear stopper pin | 1 | |
| 4 | Circlip | 1 | |
| 5 | Impeller | 1 | |
| 6 | Bearing | 1 | Π |
| \overline{O} | Oil seal | 1 | |
| 8 | Water pump seal | 1 | |
| 9 | Rubber damper | 1 | WATER FOMF . |
| 10 | Rubber damper holder | 1 | |
| | | | For assembly, reverse the disassembly |
| | | | procedure. |













DISASSEMBLING THE WATER PUMP

- 1. Remove:
- bearing ①
- \bullet oil seal 2

NOTE: .

Tap out the bearing and oil seal from the outside of the water pump housing.

- 2. Remove:
- water pump seal ①

NOTE: _

Tap out the water pump seal from the inside of the water pump housing.

- 3. Remove:
- rubber damper holder ①
- rubber damper ② (from the impeller, with a thin, flat-head screwdriver)

NOTE:

Do not scratch the impeller shaft.

EAS00474

CHECKING THE WATER PUMP

- 1. Check:
- water pump housing cover ①
- water pump housing ②
- impeller ③
- rubber damper ④
- rubber damper holder ⑤
 Cracks/damage/wear → Replace.





- 2. Check:
- water pump seal ①

WATER PUMP

• oil seal (2) Cracks/damage/wear \rightarrow Replace.

- 3. Check:
- bearing Rough movement \rightarrow Replace.

- 4. Check:
- water pump driven gear Pitting/wear \rightarrow Replace.

- 5. Check:
- water pump inlet pipe Cracks/damage/wear \rightarrow Replace.

WATER PUMP







ASSEMBLING THE WATER PUMP

- 1. Install:
- rubber damper ①
- rubber damper holder ②

NOTE: .

Before installing the rubber damper, apply tap water or coolant onto its outer surface.

- 2. Measure:
- impeller shaft tilt
 Out of specification → Repeat step 1.

CAUTION:

Make sure the rubber damper and rubber damper holder are flush with the impeller.



Impeller shaft tilt limit 0.15 mm (0.006 in)

Straightedge
 Impeller



- 3. Install:
- water pump seal ①

CAUTION:

Never lubricate the water pump seal surface with oil or grease.

NOTE: ____

- Install the water pump seal from the outside of the water pump housing.
- Install the water pump seal with a socket ② that matches its outside diameter.



WATER PUMP

- 4. Install:
- oil sealbearing (1)

o Deaning

NOTE: .

- Install the oil seal and bearing from the inside of the water pump housing.
- Make sure the side of the bearing with the number faces up.
- Gently tap the bearing into place until it is flush with the water pump housing.
- 5. Install:
- \bullet impeller (1)
- circlip ② New

- 6. Install:
- key
- water pump driven gear

NOTE: _

Align the slot (a) in the water pump driven gear with the pin (b).

- 7. Install:
- circlip ① New

INSTALLING THE WATER PUMP

- 1. Install:
- water pump housing ①

Always use a new gasket.

5 - 17















2. Install:

- O-ring New
- water pump housing cover 1
- O-rings New
- water pump inlet pipe ②

WATER PUMP

NOTE:

Before installing the water pump outlet pipe ②, lubricate the O-rings with a thin coat of lithium soap base grease.



Water pump housing cover bolt 10 Nm (1.0 m • kg, 7.2 ft • lb)

3. Fill:

• cooling system

(with the specified amount of the recommended coolant)

Refer to "CHANGING THE COOLANT" in chapter 3.

- 4. Check:
- cooling system

Leaks \rightarrow Repair or replace the faulty part.

- 5. Measure:
- radiator cap opening pressure Below the specified pressure → Replace the radiator cap.

Refer to "CHECKING THE RADIATOR CAP".



CARBURETION

CARBURETORS



| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|--|
| | Removing the carburetor | | Remove the parts in the order listed. |
| | Top cover and covers | | Refer to "TOP COVER AND COVERS" in |
| | | | chapter 3. |
| | Air filter case and electrical compo- | | Refer to "AIR FILTER CASE AND ELEC- |
| | nents board | | TRICAL COMPONENTS BOARD" in |
| | | | chapter 3. |
| 1 | Fuel hose | 1 | Disconnect. |
| 2 | Throttle cable holder cover | 2 | |
| 3 | Throttle cable holder | 1 | |
| 4 | Throttle cable joint | 2 | |
| 5 | Throttle cables | 2 | Disconnect. |
| 6 | Carburetor joint covers (left and right) | 2 | |
| 7 | Clamps (carburetor joints) | 8 | Loosen. |
| 8 | Carburetor assembly | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |




| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------------|------|---------------------------------------|
| | Separating the carburetors | | Remove the parts in the order listed. |
| 1 | Fuel overflow hose | 2 | |
| 2 | Fuel feed joint | 2 | |
| 3 | Upper bracket (left) | 1 | |
| 4 | Upper bracket (right) | 1 | |
| 5 | Throttle stop screw bracket | 1 | |
| 6 | Throttle stop screw | 1 | |
| 7 | Throttle stop screw spring | 1 | |
| 8 | Lower bracket | 1 | |
| 9 | Side bracket (front) | 1 | |
| 10 | Side bracket (rear) | 1 | |
| 11 | Starter lever shaft | 1 | |
| 12 | Starter lever shaft bracket | 4 | |
| 13 | Plastic bushings | 4 | |
| 14 | Plastic washer | 1 | |

6





| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------|------|--|
| 15 | Synchronization screw | 1 | |
| 16 | Synchronization screw spring | 1 | |
| 17 | Synchronization rod | 1 | |
| 18 | Throttle cable | 2 | |
| 19 | Carburetor | 4 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |





| Order | Job/Part | Q'ty | Remarks |
|----------------|------------------------------|------|--|
| | Disassembling the carburetor | | Remove the parts in the order listed. |
| | | | NOTE: |
| | | | The remaining steps should be followed |
| | | | for all four of the carburetors. |
| | | | • Before disassembling the carburetor, |
| | | | the pilot screw is turned out from the |
| | | | seated position to its set position |
| | | | |
| 1 | Pilot air jet No. 1 | 1 | |
| 2 | Starter plunger assembly | 1 | |
| 3 | Starter body | 1 | |
| 4 | Gasket | 1 | |
| 5 | Coasting enricher cover | 1 | |
| 6 | Coasting enricher spring | 1 | |
| \overline{O} | Coasting enricher | 1 | |





| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------------|------|---------|
| 8 | Float chamber | 1 | |
| 9 | Float chamber rubber gasket | 1 | |
| 10 | Float | 1 | |
| 1 | Needle valve | 1 | |
| 12 | Needle jet screw | 1 | |
| 13 | Main jet | 1 | |
| (14) | Jet block | 1 | |
| 15 | Gasket | 1 | |
| 16 | Main bleed pipe | 1 | |
| 17 | Pilot jet | 1 | |
| 18 | Vacuum chamber cover | 1 | |
| (19) | Piston valve spring | 1 | |
| 20 | Pilot air jet No. 2 | 1 | |
| 21 | Plastic screw | 1 | |
| 2 | Jet needle kit | 1 | |





| Order | Job/Part | Q'ty | Remarks |
|-------|--------------|------|---------------------------------------|
| 23 | Piston valve | 1 | |
| 24 | Needle jet | 1 | |
| | | | For assembly, reverse the disassembly |
| | | | procedure. |



EAS00486 CHECKING THE CARBURETORS

The following procedure applies to all of the carburetors.

NOTE:

Before disassembling the carburetor, make sure to note the number of times the pilot screw is turned out from the seated position to its set position.

- 1. Check:
- carburetor body
- float chamber
- jet housing Cracks/damage → Replace.







- 2. Check:
- fuel passages
 Obstruction → Clean.
- ****
- a. Wash the carburetor in a petroleum-based solvent. Do not use any caustic carburetor cleaning solution.
- b. Blow out all of the passages and jets with compressed air.

- 3. Check:
- float chamber body Dirt \rightarrow Clean.
- 4. Check:
- float chamber rubber gasket ①
 Cracks/damage/wear → Replace.
- 5. Check:
- float
 - Damage \rightarrow Replace.
- 6. Check:
- needle valve ①
 Damage/obstruction/wear → Replace the needle valve.









- 7. Check:
- piston valve ①
 Damage/scratches/wear→ Replace.
- piston valve diaphragm ② Cracks/tears → Replace.
- 8. Check:
- vacuum chamber cover 1
- piston valve spring 2
- jet needle holder ③
- jet needle spring ④
 Cracks/damage → Replace.
- 9. Check:
- jet needle kit ①
- needle jet ②
- main jet 3
- pilot jet ④
- pilot air jet No. 1 (5)
- pilot air jet No. 2 6
- starter plunger assembly ⑦ Bends/damage/wear → Replace.
 Obstruction → Clean.
 Blow out the jets with compressed air.



10.Check:

 piston valve movement Insert the piston valve into the carburetor body and move it up and down.
 Tightness → Replace the piston valve.

11.Check:

- fuel feed hoses
- fuel hoses
 Cracks/damage/wear → Replace.
 Obstruction → Clean.
 Blow out the hoses with compressed air.



ASSEMBLING THE CARBURETORS

The following procedure applies to all of the carburetors.

NOTE:

Before assembling the carburetor, make sure to turn out the pilot screw the same number of times, as noted before disassembly, from the seated position to the set position.

CAUTION:

- Before assembling the carburetors, wash all of the parts in a petroleum-based solvent.
- Always use a new gasket.







- 1. Install:
- gasket ①
- O-ring (2)
- needle jet ③
- jet block (4)

NOTE: .

Align the slot (a) on the needle jet with the projection (b) on the jet block.

- 2. Install:
- piston valve ①
- jet needle kit
- jet needle holder
- piston valve spring
- vacuum chamber cover ②

NOTE:

- Install the end of the piston valve spring onto the spring guide on the vacuum chamber cover.
- Align the tab (a) on the piston valve diaphragm with the recess (b) in the carburetor body.





- 3. Install:
- coasting enricher ①

- coasting enricher spring
- coasting enricher cover 2

NOTE: _

Align the tab (a) on the coasting enricher with the recess (b) in the carburetor body.

EAS00493 INSTALLING THE CARBURETORS

- 1. Adjust:
- carburetor synchronization Refer to "SYNCHRONIZING THE CARBU-RETORS" in chapter 3.
- 2. Adjust:
- engine idling speed

Engine idling speed 950 ~ 1,050 r/min 1,050 ~ 1,150 r/min (for California)

Refer to "ADJUSTING THE ENGINE IDLING SPEED" in chapter 3.

- 3. Adjust:
- throttle cable free play



Throttle cable free play (at the flange of the throttle grip) 3 ~ 5 mm (0.12 ~ 0.20 in)

Refer to "ADJUSTING THE THROTTLE CABLE FREE PLAY" in chapter 3.





MEASURING AND ADJUSTING THE FUEL LEVEL

- 1. Measure:
- fuel level (a)

Out of specification \rightarrow Adjust.



(below the line on the vacuum chamber) 15 ~ 17 mm (0.59 ~ 0.67 in)

- a. Stand the motorcycle on a level surface.
- b. Place the motorcycle on a suitable stand to ensure that the motorcycle is standing straight up.
- c. Install the fuel level gauge ① onto the fuel drain pipe ②.

Fuel level gauge YU-01312-A

- d. Loosen the fuel drain screw ③.
- e. Hold the fuel level gauge vertically next to the line on the vacuum chamber ④.
- f. Measure the fuel level (a) on both sides of the carburetor assembly.

NOTE:

The fuel level readings should be equal on both sides.

- 2. Adjust:
- fuel level

- a. Remove the carburetor assembly.
- b. Check the needle valve seat and needle valve.
- c. If either is worn, replace them as a set.
- d. If both are fine, adjust the float level by slightly bending the float tang ①.
- e. Install the carburetor assembly.
- f. Measure the fuel level again.
- g. Repeat steps (a) to (f) until the fuel level is within specification.







CHECKING THE FUEL PUMP

- 1. Check:
- fuel pump

- a. Remove the top cover and air filter case.
 Refer to "TOP COVER AND COVERS" and "AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD" in chapter 3.
- b. Disconnect the fuel hose (fuel pump to carburetor) ① from the carburetor.
- c. Place a container under the end of the fuel hose.
- d. Install the top cover and air filter case.
 Refer to "TOP COVER AND COVERS" and "AIR FILTER CASE AND ELECTRICAL COMPONENTS BOARD" in chapter 3.
- e. Start the engine and check if fuel flows from the fuel hose ①.

| Fuel flows. | Fuel pump is OK. | | |
|---------------------|------------------------|--|--|
| Fuel does not flow. | Replace the fuel pump. | | |

f. Stop the engine and check if the fuel stops flowing from the fuel hose ①.

| Fuel stops flowing. | Fuel pump is C | |)K. | |
|---------------------|------------------|-----|------|--|
| Fuel flows. | Replace pump. | the | fuel | |



EAS00514

CHASSIS

FRONT WHEEL AND BRAKE DISCS



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------------|------|--|
| | Removing the front wheel and brake | | Remove the parts in the order listed. |
| | discs | | |
| | | | NOTE: |
| | | | Place the motorcycle on a suitable stand |
| | | | so that the front wheel is elevated. |
| | | | |
| 1 | Speedometer cable | 1 | |
| 2 | Brake hose holder (left and right) | 2 | |
| 3 | Brake caliper (left and right) | 2 | 1 Refer to "REMOVING THE |
| 4 | Wheel axle pinch bolt | 1 | Loosen. FRONT WHEEL" and |
| 5 | Front wheel axle | 1 | "INSTALLING THE |
| 6 | Front wheel | 1 | J FRONT WHEEL". |

CHAS



| Order | Job/Part | Q'ty | Remarks |
|-------------|--|-------------|---|
| 7 8 9 | Speedometer gear unit Collar Brake disc (left and right) | 1 1 2 | Refer to "INSTALLING THE FRONT WHEEL". |
| | | | cedure. |

CHAS



| Order | Job/Part | Q'ty | Remarks |
|-------|--------------------------------|------|---------------------------------------|
| | Disassembling the front wheel | | Remove the parts in the order listed. |
| 1 | Oil seal (left and right) | 2 | Refer to "DISASSEMBLING THE FRONT |
| | | | WHEEL" and "ASSEMBLING THE |
| | | | FRONT WHEEL". |
| 2 | Speedometer clutch retainer | 1 | |
| 3 | Speedometer clutch | 1 | |
| 4 | Wheel bearing (left and right) | 2 | Refer to "DISASSEMBLING THE FRONT |
| | | | WHEEL" and "ASSEMBLING THE |
| | | | FRONT WHEEL". |
| 5 | Spacer flange | 1 | |
| 6 | Spacer | 1 | |
| | | | For assembly, reverse the disassembly |
| | | | procedure. |



EAS00521 **REMOVING THE FRONT WHEEL**

1. Stand the motorcycle on a level surface.

A WARNING

Securely support the motorcycle so that there is no danger of it falling over.

NOTE: __

Place the motorcycle on a suitable stand so that the front wheel is elevated.

- 2. Remove:
- · left brake caliper
- · right brake caliper

NOTE: _

Do not squeeze the brake lever when removing the brake calipers.

- 3. Elevate:
- front wheel

NOTE:

Place the motorcycle on a suitable stand so that the front wheel is elevated.





EAS00523

DISASSEMBLING THE FRONT WHEEL

- 1. Remove:
- oil seals
- wheel bearings

- a. Clean the outside of the front wheel hub.
- b. Remove the oil seals (1) with a flat-head screwdriver.

NOTE: _

To prevent damaging the wheel, place a rag (2) between the screwdriver and the wheel surface.

c. Remove the wheel bearings ③ with a general bearing puller.







CHECKING THE FRONT WHEEL

- 1. Check:
- front wheel axle Roll the front wheel axle on a flat surface.
 Bends → Replace.

A WARNING

Do not attempt to straighten a bent front wheel axle.

- 2. Check:
- tire
- front wheel
 - Damage/wear \rightarrow Replace.
 - Refer to "CHECKING THE TIRES" and "CHECKING THE WHEELS" in chapter 3.



- 3. Measure:
- radial wheel runout ①
- lateral wheel runout ②
 Over the specified limits → Replace.



Radial wheel runout limit 1 mm (0.04 in) Lateral wheel runout limit 0.5 mm (0.02 in)

- 4. Check:
- collar Damage/wear \rightarrow Replace.



- 5. Check:
- wheel bearings Front wheel turns roughly or is loose \rightarrow Replace the wheel bearings.
- oil seals
 Damage/wear → Replace.

FRONT WHEEL AND BRAKE DISCS













- 6. Replace:
- wheel bearings New
- oil seals New

- a. Clean the outside of the front wheel hub.
- b. Remove the oil seals ① with a flat-head screwdriver.

NOTE: _

To prevent damaging the wheel, place a rag (2) between the screwdriver and the wheel surface.

- c. Remove the wheel bearings ③ with a general bearing puller.
- d. Install the new wheel bearings and oil seals in the reverse order of disassembly.

CAUTION:

Do not contact the wheel bearing inner race 4 or balls (5). Contact should be made only with the outer race (6).

NOTE:

Use a socket ⑦ that matches the diameter of the wheel bearing outer race and oil seal.



CHECKING THE BRAKE DISCS

The following procedure applies to all of the brake discs.

- 1. Check:
- brake disc

Damage/galling \rightarrow Replace.

- 2. Measure:
- brake disc deflection

Out of specification \rightarrow Correct the brake disc deflection or replace the brake disc.



A Front

- **B** Rear
- (a) 1.5 mm (0.006 in) from the edge of the brake discs.

FRONT WHEEL AND BRAKE DISCS



- a. Place the motorcycle on a suitable stand so that the wheel is elevated.
- b. Before measuring the front brake disc deflection, turn the handlebar to the left or right to ensure that the front wheel is stationary.
- c. Remove the brake caliper.
- d. Hold the dial gauge at a right angle against the brake disc surface.
- e. Measure the deflection 2 ~ 3 mm (0.08 ~ 0.12 in) below the edge of the brake disc.

- 3. Measure:
- brake disc thickness
 Measure the brake disc thickness at a few different locations.

Out of specification \rightarrow Replace.



- 4. Adjust:
- brake disc deflection
- ****
- a. Remove the brake disc.
- b. Rotate the brake disc by one bolt hole.
- c. Install the brake disc.

NOTE: .

Tighten the brake disc bolts in stages and in a crisscross pattern.



Brake disc bolt 23 Nm (2.3 m • kg, 17 ft • lb) LOCTITE®

- d. Measure the brake disc deflection.
- e. If out of specification, repeat the adjustment steps until the brake disc deflection is within specification.
- f. If the brake disc deflection cannot be brought within specification, replace the brake disc.









CHECKING THE SPEEDOMETER GEAR

- 1. Check:
- speedometer clutch Bends/damage/wear → Replace.
- 2. Check:
- speedometer gear unit Damage/wear → Replace.

ASSEMBLING THE FRONT WHEEL

- 1. Install:
- wheel bearings New
- oil seals New

a. Install the new wheel bearings and oil seals in the reverse order of disassembly.

CAUTION:

Do not contact the wheel bearing inner race (1) or balls (2). Contact should be made only with the outer race (3).

NOTE: ____

Use a socket ④ that matches the diameter of the wheel bearing outer race and oil seal.

EAS00542

INSTALLING THE FRONT WHEEL

- 1. Lubricate:
- wheel axle
- wheel bearings
- oil seal lips
- speedometer gear unit



- 2. Install:
- brake discs ①

🔌 23 Nm (2.3 m · kg, 17 ft · lb)

NOTE: .

- Apply the locking agent (LOCTITE[®]) to the threads of the brake disc bolts.
- Tighten the brake disc bolts in stages and in a crisscross pattern.









FRONT WHEEL AND BRAKE DISCS









- 3. Install:
- speedometer gear unit

NOTE: _

Make sure the speedometer gear unit and the wheel hub are installed with the two projections ① meshed into the two slots ② respectively.

- 4. Install:
- collar
- 5. Install:
- front wheel

NOTE: .

Make sure the slot in the speedometer gear unit fits over the stopper on the outer tube.

- 6. Tighten:
- front wheel axle ①

🔌 58 Nm (5.8 m · kg, 42 ft · lb)

wheel axle pinch bolt (2)

🔌 20 Nm (2.0 m · kg, 14 ft · lb)

brake caliper bolts ③

🔌 40 Nm (4.0 m · kg, 29 ft · lb)

Make sure the brake cable is routed properly.

CAUTION:

Before tightening the wheel axle nut, push down hard on the handlebar several times and check if the front fork rebounds smoothly.

EAS00549

ADJUSTING THE FRONT WHEEL STATIC BALANCE

NOTE: .

- After replacing the tire, wheel or both, the front wheel static balance should be adjusted.
- Adjust the front wheel static balance with the brake discs installed.

FRONT WHEEL AND BRAKE DISCS





- 1. Remove:
- balancing weight(s)
- 2. Find:
- front wheel's heavy spot

NOTE: _____

CHAS

Place the front wheel on a suitable balancing stand.

- a. Spin the front wheel.
- b. When the front wheel stops, put an "X" mark at the bottom of the wheel.
- c. Turn the front wheel 90° so that the "X" mark is positioned as shown.
- d. Release the front wheel.
- e. When the wheel stops, put an "X" mark at the bottom of the wheel.
- f. Repeat steps (d) through (f) several times until all the marks come to rest at the same spot.
- g. The spot where all the marks come to rest is the front wheel's heavy spot "X".





- 3. Adjust:
- front wheel static balance

a. Install a balancing weight ① onto the rim exactly opposite the heavy spot "X".

NOTE:

Start with the lightest weight.

- b. Turn the front wheel 90° so that the heavy spot is positioned as shown.
- c. If the heavy spot does not stay in that position, install a heavier weight.
- d. Repeat steps (b) and (c) until the front wheel is balanced.





- 4. Check:
- front wheel static balance
- ****
- a. Turn the front wheel and make sure it stays at each position shown.
- b. If the front wheel does not remain stationary at all of the positions, rebalance it.
- *****



REAR WHEEL AND BRAKE DISC



| Order | Job/Part | Q'ty | | Remarks |
|-------|--|------|----------------------|--------------------------------|
| | Removing the rear wheel and brake disc | | Remove the | e parts in the order listed. |
| | | | NOTE: | |
| | | | Place the n | notorcycle on a suitable stand |
| | | | so that the | rear wheel is elevated. |
| | | | | |
| 1 | Brake caliper | 1 | - | |
| 2 | Wheel axle nut | 1 | | Refer to "REMOVING THE |
| 3 | Pinch bolt | 1 | Loosen. | -REAR WHEEL" and |
| 4 | Rear wheel axle | 1 | | "INSTALLING THE REAR |
| 5 | Brake caliper bracket | 1 | | WHEEL". |
| 6 | Rear wheel | 1 | - | |
| 7 | Collar | 1 | | |
| 8 | Brake disc | 1 | | |
| | | | For installa cedure. | tion, reverse the removal pro- |







| Order | Job/Part | Q'ty | Remarks |
|----------------|------------------------------|------|---------------------------------------|
| | Disassembling the rear wheel | | Remove the parts in the order listed. |
| 1 | Dust cover | 1 | |
| 2 | Hub dust seal | 1 | |
| 3 | Circuit | 1 | |
| 4 | Clutch hub | 1 | |
| 5 | O-ring | 1 | |
| 6 | Damper | 6 | |
| \overline{O} | Oil seal | 1 | |
| 8 | Circlip | 1 | |
| 9 | Bearing | 1 | |
| 10 | Flange spacer | 1 | |





| Order | Job/Part | Q'ty | Remarks |
|-------|----------|------|---------------------------------------|
| (1) | Spacer | 1 | |
| (12) | Collar | 1 | |
| 13 | Oil seal | 1 | |
| (14) | Bearing | 1 | |
| | | | For assembly, reverse the disassembly |
| | | | procedure. |



REMOVING THE REAR WHEEL

1. Stand the motorcycle on a level surface.

A WARNING

Securely support the motorcycle so that there is no danger of it falling over.

NOTE: ____

Place the motorcycle on a suitable stand so that the rear wheel is elevated.

- 2. Remove:
- brake caliper 1

NOTE:

Do not depress the brake pedal when removing the brake caliper.

- 3. Loosen:
- wheel axle nut ①
- pinch bolt 2

- 4. Remove:
- wheel axle nut
- washer
- wheel axle ①
- washer
- 5. Remove:
- rear wheel Move the rear wheel to the right to separate it from the final drive housing.











CHECKING THE REAR WHEEL

- 1. Check:
- wheel axle
- rear wheel
- wheel bearings
- oil seals Refer to "FRONT WHEEL AND BRAKE DISCS".
- 2. Check:
- tire
- rear wheel Damage/wear → Replace. Refer to "CHECKING THE TIRES" and "CHECKING THE WHEELS" in chapter 3.
- 3. Measure:
- radial wheel runout
- lateral wheel runout Refer to "FRONT WHEEL AND BRAKE DISCS".

CHECKING THE REAR WHEEL DRIVE HUB

- 1. Check:
- rear wheel drive hub Cracks/damage → Replace.
- rear wheel drive hub dampers Damage/wear → Replace.

EAS00572

INSTALLING THE REAR WHEEL

- 1. Lubricate:
- wheel axle
- wheel bearings
- oil seal lips



Recommended lubricant Lithium soap base grease

- 2. Tighten:
- wheel axle nut
 - 🔌 150 Nm (15.0 m · kg, 110 ft · lb)
- pinch bolt
- 🔌 20 Nm (2.0 m · kg, 14 ft · lb)
- brake caliper bolts

🔌 40 Nm (4.0 m · kg, 29 ft · lb)

brake torque rod nut

🔌 22 Nm (2.2 m · kg, 16 ft · lb)





ADJUSTING THE REAR WHEEL STATIC BALANCE

NOTE: _

- After replacing the tire, wheel or both, the rear wheel static balance should be adjusted.
- Adjust the rear wheel static balance with the brake disc and rear wheel drive hub installed.
- 1. Adjust:
- rear wheel static balance Refer to "FRONT WHEEL AND BRAKE DISCS".



FRONT AND REAR BRAKES



| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------------|------|--|
| | Removing the front brake pads | | Remove the parts in the order listed. |
| | | | The following procedure applies to both |
| | | | of the front brake calipers. |
| 1 | Brake caliper bolt | 2 | |
| 2 | Brake hose holder bolt | 1 | |
| 3 | Brake pad cover | 1 | |
| 4 | Brake pad clip | 2 | Refer to "REPLACING THE FRONT |
| 5 | Brake pad pin | 2 | BRAKE PADS". |
| 6 | Brake pad spring | 1 | |
| 7 | Brake pad | 2 | |
| 8 | Brake pad shim (left and right) | 2 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |

FRONT AND REAR BRAKES





| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------------|------|--|
| | Removing the rear brake pads | | Remove the parts in the order listed. |
| 1 | Brake caliper bolt | 2 | 7 |
| 2 | Brake pad cover | 1 | |
| 3 | Brake pad clip | 2 | |
| 4 | Brake pad pin | 2 | Relef to REPLACING THE REAR |
| 5 | Brake pad spring | 1 | BRARE FADS . |
| 6 | Brake pad | 2 | |
| 7 | Brake pad shim (left and right) | 2 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |



EAS00579 CAUTION:

Disc brake components rarely require disassembly.

Therefore, always follow these preventive measures:

- Never disassemble brake components unless absolutely necessary.
- If any connection on the hydraulic brake system is disconnected, the entire brake system must be disassembled, drained, cleaned, properly filled, and bled after reassembly.
- Never use solvents on internal brake components.
- Use only clean or new brake fluid for cleaning brake components.
- Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.
- Avoid brake fluid coming into contact with the eyes as it can cause serious injury.

FIRST AID FOR BRAKE FLUID ENTERING THE EYES:

• Flush with water for 15 minutes and get immediate medical attention.

EAS00582

REPLACING THE FRONT BRAKE PADS

The following procedure applies to both brake calipers.

NOTE: .

When replacing the brake pads, it is not necessary to disconnect the brake hose or disassemble the brake caliper.





- 1. Remove:
- brake caliper bolt ①
- brake hose holder bolt ②
- brake caliper ③
- brake pad cover ④

FRONT AND REAR BRAKES









- 2. Remove:
- \bullet brake pad clips ()
- \bullet brake pad pins (2)
- \bullet brake pad spring 3

- 3. Remove:
- brake pads ①

 (along with the brake pad shims)

- 4. Measure:
- brake pad wear limit ⓐ Out of specification → Replace the brake pads as a set.



Brake pad wear limit 0.5 mm (0.02 in)

- 5. Install:
- brake pad shims (onto the brake pads)
- brake pads
- brake pad spring

NOTE:

Always install new brake pads, brake pad shims, and a brake pad spring as a set.

- a. Connect a clear plastic hose ① tightly to the bleed screw ②. Put the other end of the hose into an open container.
- b. Loosen the bleed screw and push the brake caliper pistons into the brake caliper with your finger.
- c. Tighten the bleed screw.



Bleed screw 6 Nm (0.6 m • kg, 4.3 ft • lb)







- d. Install a new brake pad shim onto the new brake pads.
- e. Install new brake pads and a new brake pad spring.

NOTE: .

The arrow (a) on the brake pad spring must point in the direction of disc rotation.

- 6. Install:
- brake pad pins
- brake pad clips
- brake pad cover
- brake caliper 🔌 40 Nm (4.0 m · kg, 29 ft · lb)



- 7. Check:
- brake fluid level
 Below the minimum level mark ⓐ → Add the recommended brake fluid to the proper level.

Refer to "CHECKING THE BRAKE FLUID LEVEL" in chapter 3.

- 8. Check:
- brake lever operation
 Soft or spongy feeling → Bleed the brake system.
 Refer to "BLEEDING THE HYDRAULIC

BRAKE SYSTEM" in chapter 3.



REPLACING THE REAR BRAKE PADS

When replacing the brake pads, it is not necessary to disconnect the brake hose or disassemble the brake caliper.

- 1. Remove:
- brake caliper (1)
- brake pad cover ②

FRONT AND REAR BRAKES









- 2. Remove:
- brake pad clips ①
- brake pad pins ②
- brake pad spring ③

- 3. Remove:
- brake pads ①

 (along with the brake pad shims)

- 4. Measure:
- brake pad wear limit ⓐ Out of specification → Replace the brake pads as a set.



Brake pad wear limit 0.5 mm (0.02 in)

- 5. Install:
- brake pad shims (onto the brake pads)
- brake pads
- brake pad spring

NOTE:

Always install new brake pads, brake pad shims, and a brake pad spring as a set.

- a. Connect a clear plastic hose ① tightly to the bleed screw ②. Put the other end of the hose into an open container.
- b. Loosen the bleed screw and push the brake caliper pistons into the brake caliper with your finger.
- c. Tighten the bleed screw.



Bleed screw 6 Nm (0.6 m • kg, 4.3 ft • lb)









d. Install a new brake pad shim ③ onto each new brake pad ④.

NOTE:

The arrow (a) on the brake pad shim must point in the direction of disc rotation.

e. Install new brake pads and a new brake pad spring (5).

NOTE: _

The longer tangs (b) of the brake pad spring must point in the direction of disc rotation.

- 6. Install:
- brake pad pins
- brake pad clips
- brake pad cover
- brake caliper 🛛 🛰 40 Nm (4.0 m · kg, 29 ft · lb)



- 7. Check:
- brake fluid level

Below the minimum level mark (a) \rightarrow Add the recommended brake fluid to the proper level.

Refer to "CHECKING THE BRAKE FLUID LEVEL" in chapter 3.

7

- 8. Check:
- brake pedal operation Soft or spongy feeling \rightarrow Bleed the brake

system. Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" in chapter 3.



FRONT AND REAR BRAKES





| Order | Job/Part | Q'ty | Remarks | |
|--------|--------------------------------------|------|---------------------------------------|--|
| | Removing the front brake master | | Remove the parts in the order listed. | |
| | cylinder | | | |
| | Brake fluid | | Drain. | |
| 1 | Rear view mirror | 1 | | |
| 2 | Brake master cylinder reservoir cap | 1 | | |
| 3 | Brake master cylinder reservoir dia- | 1 | | |
| | phragm | | | |
| 4 | Brake lever | 1 | | |
| 5 | Brake lever spring | 1 | | |
| 6 | Front brake light switch connector | 2 | Disconnect. | |
| 7 | Union bolt | 1 | ₁ Refer to "DISASSEM- | |
| 8 | Brake hose | 1 | Disconnect. BLING THE FRONT | |
| 9 | Copper washer | 2 | BRAKE MASTER CYLIN- | |
| | | | DER" and "ASSEMBLING | |
| | | | AND INSTALLING THE | |
| | | | FRONT BRAKE MASTER | |
| | | | CYLINDER". | |
| 7 - 25 | | | | |




| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------|------|--|
| 10 | Brake master cylinder holder | 1 | Refer to "ASSEMBLING AND INSTALL- |
| 11 | Brake master cylinder | 1 | ING THE FRONT BRAKE MASTER |
| 12 | Front brake light switch | 1 | CYLINDER". |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |





| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------------|------|---------------------------------------|
| | Disassembling the front brake mas- | | Remove the parts in the order listed. |
| | ter cylinder | | |
| 1 | Dust boot | 1 | |
| 2 | Circlip | 1 | |
| 3 | Brake master cylinder kit | 1 | |
| 4 | Brake master cylinder | 1 | |
| | | | For assembly, reverse the disassembly |
| | | | procedure. |

CHAS



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------------|------|--|
| | Removing the rear brake master cyl- | | Remove the parts in the order listed. |
| | inder | | |
| | Right side cover | | Refer to "SEATS AND SIDE COVERS" in chapter 3 |
| | Right rider footrest | | Refer to "ENGINE" in chapter 4 |
| | Brake fluid | | Drain |
| 1 | Brake fluid reservoir cap | 1 | 2.000 |
| 2 | Brake fluid reservoir diaphragm | 1 | |
| 3 | Brake fluid reservoir | 1 | |
| 4 | Brake fluid reservoir hose | 1 | |
| 5 | Union bolt | 1 | Refer to "DISASSEMBLING |
| 6 | Copper washer | 2 | -THE REAR BRAKE MASTER |
| 7 | Brake hose | 1 | Disconnect. CYLINDER" and "ASSEM- |
| 8 | Brake master cylinder bolt | 2 | BLING AND INSTALLING |
| 9 | Cotter pin | 1 | THE REAR BRAKE CALI- PER". |



CHAS



| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------|------|--|
| 10 | Pin | 1 | |
| 11 | Brake master cylinder | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |





| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------------------|------|--|
| | Disassembling the rear brake mas- | | Remove the parts in the order listed. |
| | ter cylinder | | |
| 1 | Hose joint | 1 | |
| 2 | Dust boot | 1 | |
| 3 | Circlip | 1 | |
| 4 | Brake master cylinder push rod | 1 | |
| 5 | Brake master cylinder kit | 1 | |
| 6 | Brake master cylinder | 1 | |
| | | | For assembly, reverse the disassembly procedure. |



DISASSEMBLING THE FRONT BRAKE MASTER CYLINDER

NOTE: _

Before disassembling the front brake master cylinder, drain the brake fluid from the entire brake system.



- union bolt ①
- copper washers ②
- brake hose ③

NOTE: _

To collect any remaining brake fluid, place a container under the master cylinder and the end of the brake hose.

DISASSEMBLING THE REAR BRAKE MASTER CYLINDER

- 1. Remove:
- \bullet union bolt (1)
- copper washers (2)
- brake hose ③

NOTE: _

To collect any remaining brake fluid, place a container under the master cylinder and the end of the brake hose.

















CHECKING THE FRONT AND REAR BRAKE MASTER CYLINDERS

The following procedure applies to the both of the brake master cylinders.

- 1. Check:
- brake master cylinder ①
 Damage/scratches/wear → Replace.
- brake fluid delivery passages (brake master cylinder body)
 Obstruction → Blow out with compressed air.
- A Front
- B Rear

- 2. Check:
- brake master cylinder kit ①
 Damage/scratches/wear → Replace.
- A Front
- B Rear
- 3. Check:
- rear brake fluid reservoir ①
 Cracks/damage → Replace.
- rear brake fluid reservoir diaphragm ② Cracks/damage → Replace.
- 7

- 4. Check:
- front brake master cylinder reservoir ① Cracks/damage → Replace.
- \bullet front brake master cylinder reservoir diaphragm (2)

 $\mathsf{Damage/wear} \to \mathsf{Replace}.$

- 5. Check:
- brake hoses Cracks/damage/wear \rightarrow Replace.



ASSEMBLING AND INSTALLING THE FRONT BRAKE MASTER CYLINDER

A WARNING

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components.









Recommended brake fluid DOT 4

1. Install:

- brake master cylinder ①
- brake master cylinder holder 2

🔌 9 Nm (0.9 m · kg, 6.5 ft · lb)

NOTE: _

- Adjust the brake master cylinder to the proper angle, as shown.
- First, tighten the upper bolt, then the lower bolt.

- 2. Install:
- copper washers New
- brake hose 1
- union bolt 2 🔌 30 Nm (3.0 m · kg, 22 ft · lb)

Proper brake hose routing is essential to insure safe motorcycle operation. Refer to "CABLE ROUTING".

NOTE: _

- While holding the brake hose, tighten the union bolt as shown.
- Turn the handlebar to the left and to the right to make sure the brake hose does not touch other parts (e.g., wire harness, cables, leads). Correct if necessary.



- 3. Fill:
- brake master cylinder reservoir (with the specified amount of the recommended brake fluid)



Recommended brake fluid DOT 4

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake master cylinder reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

CAUTION:

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

- 4. Bleed:
- brake system Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" in chapter 3.



- 5. Check:
- brake fluid level

Below the minimum level mark (a) \rightarrow Add the recommended brake fluid to the proper level.

Refer to "CHECKING THE BRAKE FLUID LEVEL" in chapter 3.



- 6. Check:
- brake lever operation
- Soft or spongy feeling \rightarrow Bleed the brake system.

Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" in chapter 3.

ASSEMBLING AND INSTALLING THE REAR BRAKE MASTER CYLINDER

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components.





Recommended brake fluid DOT 4

- 1. Install:
- copper washers ① New
- brake hose 2
- union bolt ③ 🛛 🔀 30 Nm (3.0 m · kg, 22 ft · lb)

A WARNING

Proper brake hose routing is essential to insure safe motorcycle operation. Refer to "CABLE ROUTING".

CAUTION:

When installing the brake hose onto the brake master cylinder, make sure the brake pipe touches the projection (a) as shown.

- 2. Fill:
- brake fluid reservoir

Recommended brake fluid DOT 4



A WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

CAUTION:

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

- 3. Bleed:
- brake system Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" in chapter 3.



- 4. Check:
- brake fluid level

Below the minimum level mark (a) \rightarrow Add the recommended brake fluid to the proper level.

Refer to "CHECKING THE BRAKE FLUID LEVEL" in chapter 3.





- 5. Adjust:
- brake pedal position ⓐ Refer to "ADJUSTING THE REAR BRAKE" in chapter 3.



Brake pedal position (below the top of the rider footrest) 20 mm (0.79 in)

- 6. Adjust:
- rear brake light operation timing Refer to "ADJUSTING THE REAR BRAKE LIGHT SWITCH" in chapter 3.

CHAS 55

1 5 40 Nm (4.0 m · kg, 29 ft · lb)

| Order | Job/Part | Q'ty | | Remarks |
|-------|-----------------------------------|------|-----------------|-----------------------------|
| | Removing the front brake calipers | | Remove the p | parts in the order listed. |
| | | | The following | procedure applies to both |
| | | | of the front br | ake calipers. |
| | Brake fluid | | Drain. | |
| 1 | Brake hose holder bolt | 1 | - | Refer to "DISASSEM- |
| 2 | Union bolt | 1 | | BLING THE FRONT |
| 3 | Brake hose | 1 | Disconnect. | BRAKE CALIPERS" and |
| 4 | Copper washer | 2 | | "ASSEMBLING AND |
| 5 | Brake caliper bolt | 2 | | INSTALLING THE FRONT |
| 6 | Brake caliper | 1 | - | BRAKE CALIPERS". |
| | | | For installatio | n, reverse the removal pro- |
| | | | cedure. | |





| Order | Job/Part | Q'ty | Remarks |
|----------------|-------------------------------------|------|--|
| | Disassembling the front brake cali- | | Remove the parts in the order listed. |
| | pers | | |
| | | | The following procedure applies to both |
| | | | of the front brake calipers. |
| 1 | Brake pad cover | 1 | |
| 2 | Brake pad clip | 2 | |
| 3 | Brake pad pin | 2 | |
| 4 | Brake pad spring | 1 | |
| 5 | Brake pad | 2 | |
| 6 | Brake pad shim (left and right) | 2 | |
| \overline{O} | Brake caliper piston | 4 | Refer to "DISASSEMBLING THE |
| 8 | Brake caliper piston seal | 8 | FRONT BRAKE CALIPERS". |
| 9 | Bleed screw | 1 | |
| | | | For assembly, reverse the disassembly procedure. |





| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------------|------|--|
| | Removing the rear brake caliper | | Remove the parts in the order listed. |
| | Brake fluid | | Drain. |
| 1 | Union bolt | 1 | Refer to "DISASSEM- |
| 2 | Copper washer | 2 | BLING THE REAR BRAKE |
| 3 | Brake hose | 1 | Disconnect. CALIPER" and "ASSEM- |
| 4 | Brake caliper bolt | 2 | BLING AND INSTALLING |
| 5 | Brake caliper | 1 | JTHE REAR BRAKE CALI- |
| | | | PER". |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |







| Order | Job/Part | Q'ty | Remarks |
|----------------|------------------------------------|------|--|
| | Disassembling the rear brake cali- | | Remove the parts in the order listed. |
| | per | | |
| 1 | Brake pad cover | 1 | |
| 2 | Brake pad clip | 2 | |
| 3 | Brake pad pin | 2 | |
| (4) | Brake pad spring | 1 | |
| 5 | Brake pad | 2 | |
| 6 | Brake pad shim (left and right) | 2 | |
| \overline{O} | Brake caliper piston | 2 | Refer to "DISASSEMBLING THE REAR |
| 8 | Brake caliper piston seal | 4 | BRAKE CALIPER". |
| 9 | Bleed screw | 2 | |
| | | | For assembly, reverse the disassembly procedure. |



DISASSEMBLING THE FRONT BRAKE CALIPERS

The following procedure applies to both of the brake calipers.

NOTE:

Before disassembling either brake caliper, drain the brake fluid from the entire brake system.

- 1. Remove:
- union bolt ①
- copper washers (2)
- brake hose

NOTE: _

Put the end of the brake hose into a container and pump out the brake fluid carefully.

- 2. Remove:
- brake caliper pistons ①
- brake caliper piston seals (2)
- ****
- a. Secure the right side brake caliper pistons with a piece of wood ③.
- b. Blow compressed air into the brake hose joint opening (a) to force out the left side pistons from the brake caliper.

- Never try to pry out the brake caliper pistons.
- Do not loosen the bolts ④.
- c. Remove the brake caliper piston seals.
- d. Repeat the previous steps to force out the right side pistons from the brake caliper.











DISASSEMBLING THE REAR BRAKE CALIPER

NOTE:

Before disassembling the brake caliper, drain the brake fluid from the entire brake system.







- 1. Remove:
- union bolt ①
- copper washers 2
- brake hose ③

NOTE:

Put the end of the brake hose into a container and pump out the brake fluid carefully.

- 2. Remove:
- brake caliper pistons ①
- brake caliper piston seals ②
- ****
- a. Secure the right side brake caliper piston with a piece of wood ③.
- b. Blow compressed air into the brake hose joint opening (a) to force out the left side piston from the brake caliper.

- Never try to pry out the brake caliper pistons.
- Do not loosen the bolts ④.
- c. Remove the brake caliper piston seals.
- d. Repeat the previous steps to force out the right side pistons from the brake caliper.



CHECKING THE FRONT AND REAR BRAKE CALIPERS

| Recommended brake component replacement schedule | | | |
|---|---|--|--|
| Brake pads | If necessary | | |
| Piston seals | Every two years | | |
| Brake hoses | Every two years | | |
| Brake fluid | Every two years and whenever the brake is disassem- bled | | |







- 1. Check:
- brake caliper pistons ① Rust/scratches/wear → Replace the brake caliper.
- brake caliper cylinders (2) Scratches/wear \rightarrow Replace the brake caliper.
- brake calipers (3) Cracks/damage \rightarrow Replace.
- brake fluid delivery passages (brake caliper body)
 Obstruction → Blow out with compressed air.

A WARNING

Whenever a brake caliper is disassembled, replace the brake caliper piston seals.

- A Front
- B Rear
- 2. Check:
- rear brake caliper bracket ① Cracks/damage → Replace.





ASSEMBLING AND INSTALLING THE FRONT BRAKE CALIPERS

The following procedure applies to both of the brake calipers.

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components as they will cause the piston seals to swell and distort.
- Whenever a brake caliper is disassembled, replace the brake caliper piston seals.





Recommended brake fluid DOT 4

- 1. Install:
- brake caliper ① (temporarily)
- copper washers New
- brake hose ②
- union bolt ③ 🛛 🔌 30 Nm (3.0 m · kg, 22 ft · lb)

Proper brake hose routing is essential to insure safe motorcycle operation. Refer to "CABLE ROUTING".

CAUTION:

When installing the brake hose onto the brake caliper, make sure the brake pipe touches the projection (a) on the brake caliper.

- 2. Remove:
- brake caliper
- 3. Install:
- brake pads
- brake pad spring
- · brake pad pins
- brake pad clips
- brake caliper 🔌 40 Nm (4.0 m · kg, 29 ft · lb)
- brake hose holder Refer to "REPLACING THE FRONT BRAKE PADS".



- 4. Fill:
- brake master cylinder reservoir (with the specified amount of the recommended brake fluid)



Recommended brake fluid DOT 4

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake master cylinder reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

CAUTION:

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

- 5. Bleed:
- brake system Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" in chapter 3.



- 6. Check:
- brake fluid level

Below the minimum level mark (a) \rightarrow Add the recommended brake fluid to the proper level.

Refer to "CHECKING THE BRAKE FLUID LEVEL" in chapter 3.



- 7. Check:
- brake lever operation
- Soft or spongy feeling \rightarrow Bleed the brake system.

Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" in chapter 3.

EAS00642

ASSEMBLING AND INSTALLING THE **REAR BRAKE CALIPER**

- · Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components as they will cause the piston seals to swell and distort.
- Whenever a brake caliper is disassembled, replace the brake caliper piston seals.

Recommended brake fluid DOT 4



- 1. Install:
- brake caliper ① (temporarily)
- copper washers New
- brake hose (2)
- union bolt ③ 🛛 🛰 30 Nm (3.0 m · kg, 22 ft · lb)

A WARNING

Proper brake hose routing is essential to insure safe motorcycle operation. Refer to "CABLE ROUTING".

CAUTION:

When installing the brake hose onto the brake caliper, make sure the brake pipe touches the projection (a) on the brake caliper.



- 2. Remove:
- brake caliper
- 3. Install:
- brake pads
- brake pad spring
- brake caliper 🔌 40 Nm (4.0 m · kg, 29 ft · lb) Refer to "REPLACING THE REAR BRAKE PADS".
- 4. Fill:
- brake fluid reservoir (with the specified amount of the recommended brake fluid)

Recommended brake fluid DOT 4

A WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

CAUTION:

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

- 5. Bleed:
- brake system Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" in chapter 3.





- 6. Check:
- brake fluid level

Below the minimum level mark (a) \rightarrow Add the recommended brake fluid to the proper level.

Refer to "CHECKING THE BRAKE FLUID LEVEL" in chapter 3.

- 7. Check:
- brake pedal operation Soft or spongy feeling \rightarrow Bleed the brake system.

Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" in chapter 3.



HYDRAULIC CLUTCH



| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------------------|------|---------------------------------------|
| | Removing the clutch master cylinder | | Remove the parts in the order listed. |
| | Clutch fluid | | Drain. |
| 1 | Rear view mirror | 1 | |
| 2 | Clutch master cylinder reservoir cap | 1 | |
| 3 | Clutch master cylinder reservoir dia- | 1 | |
| | phragm | | |
| 4 | Clutch lever | 1 | Refer to "ASSEMBLING AND INSTALL- |
| 5 | Clutch push rod holder | 1 | ING THE CLUTCH MASTER CYLINDER". |
| 6 | Clutch switch connector | 2 | Disconnect. |
| 7 | Union bolt | 1 | Refer to "DISASSEM- |
| 8 | Clutch hose | 1 | Disconnect. BLING THE CLUTCH |
| 9 | Copper washer | 2 | JMASTER CYLINDER" and |
| | | | "ASSEMBLING AND |
| | | | INSTALLING THE |
| | | | CLUTCH MASTER CYLIN- |
| | | | DER". |







| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------|------|--|
| 10 | Clutch master cylinder holder | 1 | Refer to "ASSEMBLING AND INSTALL- |
| 11 | Clutch master cylinder | 1 | ING THE CLUTCH MASTER CYLINDER". |
| 12 | Clutch switch | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |





| Job/Part | Q'ty | Remarks |
|---------------------------------|--|---|
| Disassembling the clutch master | | Remove the parts in the order listed. |
| cylinder | | |
| Clutch master cylinder push rod | 1 | |
| Dust boot | 1 | |
| Spring | 1 | |
| Circlip | 1 | |
| Washer | 1 | |
| Clutch master cylinder kit | 1 | |
| Clutch master cylinder | 1 | |
| | | For assembly, reverse the disassembly procedure. |
| | Job/Part Disassembling the clutch master cylinder Clutch master cylinder push rod Dust boot Spring Circlip Washer Clutch master cylinder kit Clutch master cylinder | Job/PartQ'tyDisassembling the clutch master cylinderClutch master cylinder push rod1Clutch master cylinder push rod11Dust boot11Spring11Circlip11Washer11Clutch master cylinder kit1Clutch master cylinder kit1Clutch master cylinder1 |

CAUTION:

EAS00307

Clutch components rarely require disassembly.

Therefore, always follow these preventive measures:

- Never disassemble clutch components unless absolutely necessary.
- If any connection on the hydraulic clutch system is disconnected, the entire clutch system must be disassembled, drained, cleaned, properly filled, and bled after reassembly.
- Never use solvents on internal clutch components.
- Use only clean or new clutch fluid for cleaning clutch components.
- Clutch fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt clutch fluid immediately.
- Avoid clutch fluid coming into contact with the eyes as it can cause serious injury.

FIRST AID FOR CLUTCH FLUID ENTERING THE EYES:

• Flush with water for 15 minutes and get immediate medical attention.

DISASSEMBLING THE CLUTCH MASTER CYLINDER

NOTE:

Before disassembling the clutch master cylinder, drain the clutch fluid from the entire clutch system.



- 1. Remove:
- union bolt (1)
- copper washers (2)
- clutch hose ③

NOTE:

To collect any remaining clutch fluid, place a container under the master cylinder and the end of the clutch hose.



CHECKING THE CLUTCH MASTER CYLINDER

| Recommended clutch component replacement schedule | | | |
|--|--|--|--|
| Piston seals | Every two years | | |
| Clutch hose | Every two years | | |
| Clutch fluid | Every two years and whenever the clutch is disassem- bled | | |







- 1. Check:
- clutch master cylinder ①
 Damage/scratches/wear → Replace.
- clutch fluid delivery passage (clutch master cylinder body)
 Obstruction → Blow out with compressed air.
- 2. Check:
- clutch master cylinder kit ①
 Damage/scratches/wear → Replace.
- clutch hose Cracks/damage/wear \rightarrow Replace.



- 3. Check:
- clutch master cylinder reservoir ①
 Cranks/damage → Replace.
- clutch master cylinder reservoir diaphragm ②
 Damage/wear → Replace.
- 4. Check:
- clutch hose Cracks/damage/wear \rightarrow Replace.

ASSEMBLING AND INSTALLING THE CLUTCH MASTER CYLINDER

A WARNING

- Before installation, all internal clutch components should be cleaned and lubricated with clean or new clutch fluid.
- Never use solvents on internal clutch components.

Recommended clutch fluid Brake fluid DOT 4





- 1. Install:
- clutch master cylinder ①
- clutch master cylinder holder ②

🔌 9 Nm (0.9 m · kg, 6.5 ft · lb)

NOTE: _

- Install the clutch master cylinder holder with the "UP" mark facing up.
- Adjust the clutch master cylinder to the proper angle, as shown.
- First, tighten the upper bolt, then the lower bolt.

2. Install:

- copper washers New
- clutch hose ①
- union bolt ② 🛛 🔀 30 Nm (3.0 m · kg, 22 ft · lb)

Proper clutch hose routing is essential to insure safe motorcycle operation. Refer to "CABLE ROUTING".







NOTE: _

- While holding the clutch hose, tighten the union bolt as shown.
- Turn the handlebar to the left and to the right to make sure the clutch hose does not touch other parts (e.g., wire harness, cables, leads). Correct if necessary.
- 3. Install:
 - clutch push rod holder ①
- clutch lever 2

NOTE: __

Lubricate the clutch lever pivot with lithium soap base grease.

- 4. Fill:
- clutch master cylinder reservoir (with the specified amount of the recommended clutch fluid)



Recommended clutch fluid Brake fluid DOT 4

A WARNING

- Use only the designated clutch fluid. Other clutch fluids may cause the rubber seals to deteriorate, causing leakage and poor clutch performance.
- Refill with the same type of clutch fluid that is already in the system. Mixing clutch fluids may result in a harmful chemical reaction, leading to poor clutch performance.
- When refilling, be careful that water does not enter the clutch master cylinder reservoir. Water will significantly lower the boiling point of the clutch fluid and could cause vapor lock.



CAUTION:

Clutch fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt clutch fluid immediately.

- 5. Bleed:
- clutch system
 Refer to "BLEEDING THE HYDRAULIC
 CLUTCH SYSTEM" in chapter 3.
- 6. Check:
- clutch fluid level

Below the minimum level mark (a) \rightarrow Add the recommended clutch fluid to the proper level.

Refer to "CHECKING THE CLUTCH FLUID LEVEL" in chapter 3.

- 7. Check:
- clutch lever operation Soft or spongy feeling → Bleed the clutch system.
 Refer to "BLEEDING THE HYDRAULIC CLUTCH SYSTEM" in chapter 3.

7 - 57



CHAS

EAS00311



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------------|------|---------------------------------------|
| | Removing the clutch release cylin- | | Remove the parts in the order listed. |
| | der | | |
| | Engine oil | | Refer to "CHANGING THE ENGINE OIL" |
| | | | in chapter 3. |
| | Middle gear case cover, shift pedal | | Refer to "SHIFT SHAFT" in chapter 4. |
| | assembly | | |
| | Clutch fluid | | Drain. |
| 1 | Rubber cover | 1 | |
| 2 | Union bolt | 1 | Refer to "DISASSEM- |
| 3 | Clutch hose | 1 | Disconnect. BLING THE CLUTCH |
| 4 | Copper washer | 2 | RELEASE CYLINDER" and |
| | | | "ASSEMBLING AND |
| | | | INSTALLING THE |
| | | | CLUTCH RELEASE CYL- |
| | | | INDER". |



CHAS



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------|------|--|
| 5 | Joint | 1 | Refer to "ASSEMBLING AND INSTALL- |
| 6 | Copper washer | 1 | ING THE CLUTCH RELEASE CYLIN- |
| 7 | Clutch release cylinder | 1 | DER". |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |

CHAS of



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------------|------|---------------------------------------|
| | Disassembling the clutch release | | Remove the parts in the order listed. |
| | cylinder | | |
| 1 | Oil seal | 1 | h |
| 2 | Clutch release cylinder piston | 1 | Refer to "DISASSEMBLING THE |
| 3 | Spring | 1 | CLUTCH RELEASE CYLINDER". |
| 4 | Clutch release cylinder piston seal | 1 | |
| 5 | Bleed screw | 1 | |
| | | | For assembly, reverse the disassembly |
| | | | procedure. |





DISASSEMBLING THE CLUTCH RELEASE CYLINDER

NOTE:

Before disassembling the clutch release cylinder, drain the clutch fluid from the entire clutch system.

- 1. Remove:
- union bolt ①
- copper washers
- clutch hose 2

NOTE: _

Put the end of the clutch hose into a container and pump out the clutch fluid carefully.

- 2. Remove:
- oil seal
- clutch release cylinder piston
- spring
- clutch release cylinder piston seal
- ****
- a. Blow compressed air into the joint opening
 (a) to force out the piston from the clutch release cylinder.

- Cover the clutch release cylinder with a rag. Be careful not to get injured when the piston is expelled from the clutch release cylinder.
- Never try to pry out the clutch release cylinder piston.
- b. Remove the clutch release cylinder piston seal.






CHECKING THE CLUTCH RELEASE CYLINDER

| Recommended clutch component replacement schedule | | | | |
|--|--|--|--|--|
| Piston seals | Every two years | | | |
| Clutch hose | Every two years | | | |
| Clutch fluid | Every two years and whenever the clutch is disassem- bled | | | |





- 1. Check:
- clutch release cylinder body ①
 Cracks/damage → Replace the clutch release cylinder.

- 2. Check:
- clutch release cylinder ①
- clutch release cylinder piston ② Rust/scratches/wear → Replace the clutch release cylinder and clutch release cylinder piston as a set.





ASSEMBLING AND INSTALLING THE CLUTCH RELEASE CYLINDER

A WARNING

- Before installation, all internal clutch components should be cleaned and lubricated with clean or new clutch fluid.
- Never use solvents on internal clutch components as they will cause the piston seal to swell and distort.
- Whenever a clutch master cylinder is disassembled, replace the piston seal.

Recommended clutch fluid Brake fluid DOT 4

- 1. Install:
- clutch release cylinder ①

🔌 12 Nm (1.2 m · kg, 8.7 ft · lb)





- 2. Install:
- copper washer New
- joint ①
- 🔌 25 Nm (2.5 m · kg, 18 ft · lb)

- 3. Install:
- copper washers New
- clutch hose ①
- union bolt ② 🛛 🔀 25 Nm (2.5 m · kg, 18 ft · lb)

Proper clutch hose routing is essential to insure safe motorcycle operation. Refer to "CABLE ROUTING" in chapter 2.

HYDRAULIC CLUTCH



- 4. Fill:
- clutch master cylinder reservoir (with the specified amount of the recommended clutch fluid)



Recommended clutch fluid Brake fluid DOT 4

- Use only the designated clutch fluid. Other clutch fluids may cause the rubber seals to deteriorate, causing leakage and poor clutch performance.
- Refill with the same type of clutch fluid that is already in the system. Mixing clutch fluids may result in a harmful chemical reaction, leading to poor clutch performance.
- When refilling, be careful that water does not enter the clutch release cylinder reservoir. Water will significantly lower the boiling point of the clutch fluid and could cause vapor lock.
- CAUTION: Clutch fluid m

Clutch fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt clutch fluid immediately.

- 5. Bleed:
- clutch system Refer to "BLEEDING THE HYDRAULIC CLUTCH SYSTEM" in chapter 3.
- 6. Check:
 - clutch fluid level

Below the minimum level mark (a) \rightarrow Add the recommended clutch fluid to the proper level.

Refer to "CHECKING THE CLUTCH FLUID LEVEL" in chapter 3.

7. Check:

• clutch lever operation

Soft or spongy feeling \rightarrow Bleed the clutch system.

Refer to "BLEEDING THE HYDRAULIC CLUTCH SYSTEM" in chapter 3.





FRONT FORK



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------|------|--|
| | Removing the front fork legs | | Remove the parts in the order listed. |
| | | | The following procedure applies to both |
| | | | of the front fork legs. |
| | Front wheel | | Refer to "FRONT WHEEL AND BRAKE |
| | | | DISCS". |
| 1 | Front fender | 1 | |
| 2 | Front fender brace | 1 | |
| 3 | Front fork air valve cap | 1 | |
| 4 | Cap bolt | 1 | Loosen.] Refer to "REMOVING THE |
| 5 | Upper bracket pinch bolt | 1 | Loosen. FRONT FORK LEGS" and |
| 6 | Lower bracket pinch bolt | 2 | Loosen. "INSTALLING THE FRONT |
| 7 | Front fork leg | 1 | ^J FORK LEGS". |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |

CHAS



| Order | Job/Part | Q'ty | Remarks |
|----------------|-----------------------------------|------|---|
| | Disassembling the front fork legs | | Remove the parts in the order listed. |
| | | | The following procedure applies to both |
| | | | of the front fork legs. |
| 1 | Cap bolt | 1 | η |
| 2 | O-ring | 1 | Defer to "ASSEMPLING THE EDONT |
| 3 | Collar | 1 | FORKIEGS" |
| 4 | Spring seat | 1 | I OKK LEGS . |
| 5 | Fork spring | 1 | |
| 6 | Dust seal | 1 | |
| \overline{O} | Oil seal clip | 1 | EORK LEGS" and "ASSEMPTING THE |
| 8 | Damper rod bolt | 1 | FORK LEGS and ASSEMBLING THE |
| 9 | Copper washer | 1 | |

7

CHAS of



| Order | Job/Part | Q'ty | Remarks |
|-------|--------------------|------|---------------------------------------|
| 10 | Damper rod | 1 | Refer to "DISASSEMBLING THE FRONT |
| (1) | Damper rod spring | 1 | FORK LEGS" and "ASSEMBLING THE |
| (12) | Inner tube | 1 | FRONT FORK LEGS". |
| 13 | Oil seal | 1 | η |
| (14) | Seal spacer | 1 | |
| 15 | Outer tube bushing | 1 | Refer to "ASSEMBLING THE FRONT |
| 16 | Inner tube bushing | 1 | FORK LEGS". |
| 17 | Oil flow stopper | 1 | |
| 18 | Outer tube | 1 | |
| | | | For assembly, reverse the disassembly |
| | | | procedure. |

7 - 67



REMOVING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

1. Stand the motorcycle on a level surface.

A WARNING

Securely support the motorcycle so that there is no danger of it falling over.

NOTE: _____

Place the motorcycle on a suitable stand so that the front wheel is elevated.



- 2. Loosen:
- cap bolt ①

NOTE: _

Release the air pressure the front fork leg by pressing down on the front fork air valve ②.

- 3. Loosen:
- upper bracket pinch bolt ①
- lower bracket pinch bolts ②

A WARNING

Before loosening the upper and lower bracket pinch bolts, support the front fork leg.



• front fork leg

^{4.} Remove:











EAS00653 DISASSEMBLING THE FRONT FORK LEGS

FRONT FORK

The following procedure applies to both of the front fork legs.

- 1. Drain:
- fork oil

NOTE:

Stroke the outer tube several times while draining the fork oil.

- 2. Remove:
 - dust seal ①
- oil seal clip ② (with a flat-head screwdriver)

CAUTION:

Do not scratch the inner tube.

- 3. Remove:
- damper rod bolt
- damper rod

NOTE: .

While holding the damper rod with the damper rod holder ① and T-handle ②, loosen the damper rod assembly bolt.



- 4. Remove:
- inner tube

- a. Hold the front fork leg horizontally.
- b. Securely clamp the brake caliper bracket in a vise with soft jaws.
- c. Separate the inner tube from the outer tube by pulling the inner tube forcefully but carefully.

CAUTION:

- Excessive force will damage the oil seal and bushing. A damaged oil seal or bushing must be replaced.
- Avoid bottoming the inner tube into the outer tube during the above procedure, as the oil flow stopper will be damaged.





CHECKING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

- 1. Check:
- inner tube ①
- outer tube ②
 Bends/damage/scratches → Replace.

A WARNING

Do not attempt to straighten a bent inner tube as this may dangerously weaken it.





- 2. Measure:
- fork spring free length ⓐ
 Out of specification → Replace.

Spring free length limit 381.5 mm (15.02 in)

- 3. Check:
- damper rod ①
 Damage/wear → Replace.
 Obstruction → Blow out all of the oil passages with compressed air.
- oil flow stopper ②
 Damage → Replace.
- 4. Check:
- cap bolt O-ring Damage/wear → Replace.





ASSEMBLING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

A WARNING

- Make sure the oil levels in both front fork legs are equal.
- Uneven oil levels can result in poor handling and a loss of stability.

NOTE: __

- When assembling the front fork leg, be sure to replace the following parts:
 - inner tube bushing
 - outer tube bushing
 - oil seal
- dust seal
- Before assembling the front fork leg, make sure all of the components are clean.
- 1. Install:
- damper rod ①



Allow the damper rod to slide slowly down the inner tube until it protrudes from the bottom of the inner tube. Be careful not to damage the inner tube.

- 2. Install:
- inner tube bushing ① New
- oil flow stopper 2
- 3. Lubricate:
- inner tube's outer surface

Recommended lubricant Fork oil 10W or equivalent

- 4. Install:
- outer tube (on to inner tube)
- copper washer New
- damper rod bolt









- 5. Tighten:
- damper rod bolt

🔌 30 Nm (3.0 m · kg, 22 ft · lb)

NOTE:

(1)

- Apply the locking agent (LOCTITE[®]) to the threads of the damper rod bolt.
- While holding the damper rod assembly with the damper rod holder ① and T-handle ②, tighten the damper rod assembly bolt.

Damper rod holder (29 mm) YM-33962 T-handle YM-01326



] { =

2





- 6. Install:
- outer tube bushing ① New
- seal spacer ②

 (with the fork seal driver weight ③ and fork seal driver attachment ④)



- 7. Install:
- washer
- oil seal ① New

(with the fork seal driver weight ② and fork seal driver attachment ③)

CAUTION:

Make sure the numbered side of the oil seal faces up.

NOTE: .

- Before installing the oil seal, lubricate its lips with lithium soap base grease.
- Lubricate the outer surface of the inner tube with fork oil.
- Before installing the oil seal, cover the top of the front fork leg with a plastic bag ④ to protect the oil seal during installation.











- 8. Install:
- \bullet oil seal clip (1)

NOTE: _

Adjust the oil seal clip so that it fits into the outer tube's groove.

- 9. Install:
- dust seal ① New (with the fork seal driver weight ②)

10.Fill:

 front fork leg (with the specified amount of the recommended fork oil)



NOTE: _

- While filling the front fork leg, keep it upright.
- After filling, slowly pump the front fork leg up and down to distribute the fork oil.







- 11.Install:
- fork spring
- spring seat
- collar
- cap bolt

NOTE: .

- Install the spring with the smaller pitch (a) facing up (A).
- Before installing the cap bolt, lubricate its O-ring with grease.
- Temporarily tighten the cap bolt.

EAS00662

INSTALLING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

- 1. Install:
- front fork leg

NOTE: .

- Make sure the inner tube is flush with the top of the upper bracket.
- Temporarily tighten the upper and lower bracket pinch bolts.



- 2. Tighten:
- lower bracket pinch bolts ①

| X | 23 | Nm | (2.3 | m۰ | kg, | 17 | ft · | lb) | |
|---|----|----|------|----|-----|----|------|-----|--|
|---|----|----|------|----|-----|----|------|-----|--|

- cap bolt 2 3 Nm (2.3 m · kg, 17 ft · lb)
- upper bracket pinch bolt ③
 - 🔌 23 Nm (2.3 m · kg, 17 ft · lb)

A WARNING

Make sure the brake hoses and clutch hose are routed properly.

- 3. Install:
- front fender brace
- front fender
- 4. Adjust:
- compression damping Refer to "ADJUSTING THE FRONT FORK LEGS" in chapter 3.





CHAS

HANDLEBAR

| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------------|------|---------------------------------------|
| | Removing the master cylinders, | | Remove the parts in the order listed. |
| | handlebar switches and handlebar | | |
| | grips | | |
| 1 | Rear view mirror (left and right) | 2 | |
| 2 | Plastic band | 2 | |
| 3 | Front brake light switch connector | 2 | Disconnect. |
| 4 | Brake master cylinder holder | 1 | |
| 5 | Brake master cylinder | 1 | Refer to "INSTALLING THE HANDLE- |
| 6 | Right handlebar switch | 1 | BAR". |
| 7 | Throttle cable holder | 1 | |
| 8 | Throttle cable | 2 | Disconnect. |
| 9 | Throttle grip | 1 | Refer to "REMOVING THE HANDLE- |
| | | | BAR" and "INSTALLING THE HANDLE- |
| | | | BAR". |
| 10 | Clutch switch connector | 2 | Disconnect. |

CHAS



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------|------|---|
| 11 | Clutch master cylinder holder | 1 | |
| 12 | Clutch master cylinder | 1 | Refer to "INSTALLING THE HANDLE- |
| 13 | Left handlebar switch | 1 | BAR". |
| 14 | Handlebar grip | 1 | Refer to "REMOVING THE HANDLE- BAR" and "INSTALLING THE HANDLE- BAR". |
| | | | For installation, reverse the removal pro- cedure. |

7





| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------------|------|--|
| | Removing the handlebar | | Remove the parts in the order listed. |
| 1 | Upper handlebar holder | 1 | η |
| 2 | Handlebar | 1 | |
| 3 | Turn signal light bracket assembly | 1 | Refer to "INSTALLING THE HANDLE- |
| 4 | Speedometer assembly | 1 | DAR . |
| 5 | Lower handlebar holder | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |

REMOVING THE HANDLEBAR

HANDLEBAR

1. Stand the motorcycle on a level surface.

A WARNING

Securely support the motorcycle so that there is no danger of it falling over.



- 2. Remove:
- handlebar grip ①

NOTE: .

Blow compressed air between the handlebar and the handlebar grip, and gradually push the grip off the handlebar.

CHECKING THE HANDLEBAR

- 1. Check:
- handlebar ①
 Bends/cracks/damage → Replace.

A WARNING

Do not attempt to straighten a bent handlebar as this may dangerously weaken it.

- 2. Install:
- handlebar grip

•••••

- a. Apply a thin coat of rubber adhesive onto the left end of the handlebar.
- b. Slide the handlebar grip over the left end of the handlebar.
- c. Wipe off any excess rubber adhesive with a clean rag.

Do not touch the handlebar grip until the rubber adhesive has fully dried.











EAS00670 INSTALLING THE HANDLEBAR

1. Install:

• lower handlebar holder ①

🔌 40 Nm (4.0 m · kg, 29 ft · lb)

- turn signal light bracket assembly ②
- speedometer assembly ③
- 2. Install:
- handlebar (1)
- upper handlebar holder 2

🔌 20 Nm (2.0 m · kg, 14 ft · lb)

CAUTION:

- First, tighten the bolts on the front side of the handlebar holder, and then on the rear side.
- Turn the handlebar all the way to the left and right. If there is any contact with the top cover, adjust the handlebar position.

NOTE: _____

- Install upper handlebar holder as shown.
- Align the match marks (a) on the handlebar with the upper surface of the lower handlebar holder.
- 3. Install:
- handlebar grip
- ****
- a. Apply a thin coat of rubber adhesive onto the left end of the handlebar.
- b. Slide the handlebar grip over the left end of the handlebar.
- c. Wipe of any excess rubber adhesive with a clean rag.

Do not touch the handlebar grip until the rubber adhesive has fully dried.







- 4. Install:
- left handlebar switch

NOTE: _

Install the left handlebar switch as shown.

- 5. Install:
- clutch master cylinder Refer to "HYDRAULIC CLUTCH".
- 6. Install:
 - right handlebar switch

NOTE: _

Install the right handlebar switch as shown.

- 7. Install:
- front brake master cylinder Refer to "FRONT AND REAR BRAKES".
- 8. Adjust:
- brake lever free play Refer to "ADJUSTING THE FRONT BRAKE" in chapter 3.



Brake lever free play (at the end of the brake lever) 2 ~ 5 mm (0.08 ~ 0.20 in)

- 9. Adjust:
- throttle cable free play Refer to "ADJUSTING THE THROTTLE CABLE FREE PLAY" in chapter 3.



Throttle cable free play (at the flange of the throttle grip) 3 ~ 5 mm (0.12 ~ 0.20 in)









| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------------|------|---------------------------------------|
| | Removing the lower bracket | | Remove the parts in the order listed. |
| | Handlebar/handlebar holders | | Refer to "HANDLEBAR". |
| | Front fork legs | | Refer to "FRONT FORK". |
| 1 | Headlight lens unit | 1 | |
| 2 | Lead (in the headlight body) | 1 | Disconnect. |
| 3 | Turn signal light bracket assembly | 1 | |
| 4 | Speedometer assembly | 1 | |
| 5 | Headlight body | 1 | |
| 6 | Hose joint cover | 1 | |
| 7 | Brake hose joint | 1 | LEAD" |
| 8 | Steering stem nut | 1 | |



STEERING HEAD



| Order | Job/Part | Q'ty | Remarks |
|-------|--------------------|------|---|
| 9 | Upper bracket | 1 | η |
| 10 | Lock washer | 1 | Refer to "INSTALLING THE STEERING |
| 11 | Upper ring nut | 1 | HEAD". |
| 12 | Rubber washer | 1 | |
| 13 | Lower ring nut | 1 | Refer to "REMOVING THE LOWER |
| 14 | Lower bracket | 1 | ^F BRACKET" and "INSTALLING THE |
| | | | STEERING HEAD". |
| 15 | Bearing cover | 1 | |
| 16 | Upper bearing | 1 | |
| 17 | Lower bearing | 1 | |
| 18 | Bearing outer race | 2 | |
| 19 | Rubber seal | 1 | |
| | | | For installation, reverse the removal pro- cedure. |

7



EAS00677 **REMOVING THE LOWER BRACKET**

1. Stand the motorcycle on a level surface.

A WARNING

Securely support the motorcycle so that there is no danger of it falling over.



- lower ring nut ①
 - (with the steering nut wrench 2)
- lower bracket



Steering nut wrench YU-33975

A WARNING

Securely support the lower bracket so that there is no danger of it falling.



CHECKING THE STEERING HEAD

- 1. Wash:
- bearings
- bearing races



Recommended cleaning solvent Kerosene

- 2
- 2. Check:
- bearings (1)
- bearing races ② Damage/pitting \rightarrow Replace.



(2)

(1)





STEERING HEAD



- 3. Replace:
- bearings
- bearing races

- a. Remove the bearing races from the steering head pipe with a long rod (1) and hammer.
- b. Remove the bearing race from the lower bracket with a floor chisel (2) and hammer.
- c. Install a new rubber seal and new bearing races.

CAUTION

If the bearing race is not installed properly, the steering head pipe could be damaged.

NOTE: _

- Always replace the bearings and bearing races as a set.
- · Whenever the steering head is disassembled, replace the rubber seal.

- 4. Check:
- upper bracket
- lower bracket (along with the steering stem) Bends/cracks/damage \rightarrow Replace.

EAS00683

INSTALLING THE STEERING HEAD

- 1. Lubricate:
- upper bearing
- lower bearing
- bearing races

Recommended lubricant



- 2. Install:
- lower bracket
- lower ring nut (1)
- rubber washer (2)
- upper ring nut ③
- lock washer ④ Refer to "CHECKING AND ADJUSTING THE STEERING HEAD" in chapter 3.





STEERING HEAD



- 3. Install:
- upper bracket
- steering stem nut

NOTE:

Temporarily tighten the steering stem nut.

- 4. Install:
- front fork legs

NOTE: _

Temporarily tighten the lower bracket pinch bolts.

- 5. Tighten:
- steering stem nut ①

🔌 110 Nm (11.0 m · kg, 80 ft · lb)

- 6. Install:
- brake hose joint ①
 ③ 6 Nm (0.6 m · kg, 4.3 ft · lb)

- 7. Install:
- hose joint cover ①
 - 🔌 6 Nm (0.6 m · kg, 4.3 ft · lb)
- 8. Install:
- front fork legs Refer to "FRONT FORK".







REAR SHOCK ABSORBER



REAR SHOCK ABSORBER



| Order | Job/Part | Q'ty | Remarks |
|-------------|---|------------------|--|
| 1 2 3 | Removing the rear shock absorbers Nut (left and right) Washer (left and right) Bolt (left and right) | 2 2 2 2 | Remove the parts in the order listed. Refer to "REMOVING THE REAR SHOCK ABSORBER ASSEMBLIES" and "INSTALLING THE REAR SHOCK |
| 5 | Rear shock absorber (left and right) | 2 | ABSORBER ASSEMBLIES". For installation, reverse the removal pro- cedure. |



HANDLING THE REAR SHOCK ABSORBER

This rear shock absorber contains highly compressed nitrogen gas. Before handling the rear shock absorber, read and make sure you understand the following information. The manufacturer cannot be held responsible for property damage or personal injury that may result from improper handling of the rear shock absorber.

- Do not tamper or attempt to open the rear shock absorber.
- Do not subject the rear shock absorber to an open flame or any other source of high heat. High heat can cause an explosion due to excessive gas pressure.
- Do not deform or damage the rear shock absorber in any way. Rear shock absorber damage will result in poor damping performance.

AS00691

REMOVING THE REAR SHOCK ABSORBER ASSEMBLIES

1. Stand the motorcycle on a level surface.

A WARNING

Securely support the motorcycle so that there is no danger of it falling over.

NOTE: _

Place the motorcycle on a suitable stand so that the rear wheel is elevated.

- 2. Remove:
- rear shock absorber upper bolt
- rear shock absorber lower nut
- 3. Pull out the rear shock absorber top, and turn the rear shock absorber backward.
- 4. Remove:
- rear shock absorber







CHECKING THE REAR SHOCK ABSORBER ASSEMBLIES

- 1. Check:
- rear shock absorber rod Bends/damage → Replace the rear shock absorber assembly.
- rear shock absorber Gas leaks/oil leaks → Replace the rear shock absorber assembly.
- spring Damage/wear → Replace the rear shock absorber assembly.
- bolt Bends/damage/wear → Replace.

EAS00699

INSTALLING THE REAR SHOCK ABSORBER ASSEMBLIES

- 1. Lubricate:
- rear shock absorber mounting pivot



- 2. Install:
 - rear shock absorber

NOTE: _

The rear shock absorber should be installed so that mark (a) on the rear shock absorber faces outward.



- 3. Tighten:
- rear shock absorber upper bolt

🔌 20 Nm (2.0 m · kg, 14 ft · lb)

rear shock absorber lower nut

🔌 30 Nm (3.0 m · kg, 22 ft · lb)

SWINGARM



CHAS

SWINGARM

| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------------------|------|---------------------------------------|
| | Removing the swingarm | | Remove the parts in the order listed. |
| | Muffler | | Refer to "ENGINE" in chapter 4. |
| | Rear shock absorbers | | Refer to "REAR SHOCK ABSORBER". |
| | Final drive assembly | | Refer to "SHAFT DRIVE". |
| 1 | Pinch bolt | 1 | |
| 2 | Brake torque rod | 1 | Refer to "INSTALLING THE SWINGARM". |
| 3 | Pivot bolt cover (left and right) | 2 | |
| 4 | Locknut | 1 | Π |
| 5 | Right pivot bolt | 1 | Refer to "REMOVING THE SWINGARM" |
| 6 | Left pivot bolt/lock washer | 1/1 | and "INSTALLING THE SWINGARM". |
| 7 | Swingarm | 1 | |

7 - 89

SWINGARM

CHAS



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------|------|--|
| 8 | Rubber boot/spring | 1/1 | Refer to "INSTALLING THE SWINGARM". |
| 9 | Spacer (left and right) | 2 | |
| 10 | Oil seal (left and right) | 2 | |
| 11 | Bearing (left and right)/ | 2/2 | |
| | bearing race (left and right) | | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |

REMOVING THE SWINGARM

SWINGARM

1. Stand the motorcycle on a level surface.

A WARNING

Securely support the motorcycle so that there is no danger of it falling over.

NOTE: _

Place the motorcycle on a suitable stand so that the rear wheel is elevated.



- 2. Measure:
- swingarm side play
- swingarm vertical movement
- ****
- a. Measure the tightening torque of the swingarm pivot bolts and locknut.



- b. Measure the swingarm side play by moving the swingarm from side to side.
- c. If the swingarm side play is out of specification, check the spacers and bearings.



d. Check the swingarm vertical movement by moving the swingarm up and down. If swingarm vertical movement is not smooth or if there is binding, check the spacers and bearings.

SWINGARM





EAS00708 **CHECKING THE SWINGARM**

- 1. Check:
- swingarm
 - Bends/cracks/damage \rightarrow Replace.
- 2. Check:
- left pivot bolt
- right pivot bolt Damage/wear \rightarrow Replace.
- 3. Check:
- spacers
- oil seals
- bearings
- pivot bolt covers Damage/wear \rightarrow Replace.

EAS00712 INSTALLING THE SWINGARM

- 1. Lubricate:
- bearings
- spacers
- oil seals



Recommended lubricant Lithium soap base grease

- 2. Install:
- rubber boot ①

NOTE: ____

Make sure the hole (2) on the rubber boot is facing downward.









SWINGARM



- 3. Tighten:
- left pivot bolt ①
- right pivot bolt 2
- locknut ③

a. Tighten the left pivot bolt ① to specification.



b. Tighten the right pivot bolt ② to specification.

> Right pivot bolt 6 Nm (0.6 m • kg, 4.3 ft • lb)

c. Tighten the locknut (3) to specification.



Locknut 100 Nm (10.0 m • kg, 72 ft • lb)

d. Bend the lock washer tab ④ along a flat side of the locknut.



- 4. Install:
- brake torque rod ①

🔌 22 Nm (2.2 m · kg, 16 ft · lb)

A WARNING

Always use a new cotter pin.

- 5. Install:
- rear wheel Refer to "REAR WHEEL AND BRAKE DISC".

SHAFT DRIVE



SHAFT DRIVE

| A | Symptom | В | Possible cause |
|----|---|-------|--|
| 1. | A pronounced hesitation or jerky movement | A. Be | earing damage |
| | during acceleration, deceleration or sustained | B. Im | proper gear backlash |
| | speeds. (not to be confused with engine surg- | C. Da | amaged gear teeth |
| | ng or transmission-related movements.) | D. Br | oken drive shaft |
| 2. | A rolling "rumble" noticeable at low speeds, a | E. Br | oken gear teeth |
| | nigh-pitched whine or a "clunk" from a shaft | F. Se | eizure due to lack of lubrication |
| | drive component, or from the vicinity of the | G. Sr | nall foreign objects lodged between moving |
| | shaft drive. | ра | rts |
| 3. | The shaft drive is locked up or no power is ransmitted from the engine to the rear wheel. | | |

NOTE:

Causes A, B, and C may be extremely difficult to diagnose. The symptoms are quite subtle and difficult to distinguish from normal operating noises. If there is reason to believe that these components are damaged, remove them and check them individual.





Inspection notes

1. Inves tigate any unusual noises.

The following noises may indicate a mechanical defect:

 A rolling "rumble" during coasting, acceleration or deceleration (increases with the rear wheel speed, but does not increase with higher engine or transmission speeds).

Diagnosis: Possible wheel bearing damage

b. A whining noise that varies with acceleration and deceleration.

Diagnosis: Possible incorrect reassembly or too little gear backlash

A WARNING

Insufficient gear backlash is extremely destructive to the gear teeth. If a test ride, following reassembly, indicates these symptoms, stop riding immediately to minimize gear damage.

c. A slight "clunk" evident at low speed operation (not to be confused with normal motorcycle operation).

Diagnosis: Possible broken gear teeth

A WARNING

Stop riding immediately if broken gear teeth are suspected. This condition could result in the shaft drive assembly locking up, causing a loss of control and possible injury to the rider.

SHAFT DRIVE



EAS00716 Troubleshooting chart

When causes (A) or (B) shown in the table at the beginning of the "TROUBLESHOOTING" section exist, check the following points.





CHECKING THE FINAL DRIVE OIL FOR CONTAMINATION AND CHECKING THE SHAFT DRIVE FOR LEAKS

1. Drain:

- final drive oil (from the final drive housing) Refer to "CHANGING THE FINAL DRIVE OIL" in chapter 3.
- 2. Check:
- final drive oil

Large amount of metal particles \rightarrow Check for bearing seizure.

NOTE: _

A small amount of metal particles in the final drive oil is normal.

- 3. Check:
- shaft drive housing (for oil leaks)

- a. Thoroughly clean the entire motorcycle and then completely dry it.
- b. Apply a leak-locating compound or dry powder spray to the shaft drive.
- c. Test ride the motorcycle long enough to locate a leak.
 - Oil leak \rightarrow Repair or replace the faulty part(s).
- 1) Oil seal
- 2 O-ring

③ Forward

NOTE: .

- What may appear to be an oil leak on a new or fairly new motorcycle, may result from the application of a rust preventive coating or excessive seal lubrication.
- Always clean the motorcycle and recheck the area where the leak is thought to originate from.






EAS00719 MEASURING THE RING GEAR BACKLASH

- 1. Secure the final drive assembly in a vise.
- 2. Remove:
- final drive oil drain bolt
- 3. Drain:
- final drive oil (from the final drive assembly)
- 4. Measure:
 - ring gear backlash
 Out of specification → Adjust.



•••••

a. Install the ring gear fix bolt ①, into the final gear oil drain hole.



Ring gear fix bolt (M14) YM-01524

b. Finger tighten the bolt until it stops the ring gear from moving.

NOTE: .

Do not overtighten the bolt.

c. Install the final gear backlash band ② and dial gauge ③.



Final gear backlash band YM-01230

(a) Dial-gauge-plunger contact point

- d. Gently rotate the gear coupling from engagement to engagement.
- e. Record the reading on the dial gauge.
- f. Remove the dial gauge, final gear backlash band, and bolt.
- g. Rotate the final drive pinion gear 90°.
- h. Reinstall the bolt, special tool, and dial gauge.
- i. Repeat steps (d) to (h) three more times (for a total of four measurements).
- j. If any of the readings are over specification, adjust the ring gear backlash.













ADJUSTING THE RING GEAR BACKLASH

- 1. Remove:
- ring gear bearing housing nuts
- ring gear bearing housing bolts

NOTE: .

Working in a crisscross pattern, loosen each nut 1/4 of a turn. After all of the nuts are fully loosened, remove them and the bolts.

- 2. Remove:
- ring gear bearing housing ①
- dust cover 2
- ring gear ③
- ring gear shim(s) ④
- thrust washer (5)
- 3. Adjust:
- ring gear backlash

a. Select the suitable shim(s) and thrust washer with the following chart.

| Thinner shim | Ring gear increased. | backlash | is |
|--------------|----------------------|----------|----|
| Thicker shim | Ring gear decreased. | backlash | is |

- b. If it is necessary to increase the ring gear backlash by more than 0.2 mm, reduce the thrust washer thickness by 0.2 mm for every 0.2 mm increase of ring gear shim thickness.
- c. If it is necessary to reduce the ring gear backlash by more than 0.2 mm, increase the thrust washer thickness by 0.2 mm for every 0.2 mm decrease of ring gear shim thickness.













EAS00721 **MEASURING THE RING-GEAR-TO-**STOPPER-BOLT CLEARANCE

1. Remove:

- ring gear bearing housing (along with the ring gear) Refer to "ADJUSTING THE RING GEAR BACKLASH".
- 2. Measure:
- ring-gear-to-stopper-bolt clearance (a) Out of specification \rightarrow Adjust.



- 1 Stopper bolt
- ② Ring gear
- 3. Install:
- ring gear bearing housing (along with the ring gear)

EAS00722

ADJUSTING THE RING-GEAR-TO-STOPPER-BOLT CLEARANCE

- 1. Remove:
- ring gear (1)
- stopper bolt 2
- stopper bolt shim(s) ③
- ring gear bearing housing
- 2. Select:
- stopper bolt shim(s)









- 3. Install:
- stopper bolt shim(s) ①

stopper bolt ②

🔌 9 Nm (0.9 m · kg, 6.5 ft · lb)

- ring gear ③
- ring gear bearing housing

CAUTION:

- The stopper bolt has left-hand threads. To tighten the stopper bolt, turn it counter-clockwise.
- Apply LOCTITE[®] onto the stopper bolt.
- 4. Measure:
- ring-gear-to-stopper-bolt clearance

NOTE:

If the ring-gear-to-stopper-bolt clearance is out of specification, repeat the above procedure.







| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------------------|------|--|
| | Removing the final drive assembly | | Remove the parts in the order listed. |
| | Final gear oil | | Drain. |
| | Rear wheel | | Refer to "REAR WHEEL AND BRAKE |
| | | | DISC". |
| | Rear shock absorber (left) | | Refer to "REAR SHOCK ABSORBER". |
| 1 | Final drive assembly | 1 | Refer to "INSTALLING THE FINAL |
| | | | DRIVE ASSEMBLY". |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |



CHAS



| Order | Job/Part | Q'ty | Remarks |
|----------------|------------------------------------|------|---------------------------------------|
| | Disassembling the final drive | | Remove the parts in the order listed. |
| | assembly | | |
| 1 | Circlip | 2 | |
| 2 | Oil seal | 1 | |
| 3 | Drive shaft | 1 | |
| 4 | Spring | 1 | |
| 5 | Ring gear bearing housing/oil seal | 1/1 | Π |
| 6 | Dust cover | 1 | |
| \overline{O} | Ring gear/bearing | 1/1 | |
| 8 | Ring gear shim(s) | | DINION GEAR AND DING GEAR" |
| 9 | Thrust washer | 1 | FINION GEAR AND KING GEAR . |
| 10 | Stopper bolt | 1 | |
| (1) | Stopper bolt shim(s) | | μ |

CHAS



| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------------|------|---------------------------------------|
| 12 | Nut | 1 | Left-hand threads.] Refer to "DISAS- |
| (13) | Gear coupling | 1 | SEMBLING THE |
| (14) | Bearing retainer/oil seal | 1/1 | Left-hand threadsFINAL DRIVE |
| (15) | Final drive pinion gear/bearing | 1/1 | ASSEMBLY" and |
| (16) | Final drive pinion gear shim(s) | | []] "ALIGNING THE |
| 17 | Bearing | 1 | FINAL DRIVE PIN- |
| (18) | Bearing | 1 | ION GEAR AND |
| (19) | Oil seal | 1 | RING GEAR". |
| 20 | Collar | 1 | |
| 21 | Final drive housing | 1 | |
| | | | For assembly, reverse the disassembly |
| | | | procedure. |













DISASSEMBLING THE FINAL DRIVE ASSEMBLY

- 1. Remove:
- ring gear bearing housing nuts
- ring gear bearing housing bolts

NOTE: _

Working in a crisscross pattern, loosen each nut 1/4 of a turn. After all of the nuts are fully loosened, remove them and the bolts.

- 2. Straighten:
- punched portion of the nut

- 3. Remove:
- nut
- gear coupling ①
 (with the coupling gear/middle shaft tool ②)



Coupling gear/middle shaft tool YM-01229

- 4. Remove:
- bearing retainer
 (with the bearing retainer wrench ①)



Bearing retainer wrench YM-04050

CAUTION:

The bearing retainer has left-hand threads. To loosen the bearing retainer, turn it clockwise.

- 5. Remove:
- final drive pinion gear

Always use new bearings.



CAUTION:

The final drive pinion gear should only be removed if ring gear replacement is necessary.

NOTE: ____

Lightly tap on the end of the final drive pinion gear with a soft hammer.

EAS00725 **REMOVING AND INSTALLING THE RING GEAR BEARINGS**

- 1. Remove:
- collar (1)
- oil seal 2
- bearing ③

(with an suitable press tool ④ and an appropriate support for the final drive housing)

- 2. Check:
- bearing
 - Damage \rightarrow Replace.

- 5
- 3. Remove:
- bearing (1)

- a. Heat the final drive housing to approximately 150 °C (302 °F).
- b. Remove the bearing outer races with an appropriately shaped punch 2.
- c. Remove the inner race from the final drive pinion gear.

NOTE: _

The removal of the final drive pinion gear bearing is a difficult procedure and is rarely necessary.











4. Install:

```
    bearing New
```

- ****
- a. Heat the final gear case to approximately 150 °C (302 °F).
- b. Install the bearing outer races with a socket or appropriate tool that matches the diameter of the races.
- c. Install the inner race onto the final drive pinion gear.
- *****





5. Install:

- collar (1)
- oil seal ② New
- bearing ③

(with a suitable press tool and an appropriate support for the final drive housing)

NOTE: .

The bearing can be reused, but Yamaha recommends installing a new one.

ALIGNING THE FINAL DRIVE PINION GEAR AND RING GEAR

NOTE: _

Aligning the final drive pinion gear and ring gear is necessary when any of the following parts are replaced:

- Final drive housing
- Ring gear bearing housing
- Any bearing









- 1. Select:
- final drive pinion gear shim(s) ①
- ring gear shim(s) ②

- a. Position the final drive pinion gear and the ring gear with shims (1) and (2). Calculate the respective thicknesses from information marked on the final drive housing and the drive pinion gear.
- (1) Final drive pinion gear shim
- 2 Ring gear shim
- ③ Thrust washer

b. To find final drive pinion gear shim thickness "A", use the following formula:

Final drive pinion gear shim thickness A = (84 + a)/100 - (83 + b)/100)

Where:

(a) = a numeral (positive or negative) on the ring gear, to be divided by 100 and added to "84".

(b) = a numeral on the final drive housing, to be divided by 100 and added to "83".

Example:

If the final drive pinion gear is marked "+01" and the final drive housing is marked "50":

- A = (84 + 1/100) (83 + 50/100)
 - = (84 + 0.01) (83 + 0.50)83.50

= 0.51

Therefore, the calculated final drive pinion gear shim thickness is 0.51 mm. Shim sizes are supplied in the following thicknesses.

| K | Final drive pinion gear shims | | |
|----------|-------------------------------|----------------|--|
| Thickn | iess (mm) | 0.30 0.40 0.50 | |





Since the final drive pinion gear shims are only available in 0.10 mm increments, round off to the hundredths digit.

| Hundredth | Rounded value |
|---------------|---------------|
| 0, 1, 2 | 0 |
| 3, 4, 5, 6, 7 | 5 |
| 8, 9 | 10 |

In the example above, the calculated final drive pinion gear shim thickness is 0.51 mm. The chart instructs you to round off the 1 to 0. Thus, you should use a 0.50 mm final drive pinion gear shim.





c. To find ring gear shim thickness "B", use the following formula:

Ring gear shim thickness B = (45 + ⓒ/100) + (3 + ⓓ/100) − [(35.40 − ⓔ/100) + ᠿ]

Where:

 \bigcirc = a numeral on the final drive housing, to be divided by 100 and added to "45".

d = a numeral usually on the outside of the ring gear bearing housing, to be divided by 100 and added to "3".

e = a numeral (positive or negative) on the inside of the ring gear, to be divided by 100 and added to "35.40".

(f) = the ring gear bearing thickness constant.



Ring gear bearing thickness "①" 13.00 mm (0.5118 in)



Example:

If the final drive housing is marked "51", the ring gear bearing housing is marked "35", the ring gear is marked "-05", and "①" is 13.00:

- $\mathsf{B} = (45 + 51/100) + (3 + 35/100) -$
 - [(35.40 5/100) + 13]
 - = (45 + 0.51) + (3 + 0.35) -
 - [(35.40 0.05) + 13]
 - = 45.51 + 3.35 [(35.40 0.05) + 13]
 - = 48.86 [35.35 + 13]
 - = 48.86 48.35

Therefore, the calculated ring gear shim thickness is 0.51 mm.

Shim sizes are supplied in the following thicknesses.



Since the ring gear shims are only available in 0.10 mm increments, round off the hundredths digit.

| Hundredth | Rounded value |
|---------------|---------------|
| 0, 1, 2 | 0 |
| 3, 4, 5, 6, 7 | 5 |
| 8, 9 | 10 |

In the example above, the calculated ring gear shim thickness is 0.51 mm (0.0200 in). The chart instructs you to round off the 1 to 0. Thus, you should use a 0.50 mm (0.0197 in) ring gear shim.







- 2. Install:
- shims (as calculated)

- final drive pinion gear
- bearing retainer

🔌 110 Nm (11.0 m · kg, 80 ft · lb)

(with the bearing retainer wrench 1)

CAUTION:

The bearing retainer has left-hand threads. To tighten the bearing retainer, turn it counterclockwise.



Bearing retainer wrench YM-04050





- 3. Install:
- gear coupling ①
- nut (2) [130 Nm (13.0 m · kg, 94 ft · lb)] (with the coupling gear/middle shaft tool (3))



Coupling gear/middle shaft tool YM-01229

CAUTION:

Apply LOCTITE[®] to the nut.

4. Lock the threads with a drift punch.

- 5. Install:
- ring gear bearing housing (along with the ring gear, but without the thrust washer)
- 6. Adjust:
- ring gear backlash Refer to "MEASURING THE RING GEAR BACKLASH" and "ADJUSTING THE RING GEAR BACKLASH".



- 7. Measure:
- ring-gear-to-thrust-washer clearance
- a. Remove the ring gear bearing housing (along with the ring gear).
- b. Place four pieces of Plastigauge[®] between the original thrust washer and the ring gear.
- c. Install the ring gear bearing housing and tighten the bolts and nuts to specification.



Ring gear bearing housing bolt 40 Nm (4.0 m • kg, 29 ft • lb) Ring gear bearing housing nut 23 Nm (2.3 m • kg, 17 ft • lb)

NOTE: _

Do not turn the final drive pinion gear and ring gear while measuring the ring-gear-to-thrust-washer clearance with Plastigauge[®].

- d. Remove the ring gear bearing housing.
- e. Measure the width of the flattened Plastigauge[®] ①.



Ring-gear-to-thrust-washer clearance 0.10 ~ 0.20 mm (0.0039 ~ 0.0079 in)

- f. If the ring-gear-to-thrust-washer clearance is within specification, install the ring gear bearing housing (along with the ring gear).
- g. If the ring-gear-to-thrust-washer clearance is out of specification, select the correct thrust washer as follows.
- h. Select the suitable thrust washer from the following chart.



i. Repeat the measurement steps until the ring-gear-to-thrust-washer clearance is within the specified limits.

Ring-gear-to-thrust-washer clearance 0.10 ~ 0.20 mm (0.0039 ~ 0.0079 in)



13310101



CHECKING THE DRIVE SHAFT

SHAFT DRIVE

- 1. Check:
- drive shaft splines
 Damage/wear → Replace the drive shaft.

INSTALLING THE FINAL DRIVE ASSEMBLY

- 1. Lubricate:
- drive shaft splines



Recommended lubricant Molybdenum disulfide grease

- 2. Install:
- final drive assembly

NOTE: ____

Align the drive shaft splines with the driven yoke of the universal joint.

- 3. Tighten:
- final drive assembly nuts

🔌 42 Nm (4.2 m · kg, 30 ft · lb)

NOTE: .

Apply locking agent (LOCTITE[®]) to the threads of the final gear assembly nuts.

- 4. Install:
- rear shock absorber (left) Refer to "REAR SHOCK ABSORBER".
- rear wheel Refer to "REAR WHEEL AND BRAKE DISC".
- 5. Fill:
- final drive assembly Refer to "CHECKING THE FINAL DRIVE OIL LEVEL" in chapter 3.



EAS00729

ELECTRICAL

ELECTRICAL COMPONENTS

- 1 Ignitor unit
- ② Pressure sensor
- ③ Ignition coil (#1 & #3)
- ④ Neutral switch
- 5 Oil level gauge
- 6 V-boost control unit
- ⑦ V-boost servo motor
- (8) Ignition coil (#2 & #4)
- (9) Fuel pump relay

① Thermo switch① Temperature sender





- ① Starter relay
- ② Main fuse
- ③ Battery④ Rectifier/regulator
- 5 Sidestand switch
- (6) Rear brake light switch
- ⑦ Horn
- 8 Turn signal relay
 9 Starting circuit cutoff relay
- 1 Diode assembly
- 1 Main switch
- ⁽¹⁾ Wire harness









SWITCHES CHECKING SWITCH CONTINUITY

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, check the wiring connections and if necessary, replace the switch.

CAUTION:

Never insert the tester probes into the coupler terminal slots ①. Always insert the probes from the opposite end of the coupler, taking care not to loosen or damage the leads.

Pocket tester YU-03112

NOTE: .

- Before checking for continuity, set the pocket tester to "0" and to the " $\Omega \times$ 1" range.
- When checking for continuity, switch back and forth between the switch positions a few times.

The terminal connections for switches (e.g., main switch, engine stop switch) are shown in an illustration similar to the one on the left.

The switch positions (a) are shown in the far left column and the switch lead colors (b) are shown in the top row in the switch illustration.

NOTE:

"O—O" terminals (i.e., a closed circuit at the respective switch position).

The example illustration on the left shows that:

There is no continuity between all terminals when the switch is set to "OFF".

There is continuity between red and brown when the switch is set to "ON".



CHECKING THE SWITCHES

Check each switch for damage or wear, proper connections, and also for continuity between the terminals. Refer to "CHECKING SWITCH CONTINUITY".

Damage/wear \rightarrow Repair or replace.

Improperly connected \rightarrow Properly connect.

Incorrect continuity reading \rightarrow Replace the switch.





- ① Dimmer switch
- ② Horn switch
- ③ Turn signal switch
- ④ Clutch switch
- (5) Engine stop switch
- 6 Start switch
- ⑦ Fuel reserve switch
- (8) Front brake light switch
- ④ Main switch
- 1 Fuse
- (1) Rear brake light switch
- ③ Sidestand switch
- (3) Neutral switch
- (1) Oil level switch



CHECKING THE BULBS AND BULB SOCKETS

Check each bulb and bulb socket for damage or wear, proper connections, and also for continuity between the terminals.

Damage/wear \rightarrow Repair or replace the bulb, bulb socket or both.

Improperly connected \rightarrow Properly connect.

No continuity \rightarrow Repair or replace the bulb, bulb socket or both.





TYPES OF BULBS

The bulbs used on this motorcycle are shown in the illustration on the left.

- Bulbs (a) and (b) are used for the headlights and usually use a bulb holder that must be detached before removing the bulb. The majority of these types of bulbs can be removed from their respective socket by turning them counterclockwise.
- Bulbs ⓒ is used for turn signal and tail/ brake lights and can be removed from the socket by pushing and turning the bulb counterclockwise.
- Bulbs (d) and (e) are used for meter and indicator lights and can be removed from their respective socket by carefully pulling them out.

CHECKING THE CONDITION OF THE BULBS

The following procedure applies to all of the bulbs.

- 1. Remove:
- bulb



Since the headlight bulb gets extremely hot, keep flammable products and your hands away from the bulb until it has cooled down.

CAUTION:

- Be sure to hold the socket firmly when removing the bulb. Never pull the lead, otherwise it may be pulled out of the terminal in the coupler.
- Avoid touching the glass part of the headlight bulb to keep it free from oil, otherwise the transparency of the glass, the life of the bulb, and the luminous flux will be adversely affected. If the headlight bulb gets soiled, thoroughly clean it with a cloth moistened with alcohol or lacquer thinner.
- 2. Check:
- bulb (for continuity) (with the pocket tester) No continuity → Replace.

Pocket tester YU-03112

NOTE:

Before checking for continuity, set the pocket tester to "0" and to the " $\Omega \times 1$ " range.

- a. Connect the positive tester probe to terminal ① and the negative tester probe to terminal ②, and check the continuity.
- b. Connect the positive tester probe to terminal ① and the negative tester probe to terminal ③, and check the continuity.
- c. If either of the readings indicate no continuity, replace the bulb.





CHECKING THE CONDITION OF THE BULB SOCKETS

The following procedure applies to all of the bulb sockets.

- 1. Check:
- bulb socket (for continuity) (with the pocket tester) No continuity → Replace.

Pocket tester YU-03112

NOTE: .

Check each bulb socket for continuity in the same manner as described in the bulb section; however, note the following.

- a. Install a good bulb into the bulb socket.
- b. Connect the pocket tester probes to the respective leads of the bulb socket.
- c. Check the bulb socket for continuity. If any of the readings indicate no continuity, replace the bulb socket.

IGNITION SYSTEM



IGNITION SYSTEM CIRCUIT DIAGRAM



IGNITION SYSTEM



EAS00737 TROUBLESHOOTING

The ignition system fails to operate (no spark or intermittent spark).

Check:

- 1. main and ignition fuses
- 2. battery
- 3. spark plugs
- 4. ignition spark gap
- 5. spark plug cap resistance
- 6. ignition coil resistance
- 7. pickup coil resistance
- 8. main switch
- 9. engine stop switch
- 10.neutral switch
- 11.sidestand switch
- 12.diode assembly
- 13.vacuum pressure sensor
- 14.wiring connections (of the entire ignition system)

NOTE:

- Before troubleshooting, remove the following part(s):
- 1) top cover
- 2) electrical components board
- 3) left side cover
- 4) rider seat
- 5) main switch cover
- Troubleshoot with the following special tool(s).

Ignition checker YM-34487 Pocket tester YU-03112

EAS00738

- 1. Main and ignition fuses
- Check the main and ignition fuses for continuity.
 Refer to "CHECKING THE FUSES" in
- chapter 3.
- Are the main and ignition fuses OK?





- Check the condition of the battery. Refer to "CHECKING THE BATTERY" in chapter 3.
- Minimum open-circuit voltage 12.8 V or more at 20 °C (68 °F)

Is the battery OK?



3. Spark plugs

AS00741

The following procedure applies to all of the spark plugs.

- Check the condition of the spark plug.
- Check the spark plug type.
- Measure the spark plug gap. Refer to "CHECKING THE SPARK PLUGS" in chapter 3.

Standard spark plug DPR8EA-9 (NGK) X24EPR-U9 (DENSO) Spark plug gap

0.8 ~ 0.9 mm (0.03 ~ 0.04 in)

 Is the spark plug in good condition, is it of the correct type, and is its gap within specification?



the spark plug.

IGNITION SYSTEM



EAS00743

4. Ignition spark gap

The following procedure applies to all of the spark plugs.

- Disconnect the spark plug cap from the spark plug.
- Connect the dynamic spark tester ① as shown.
- ② Spark plug cap
- Set the main switch to "ON".
- Measure the ignition spark gap (a).
- Crank the engine by pushing the starter switch and gradually increase the spark gap until a misfire occurs.



- Remove the spark plug cap from the spark plug lead.
- Connect the pocket tester (Ω × 1k) to the spark plug cap as shown.
- Measure the spark plug cap resistance.



IGNITION SYSTEM ELEC







ELECTRIC STARTING SYSTEM CIRCUIT DIAGRAM







STARTING CIRCUIT CUTOFF SYSTEM OPERATION

If the engine stop switch is set to " ()" and the main switch is set to "ON" (both switches are closed), the starter motor can only operate if at least one of the following conditions is met:

- The transmission is in neutral (the neutral switch is closed).
- The clutch lever is pulled to the handlebar (the clutch switch is closed) and the sidestand is up (the sidestand switch is closed).

The starting circuit cutoff relay prevents the starter motor from operating when neither of these conditions has been met. In this instance, the starting circuit cutoff relay is open so current cannot reach the starter motor. When at least one of the above conditions has been met the starting circuit cutoff relay is closed and the engine can be started by pressing the starter switch.

WHEN THE TRANSMISSION IS IN NEUTRAL



WHEN THE SIDESTAND IS UP AND THE CLUTCH LEVER IS PULLED TO THE HANDLEBAR

- ① Battery
- ② Main fuse
- ③ Main switch
- ④ Ignition fuse
- 6 Starting circuit cutoff relay
- ⑦ Diode assembly⑧ Clutch switch
- (9) Sidestand switch
- Meutral switch
- (1) Start switch
- 12 Starter relay
- (3) Starter motor

EAS00739



EAS00757 TROUBLESHOOTING

The starter motor fails to turn.

Check:

- 1. main and ignition fuses
- 2. battery
- 3. starter motor
- 4. starting circuit cutoff relay
- 5. starter relay
- 6. main switch
- 7. engine stop switch
- 8. neutral switch
- 9. sidestand switch
- 10.clutch switch
- 11.start switch
- 12.diode assembly
- 13.wiring connections (of the entire starting system)

NOTE:

- Before troubleshooting, remove the following part(s):
- 1) top cover
- 2) electrical components board
- 3) left side cover
- 4) rider seat
- 5) main switch cover
- Troubleshoot with the following special tool(s).



EAS00738

- 1. Main and ignition fuses
- Check the main and ignition fuses for continuity. Refer to "CHECKING THE FUSES" in chapter 3.
- Are the main and ignition fuses OK?



- 2. Battery
- Check the condition of the battery. Refer to "CHECKING THE BATTERY" in chapter 3.
- Minimum open-circuit voltage 12.8 V or more at 20 °C (68 °F)

Is the battery OK?





AS00758

• Connect the positive battery terminal ① and starter motor lead ② with a jumper lead ③.



- A wire that is used as a jumper lead must have at least the same capacity or more as that of the battery lead, otherwise the jumper lead may burn.
- This check is likely to produce sparks, therefore make sure nothing flammable is in the vicinity.
- Does the starter motor turn?



ELECTRIC STARTING SYSTEM





8

switch.

ELECTRIC STARTING SYSTEM









STARTER MOTOR



STARTER MOTOR



| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------------|------|--|
| | Removing the starter motor | | Remove the parts in the order listed. |
| | Coolant drain cock assembly | | Refer to "THERMOSTAT ASSEMBLY |
| | | | AND CONDUIT" in chapter 5. |
| 1 | Starter motor lead | 1 | |
| 2 | Starter motor assembly | 1 | |
| | | | For installation, reverse the removal pro- |
| | | | cedure. |
EAS00768

STARTER MOTOR





| Order | Job/Part | Q'ty | Remarks |
|----------------|---------------------------------|------|---------------------------------------|
| | Disassembling the starter motor | | Remove the parts in the order listed. |
| 1 | Starter motor front cover | 1 | |
| 2 | Washer kit | 1 | |
| 3 | Starter motor rear cover | 1 | |
| 4 | Washer kit | 1 | |
| 5 | Armature coil | 1 | |
| 6 | Brush seat | 1 | |
| \overline{O} | Brush holder | 1 | |
| 8 | Starter motor yoke | 1 | |
| | | | For assembly, reverse the disassembly |
| | | | procedure. |







CHECKING THE STARTER MOTOR

- 1. Check:
- commutator
 - $\mbox{Dirt} \rightarrow \mbox{Clean}$ with 600 grit sandpaper.
- 2. Measure:
- commutator diameter ⓐ
 Out of specification → Replace the starter motor.



- 3. Measure:
- mica undercut (a)

Out of specification \rightarrow Scrape the mica to the proper measurement with a hacksaw blade that has been grounded to fit the commutator.



Mica undercut 0.7 mm (0.03 in)

NOTE: _

The mica of the commutator must be undercut to ensure proper operation of the commutator.



- 4. Measure:
 - armature assembly resistances (commutator and insulation)

Out of specification \rightarrow Replace the starter motor.

a. Measure the armature assembly resistances with the pocket tester.



b. If any resistance is out of specification, replace the starter motor.



STARTER MOTOR

- 5. Measure:
- brush length ⓐ
 Out of specification → Replace the brushes as a set.

Brush length wear limit 5 mm (0.20 in)

6. Measure:

18210401

I8210602

 brush spring force
 Out of specification → Replace the brush springs as a set.

Brush spring force 8.82 N (899 gf, 31.8 oz)

- 7. Check:
- gear teeth

Damage/wear \rightarrow Replace the gear.

- 8. Check:
- bearing
- oil seal

Damage/wear \rightarrow Replace the defective part(s).





b

a

Jul

 $\top \top \top$

EAS00772

ASSEMBLING THE STARTER MOTOR

- 1. Install:
- \bullet brush seat (1)

NOTE: _

Align the tab (a) on the brush seat with the slot (b) in the starter motor yoke.

- 2. Install:
- starter motor yoke ①
- starter motor front cover ②
- starter motor rear cover $\ensuremath{\mathfrak{3}}$

NOTE:

Align the match marks (a) on the starter motor yoke with the match marks (b) on the front and starter motor rear cover.



STARTER MOTOR

- 3. Install:
- O-rings ① New
- bolts 2

🔌 5 Nm (0.5 m · kg, 36 ft · lb)





CHARGING SYSTEM



CHARGING SYSTEM

• Check the condition of the battery.

YES

Refer to "CHECKING THE BATTERY" in

Minimum open-circuit voltage

12.8 V or more at 20 °C (68 °F)

EAS00739

Battery

chapter 3.

Is the battery OK?

0

EAS00775



NO

Clean the battery

replace the battery.

terminals.

Recharge or

EAS00774 TROUBLESHOOTING

The battery is not being charged.

Check:

- 1. main fuse
- 2. battery
- 3. charging voltage
- 4. stator coil resistance
- 5. wiring connections (of the entire charging system)

NOTE:

- Before troubleshooting, remove the following part(s):
- 1) left side cover
- 2) rider seat
- Troubleshoot with the following special tool(s).





LIGHTING SYSTEM



LIGHTING SYSTEM CIRCUIT DIAGRAM



LIGHTING SYSTEM



EAS00781 TROUBLESHOOTING

Any of the following fail to light: headlight, high beam indicator light, taillight, auxiliary light or meter light.

Check:

- 1. main and headlight fuses
- 2. battery
- 3. main switch
- 4. dimmer switch
- 5. wiring connections (of the entire lighting system)

NOTE:

- Before troubleshooting, remove the following part(s):
- 1) top cover
- 2) electrical components board
- 3) rider seat
- 4) main switch cover
- 5) headlight lens unit
- Troubleshoot with the following special tool(s).



Pocket tester YU-03112

EAS00738

- 1. Main and headlight fuses
- Check the main and headlight fuses for continuity.
 Refer to "CHECKING THE FUSES" in
 - chapter 3.
- Are the main and headlight fuses OK?



2. Battery

EAS00739

 Check the condition of the battery. Refer to "CHECKING THE BATTERY" in chapter 3.



• Is the battery OK?



3. Main switch

AS00749

- Check the main switch for continuity.
- Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?





- 3. Voltage
- Connect the pocket tester (DC 20 V) to the headlight and high beam indicator light couplers as shown.
- A When the dimmer switch is set to " $\equiv O$ " B When the dimmer switch is set to " $\equiv O$ "

Headlight coupler (wire harness side)



LIGHTING SYSTEM







- EAS00790 3. The tail/brake light fails to come on.
- 1. Tail/brake light bulb and socket
- · Check the tail/brake light bulb and socket for continuity.
- Refer to "CHECKING THE BULBS AND BULB SOCKETS".
- Are the tail/brake light bulb and socket OK?



2. Voltage

• Connect the pocket tester (DC 20 V) to the tail/brake light coupler (wire harness side) as shown.

Positive tester probe \rightarrow blue (1) Negative tester probe \rightarrow black (2)



- Set the main switch to "ON".
- Measure the voltage (12 V) of blue ① on the tail/brake light connectors (wire harness side).
- Is the voltage within specification?





This circuit is OK.





SIGNALING SYSTEM





- 1 Main switch
- ④ Main fuse
- ⑤ Battery
- 1 Front brake light switch
- (1) Engine stop switch
- ⁽²⁾ Fuel level indicator light
- ⁽²⁾ Oil level warning light
- ② Neutral indicator light
- Turn signal indicator light
- 3 Diode assembly
- 3 Fuel sender
- 36 Engine oil level switch
- ③ Neutral switch
- 40 Horn
- (1) Turn signal relay
- (1) Turn signal switch
- Horn switch
- In turn signal/position light
- 49 Rear turn signal light
- 50 Rear brake light switch
- 5) Tail/brake light
- 65 Signaling system fuse
- Ignition fuse



EAS00794 TROUBLESHOOTING

- Any of the following fail to light: flasher light, brake light or an indicator light.
- The horn fails to sound.

Check:

- 1. main, ignition, and signaling system fuses
- 2. battery
- 3. main switch
- 4. wiring connections (of the entire signaling system)

NOTE:

- Before troubleshooting, remove the following part(s):
- 1) top cover
- 2) electrical components board
- 3) rider seat
- 4) main switch cover
- 5) left side cover
- Troubleshoot with the following special tool(s).





8

ING SYSTEM".





ELEC SIGNALING SYSTEM EAS00797 Set the main switch to "ON". 2. The tail/brake light fails to come on. • Pull in the brake lever or push down on the 1. Tail/brake light bulb and socket brake pedal. • Measure the voltage (12 V) of yellow (1) on Check the tail/brake light bulb and socket the tail/brake light connectors (wire harness for continuity. Refer to "CHECKING THE BULBS AND side). Is the voltage within specification? BULB SOCKETS". Are the tail/brake light bulb and socket OK? NO YES YES NO This circuit is OK. The wiring circuit from the main switch Replace the tail/ to the meter light brake light bulb, coupler is faulty and socket or both. must be repaired. EAS00799 2. Brake light switches 3. The turn signal light, turn signal indicator light or both fail to blink. · Check the brake light switches for continuity. 1. Turn signal indicator light bulb and socket Refer to "CHECKING THE SWITCHES". • Check the turn signal light bulb and socket Is the brake light switch OK? for continuity. Refer to "CHECKING THE BULBS AND YES NO BULB SOCKETS". Are the turn signal light bulb and socket Replace the brake OK? light switch. YES NO 3. Voltage Replace the turn sig- Connect the pocket tester (DC 20 V) to the nal light bulb, socket tail/brake light connectors (wire harness or both. side) as shown. Positive tester probe \rightarrow yellow (1) Negative tester probe \rightarrow black (2) 2. Turn signal switch Check the turn signal switch for continuity. Refer to "CHECKING THE SWITCHES". ۩ Is the turn signal switch OK? NO YES R Replace the left han-2 dlebar switch.

ELEC SIGNALING SYSTEM 3. Voltage Set the main switch to "ON". Set the turn signal switch to "⇔" or "⇔". • Connect the pocket tester (DC 20 V) to the • Measure the voltage (12 V) on brown/white turn signal relay coupler (wire harness side) (1) at the turn signal relay coupler (wire haras shown. ness side). Positive tester probe \rightarrow brown (1) Is the voltage within specification? Negative tester probe \rightarrow ground NO YES The turn signal relay is faulty and must be replaced. (T) Br/W Br L W/G Y/R В 5. Voltage • Connect the pocket tester (DC 20 V) to the Set the main switch to "ON". turn signal light connector or tachometer Measure the voltage (12 V) on brown ① at coupler (wire harness side) as shown. the turn signal relay coupler (wire harness A Turn signal light side). B Turn signal indicator light Is the voltage within specification? Left turn signal light Positive tester probe \rightarrow chocolate (1) YES NO Negative tester probe \rightarrow ground Right turn signal light The wiring circuit Positive tester probe \rightarrow dark green (2) from the main switch Negative tester probe \rightarrow ground to the turn signal А relay coupler is faulty and must be Ch Dg repaired. (1)4. Voltage • Connect the pocket tester (DC 20 V) to the turn signal relay coupler (wire harness side) as shown. B Positive tester probe \rightarrow brown/white (1) Negative tester probe \rightarrow ground Sb G Sb G Dg Ch Ċh | Dg B/R R/B R/B B/R ∩ Br W/G Y/R В

















EAS00808 TROUBLESHOOTING

- The radiator fan motor fails to turn.
- The water temperature gauge needle fails to move when the engine is warm.

Check:

- 1. main, signaling system, and radiator fan motor fuses
- 2. battery
- 3. main switch
- 4. radiator fan motor
- 5. thermo switch
- 6. temperature sender
- 7. wiring connections (the entire cooling system)

NOTE:

- Before troubleshooting, remove the following part(s):
- 1) top cover
- 2) electrical components board
- 3) rider seat
- 4) main switch cover
- Troubleshoot with the following special tool(s).



Pocket tester YU-03112

EAS00738

- 1. Main, signaling system, and radiator fan motor fuses
- Check the main, signaling system, and radiator fan motor fuses for continuity.
 Refer to "CHECKING THE FUSES" in chapter 3.
- Are the main, signaling system, and radiator fan motor fuses OK?





EAS00739

 Check the condition of the battery. Refer to "CHECKING THE BATTERY" in chapter 3.



• Is the battery OK?



3. Main switch

AS00749

EAS00809

- Check the main switch for continuity.
- Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?



switch.

4. Radiator fan motor

- Disconnect the radiator fan motor coupler from the wire harness.
- Connect the battery (12 V) as shown.

Positive battery lead \rightarrow blue () Negative battery lead \rightarrow black (2)







EAS00812

6. Temperature sender

- Remove the temperature sender from the radiator.
- Connect the pocket tester (Ω × 10) to the temperature sender ① as shown.
- Immerse the temperature sender in a container filled with coolant ②.

NOTE:

0

Make sure the temperature sender terminals do not get wet.

- Place a thermometer (3) in the coolant.
- Slowly heat the coolant, and then let it cool to the specified temperature indicated in the table.
- Check the temperature sender for resistance at the temperatures indicated below.

50 °C (122 °F): 153.9 Ω

Temperature sender resistance



- Handle the temperature sender with special care.
- Never subject the temperature sender to strong shocks. If the temperature sender is dropped, replace it.



ature sender.

7. Wiring

EAS00813

- Check the entire cooling system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the cooling system's wiring properly connected and without defects?

NO

This circuit is OK.

Properly connect or repair the cooling system's wiring.



FUEL PUMP SYSTEM CIRCUIT DIAGRAM





FUEL PUMP CIRCUIT OPERATION

The ignitor unit includes the control unit for the fuel pump.

- 1 Battery
- ② Main fuse
- ③ Main switch
- (4) Ignition fuse
- 5 Engine stop switch
- 6 Fuel level indicator light
- ⑦ Fuel sender
- [®] Fuel reserve switch
- (9) Fuel pump relay
- 1 Fuel pump
- 1 Ignitor unit





TROUBLESHOOTING

If the fuel pump fails to operate.

Check:

- 1. main and ignition fuses
- 2. battery
- 3. main switch
- 4. engine stop switch
- 5. fuel reserve switch
- 6. fuel level indicator light bulb and socket
- 7. fuel sender
- 8. fuel pump relay
- 9. fuel pump resistance
- 10.wiring connections (the entire fuel system)

NOTE:

- Before troubleshooting, remove the following part(s):
- 1) top cover
- 2) rider seat
- 3) main switch cover
- Troubleshoot with the following special tool(s).





EAS00739

- Check the condition of the battery. Refer to "CHECKING THE BATTERY" in chapter 3.
- Minimum open-circuit voltage 12.8 V or more at 20 °C (68 °F)

Is the battery OK?



3. Main switch

AS00749

- Check the main switch for continuity.
 Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?



4. Engine stop switch

- Check the engine stop switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the engine stop switch OK?



ELEC



8 - 49



eAS00817 9. Fuel pump resistance

- Disconnect the fuel pump coupler from the wire harness.
- Connect the pocket tester (Ω × 1) to the fuel pump coupler as shown.

$\begin{array}{l} \mbox{Positive tester probe} \rightarrow \mbox{blue/black} \black \b$



Measure the fuel pump resistance.



• Is the fuel pump OK?



10. Wiring connections

- Check the entire fuel pump system's wiring. Refer to "CIRCUIT DIAGRAM".
 Is the fuel system's wiring properly con-
- nected and without defects?



ELEC

CHECKING THE FUEL PUMP

Gasoline is extremely flammable and under certain circumstances there can be a danger of an explosion or fire. Be extremely careful and note the following points:

- Stop the engine before refueling.
- Do not smoke, and keep away from open flames, sparks, or any other source of fire.
- If you do accidentally spill gasoline, wipe it up immediately with dry rags.
- If gasoline touches the engine when it is hot, a fire may occur. Therefore, make sure the engine is completely cool before performing the following test.
- 1. Check:
- Fuel pump operation
- ****
- a. Fill the fuel tank.
- b. Put the end of the fuel hose into an open container.
- c. Connect the battery (12 V) to the fuel pump coupler as shown.

Positive battery lead \rightarrow blue/black (1) Negative battery lead \rightarrow black (2)

d. If fuel flows out of the fuel hose, the fuel pump is OK. If fuel does not flow, replace the fuel pump.



V-BOOST SYSTEM ELE



V-BOOST SYSTEM CIRCUIT DIAGRAM



TROUBLESHOOTING

When the engine speed changes, the V-BOOST servomotor does not operate.

Procedure 1

Check:

- 1. V-boost servomotor operation (with the V-boost servomotor coupler connected to the wire harness)
- 2. voltage (V-boost control unit)
- 3. voltage (servo motor)
- 4. V-boost servomotor operation (with the V-boost servomotor coupler disconnected from the wire harness)
- 5. V-boost servomotor resistance
- 6. wiring (the entire V-boost system)

Procedure 2

Check:

- 1. main and ignition fuses
- 2. batterv
- 3. main switch
- 4. engine stop switch
- 5. wiring

(the entire EXUP system)

NOTE:

- Before troubleshooting, remove the following part(-s):
 - 1) rider seat
 - 2) fuel tank
 - 3) bottom cowling
- Troubleshoot with the following special tool(-s).

Pocket tester YU-03112

Procedure 1

- 1. V-boost servomotor operation (with the V-boost servomotor coupler connected to the wire harness)
- Disconnect the V-boost cables from the V-boost servomotor pulley.
- Set the main switch to "ON".



Go to "Procedure 2".





low/blue)










TROUBLESHOOTING

NOTE:

EAS00844

The following guide for troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to basic troubleshooting. Refer to the relative procedure in this manual for checks, adjustments, and replacement of parts.

STARTING PROBLEMS

ENGINE

Cylinder(s) and cylinder head(s)

- Loose spark plug
- Loose cylinder head
- Damaged cylinder head gasket
- Worn or damaged cylinder
- Incorrect valve clearance
- Improperly sealed valve
- Incorrect valve-to-valve-seat contact
- Incorrect valve timing
- Faulty valve spring
- Seized valve

Piston(s) and piston ring(s)

- Improperly installed piston ring
- Damaged, worn or fatigued piston ring
- · Seized piston ring
- Seized or damaged piston

Air filter

- Improperly installed air filter
- Clogged air filter element

Crankcase and crankshaft

- Improperly assembled crankcase
- Seized crankshaft

FUEL SYSTEM

Fuel tank

- Empty fuel tank
- Clogged fuel filter
- Clogged fuel strainer
- Clogged fuel tank drain hose
- Clogged rollover valve
- Clogged rollover valve hose
- Deteriorated or contaminated fuel

Fuel pump

- Faulty fuel pump
- Faulty fuel pump relay

Carburetor(s)

- Deteriorated or contaminated fuel
- Clogged pilot jet
- Clogged pilot air passage
- Sucked-in air
- Damaged float
- Worn needle valve
- Improperly installed needle valve seat
- Incorrect fuel level
- Improperly installed pilot jet
- Clogged starter jet
- Faulty starter plunger
- · Improperly adjusted starter cable



ELECTRICAL SYSTEMS

Battery

- Discharged battery
- Faulty battery

Fuse(s)

- Blown, damaged or incorrect fuse
- Improperly installed fuse

Spark plug(s)

- Incorrect spark plug gap
- Incorrect spark plug heat range
- Fouled spark plug
- Worn or damaged electrode
- Worn or damaged insulator
- Faulty spark plug cap

Ignition coil(s)

- Cracked or broken ignition coil
- Broken or shorted primary or secondary coils
- Faulty spark plug lead

EAS00846

INCORRECT ENGINE IDLING SPEED

ENGINE

Cylinder(s) and cylinder head(s)

- Incorrect valve clearance
- Damaged valve train components

Air filter

• Clogged air filter element

FUEL SYSTEM

Carburetor(s)

- Faulty starter plunger
- Loose or clogged pilot jet
- Loose or clogged pilot air jet
- Damaged or loose carburetor joint
- Improperly synchronized carburetors
- Improperly adjusted engine idling speed (throttle stop screw)
- Improper throttle cable free play
- Flooded carburetor

Ignition system

- Faulty ignitor unit
- Faulty pickup coil
- Broken generator rotor woodruff key

Switches and wiring

- Faulty main switch
- Faulty engine stop switch
- Broken or shorted wiring
- · Faulty neutral switch
- Faulty start switch
- Faulty sidestand switch
- Faulty clutch switch
- Improperly grounded circuit
- Loose connections

Starting system

- · Faulty starter motor
- Faulty starter relay
- Faulty starting circuit cutoff relay
- Faulty starter clutch

ELECTRICAL SYSTEMS Battery

- Discharged battery
- Faulty battery

Spark plug(s)

- Incorrect spark plug gap
- Incorrect spark plug heat range
- Fouled spark plug
- Worn or damaged electrode
- Worn or damaged insulator
- Faulty spark plug cap

Ignition coil(s)

- Broken or shorted primary or secondary coils
- Faulty spark plug lead
- Cracked or broken ignition coil

Ignition system

- Faulty ignitor unit
- Faulty pickup coil
- Broken generator rotor woodruff key

POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE

Refer to "STARTING PROBLEMS".

ENGINE

Air filter

• Clogged air filter element

Air intake system

- Bent, clogged or disconnected carburetor air vent hose
- Clogged or leaking air duct

EAS00850

FAULTY GEAR SHIFTING

SHIFTING IS DIFFICULT

Refer to "CLUTCH DRAGS". SHIFT PEDAL DOES NOT MOVE Shift shaft

- Improperly adjusted shift rod
- Bent shift shaft

Shift drum and shift forks

- Foreign object in a shift drum groove
- Seized shift fork
- Bent shift fork guide bar

Transmission

- Seized transmission gear
- Foreign object between transmission gears
- Improperly assembled transmission

FAULTY CLUTCH

CLUTCH SLIPS

Clutch

- Improperly assembled clutch
- Improperly assembled clutch master cylinder
- Improperly assembled clutch release cylinder
- Incorrect clutch fluid level
- Damaged clutch hose
- Loose or fatigued clutch spring
- Loose union bolt
- Worn friction plate
- Worn clutch plate
- Damaged clutch release cylinder

Engine oil

- Incorrect oil level
- Incorrect oil viscosity (low)
- Deteriorated oil

FUEL SYSTEM Carburetor(s)

- Faulty diaphragm
- Incorrect fuel level
- Loose or clogged main jet

TRBI

Fuel pump

• Faulty fuel pump

JUMPS OUT OF GEAR Shift shaft

- Incorrect shift pedal position
- Improperly returned stopper lever

Shift forks

Worn shift fork

Shift drum

- Incorrect axial play
- Worn shift drum groove

Transmission

• Worn gear dog

CLUTCH DRAGS

Clutch

- Air in hydraulic clutch system
- Unevenly tensioned clutch springs
- Warped pressure plate
- Bent clutch plate
- Swollen friction plate
- Bent clutch push rod
- Damaged clutch boss
- Burnt primary driven gear bushing
- Damaged clutch release cylinder
- Match marks not aligned

Engine oil

- Incorrect oil level
- Incorrect oil viscosity (high)
- Deteriorated oil





ENGINE

Clogged coolant passages

- Cylinder head(s) and piston(s)
- Heavy carbon buildup

Engine oil

- Incorrect oil level
- Incorrect oil viscosity
- Inferior oil quality

COOLING SYSTEM

Coolant

Low coolant level

Radiator

- Damaged or leaking radiator
- Faulty radiator cap
- Bent or damaged radiator fin

Water pump

• Damaged or faulty water pump

Thermostat

• Thermostat stays closed

Hose(s) and pipe(s)

- Damaged hose
- Improperly connected hose
- Damaged pipe
- Improperly connected pipe

COOLING SYSTEM

Thermostat

• Thermostat stays open

POOR BRAKING PERFORMANCE

- Worn brake pad
- Worn brake disc
- Air in hydraulic brake system
- Leaking brake fluid
- Faulty brake caliper seal

FUEL SYSTEM

Carburetor(s)

- Incorrect main jet setting
- Incorrect fuel level
- Damaged or loose carburetor joint

Air filter

• Clogged air filter element

CHASSIS

Brake(s)

- Dragging brake
- ELECTRICAL SYSTEMS

Spark plug(s)

- Incorrect spark plug gap
- Incorrect spark plug heat range

Ignition system

Faulty ignitor unit

- Loose union bolt
- Damaged brake hose
- Oil or grease on the brake disc
- Oil or grease on the brake pad
- Incorrect brake fluid level



FAULTY FRONT FORK LEGS

LEAKING OIL

- Bent, damaged or rusty inner tube
- Cracked or damaged outer tube
- Improperly installed oil seal
- Damaged oil seal lip
- Incorrect oil level (high)
- · Loose damper rod assembly bolt
- Damaged damper rod assembly bolt copper washer
- Cracked or damaged cap bolt O-ring
- Loose drain bolt
- Damaged drain bolt gasket

EAS00862

UNSTABLE HANDLING

Handlebar

• Bent or improperly installed handlebar

Steering head components

- Improperly installed upper bracket
- Improperly installed lower bracket (improperly tightened ring nut)
- Bent steering stem
- Damaged ball bearing or bearing race

Front fork leg(s)

- Uneven oil levels (both front fork legs)
- Unevenly tensioned fork spring (both front fork legs)
- Broken fork spring
- Bent or damaged inner tube
- Bent or damaged outer tube

Swingarm

- Worn bearing or bushing
- Bent or damaged swingarm

MALFUNCTION

- Bent or damaged inner tube
- Bent or damaged outer tube
- Damaged fork spring
- Worn or damaged outer tube bushing
- Bent or damaged damper rod
- Incorrect oil viscosity
- Incorrect oil level

Rear shock absorber assemblies

- Faulty rear shock absorber spring
- Leaking oil or gas

Tire(s)

- Uneven tire pressures (front and rear)
- Incorrect tire pressure
- Uneven tire wear

Wheel(s)

- Incorrect wheel balance
- Deformed cast wheel
- Damaged wheel bearing
- Bent or loose wheel axle
- Excessive wheel runout

Frame

- Bent frame
- Damaged steering head pipe
- Improperly installed bearing race



HEADLIGHT DOES NOT LIGHT

- Wrong headlight bulb
- Too many electrical accessories
- Hard charging
- Incorrect connection
- Improperly grounded circuit
- Poor contacts (main or light switch)
- Burnt-out headlight bulb

HEADLIGHT BULB BURNT OUT

- Wrong headlight bulb
- Faulty battery
- Faulty rectifier/regulator
- Improperly grounded circuit
- Faulty main switch
- Faulty light switch
- Headlight bulb life expired

TAIL/BRAKE LIGHT DOES NOT LIGHT

- Wrong tail/brake light bulb
- Too many electrical accessories
- Incorrect connection
- Burnt-out tail/brake light bulb

TAIL/BRAKE LIGHT BULB BURNT OUT

- Wrong tail/brake light bulb
- Faulty battery
- · Incorrectly adjusted rear brake light switch
- Tail/brake light bulb life expired

TURN SIGNAL DOES NOT LIGHT

SHTG

- Faulty turn signal switch
- Faulty turn signal relay
- Burnt-out turn signal bulb
- Incorrect connection
- · Damaged or faulty wire harness
- Improperly grounded circuit
- Faulty battery
- Blown, damaged or incorrect fuse

TURN SIGNAL BLINKS SLOWLY

- Faulty turn signal relay
- Faulty main switch
- · Faulty turn signal switch
- Incorrect turn signal bulb

TURN SIGNAL REMAINS LIT

- Faulty turn signal relay
- Burnt-out turn signal bulb

TURN SIGNAL BLINKS QUICKLY

- Incorrect turn signal bulb
- Faulty turn signal relay
- Burnt-out turn signal bulb

HORN DOES NOT SOUND

- Improperly adjusted horn
- Damaged or faulty horn
- Faulty main switch
- Faulty horn switch
- Faulty battery
- Blown, damaged or incorrect fuse
- · Faulty wire harness



YAMAHA MOTOR CO., LTD. 2500 SHINGAI IWATA SHIZUOKA JAPAN

PRINTED IN U.S.A.

VMX12N(C) WIRING DIAGRAM



 Main switch
 Rectifier/regulator ③ Generator
 ④ Main fuse (5) Battery(6) Starter relay ⑦ Starter motor
⑧ Starting circuit cutoff relay ③ Right handlebar switch Tront brake light switch (1) Engine stop switch 12 Start switch
13 Fuel reserve switch (1) Sidestand switch (5) Fuel pump relay
(6) Fuel pump Tooost control unit [®] V-boost servo motor ⁽ⁱ⁾ Vacuum pressure sensor Ignitor unit Ignition coil
 Spark plug 2 Spark plug
 2 Pickup coil 23 Pickup coll
29 Meter assembly
29 Fuel level indicator light
20 Oil level warning light
20 Tachometer
20 Water temperature gauge
20 Neutral indicator light
20 Turp cignal indicator light Turn signal indicator light (i) Meter light Bigh beam indicator light 3 Temperature sender j Diode assembly 3 Fuel sender il level switch 37 Neutral switch
 38 Speedometer
 39 Meter light Weiter light
Horn
Turn signal relay
Left handlebar switch
Turn signal switch
Horn switch 45 Dimmer switch We clutch switch
Clutch switch
Headlight
Front turn signal light @ Rear turn signal light
@ Rear brake light switch (i) Tail/brake light
 (ii) Tail/brake light
 (iii) Radiator fan motor
 (iii) Thermo switch
 (iii) Radiator fan motor fuse Signaling system fuse
Headlight fuse
Ignition fuse